

BRUSH CUTTER

UMK435T

PARTS CATALOGUE

2



UMK435T

FOREWORD INDEX

1

ENGINE GROUP

2

FRAME GROUP

3

PART NUMBER INDEX

4

PART NAME INDEX

5

Instruction for use of parts catalogue

- **This parts catalogue was prepared based on the latest information available as of November 17, 2005.**
- See the parts catalogue news for any revision that is made after November 17, 2005.
- **Always specify the part number when ordering a part.**
 - Check the model, type, serial numbers, color, maker, and the size as needed before ordering a part.
 - Note that the illustrations (part drawings) can differ from the actual parts in shape.
They are given just to help you to refer to the parts.
- **When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers on the cover. We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times. To check whether a parts catalogue revision has been issued, please contact your Honda distributor.**


Initial version issue date August 10, 2005
Honda Motor Co., Ltd.

CONTENTS

	Page	Address No.
● Instruction for use of parts catalogue	1	B 1
● How to refer to the part information	2	B 2
● Part catalogue structure	3	B 3
● When the parts were revised	4	B 4
● Abbreviations used in the parts catalogue	4	B 4
● How to check the part block and serial numbers	5	B 5
● Models, parts catalogue codes and applicable serial numbers	6	B 6
● Features of each type	6	B 6
● Fuel hose, general purpose hoses and vinyl hose	7	B 7
● FLAT RATE SERVICE TIME	8	B 8
● Illustrated index	13	B13
● ENGINE GROUP	16	C 1
● FRAME GROUP	31	D 1
● PART NO. INDEX	39	E 1
● PART NAME INDEX	41	F 1

How to refer to the part information

A Reference with "Illustrated index"



B Reference with "Part number index"

Part Number	Address	Page	Ref.	Part Number	Address	Page
06000				15212-ZW9-000	1-C14	3C
06316-ZW9-000	1-G9	88	1	15220-ZW9-003	1-C14	3C
11000				15332-ZW9-000	1-E8	55
11300-ZW9-405	1-C11	27	1	15332-ZW9-A30	1-E11	58
11300-ZW9-406	1-C11	27	1	15400-PFB-004	1-C11	27
11340-ZW9-000	1-C11	27	2	15422-ZW9-000	1-C14	3C
11342-ZW9-000	1-C11	27	3	15473-881-000	1-C14	3C
11381-ZW9-003	1-C12	28	1	15474-ZW9-000	1-C14	3C
12000				15611-921-000	1-C10	26
12000-ZW9-405ZA	1-C11	27	4	15655-ZW9-000	1-C11	27
12155-ZV4-A00	1-C13	29	1	16000		
12166-ZW9-000	1-C10	26	1	16010-ZV4-005	1-D4	36
12209-GB4-681	1-C16	32	1	16011-ZV4-005	1-D4	36
12210-ZW9-405ZA	1-C10	26	2	16013-ZW9-003	1-D4	36
12216-ZE2-300	1-E8	55	1	16016-ZW9-003	1-D4	36
	1-E11	58	1	16016-ZW9-721	1-D4	36
				16023-ZW9-003	1-D4	36
				16024-ZV4-650	1-D4	36
				16028-ZV4-650	1-D4	36

C Reference with "Part name index"

Part name	Address	Page	Ref.
[A]			
ABSORBER, FUEL	1-E15	62	5
ARMATURE COMP.	1-D11	43	7
ARM COMP., LINK JOINT	1-G6	85	18
ARM COMP., SHIFT LINK	1-G6	85	14
ARM COMP., TILT	1-F15	79	20
ARM, FUEL PUMP ROCKER	1-C16	32	4
ARM, REVERSE LOCK	1-F15	79	18
ARM, SHIFT LINK	1-F11	74	7
ARM, STOPPER	1-D1	33	12
ARM, THROTTLE REMOTE	1-F11	74	6
ARM, VALVE ROCKER	1-C16	32	3
[B]			
BAG, TOOL, 160MM	1-G5	84	10
BAND	1-G6	86	37
BAND B1, WIRE	1-F6	69	1
BAND, CORD	1-F3	67	18
BAND, TUBE CLIP, 11MM	1-E15	63	20
BAND, TUBE CLIP, 12.5MM	1-E15	63	19

Address No. 1-C10

Block No. E-2

Ref No.

CYLINDER HEAD

Service item F.R.T.

O-RING, 26X2.7	0.1
PLUG, SPARK	0.2
O-RING, 9.5X1.5	0.2
SENSOR ASSY., WATER TEMPERATURE	0.3
COVER COMP., HEAD	1.8
GASKET, CYLINDER HEAD	2.4
OIL SEAL, 20X32X6	3.1
HEAD COMP., CYLINDER	3.1


ZW93-EG200

Ref. No.	Part No.	Description	Reqd. QTY						Serial No.	Parts catalogue code
			BF 99D1	BFP 99D1	BF 100D1	BFP 100D1	BF 100B1	BFP 100B1		
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2	2	2	2	2			
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER	1	1	1	1	1			
3	12251-ZW9-003	GASKET, CYLINDER HEAD	1	1	1	1	1			
4	12310-ZW9-000	COVER COMP., HEAD	1	1	1	1	1			
5	12312-ZW9-000	PACKING, HEAD COVER	1	1	1	1	1			
6	15611-921-000	CAP, OIL (NO GAUGE)	1	1	1	1	1			
7	16617-ZW9-000	HOLDER, CABLE	1	1	1	1	1	SC,SG		
	16617-ZW9-010		1	1	1	1	1	1001800 LHC,LHD		
			1	1	1	1	1	1001801 LHC,LHD		
8	35673-ZW5-003	SENSOR ASSY., WATER TEMPERATURE	1	1	1	1	1			
9	90003-ZW9-000	BOLT, FLANGE, 6X22	4	4	4	4	4			
10	90007-ZW9-003	BOLT, FLANGE, 8X83	6	6	6	6	6			
11	90011-ZW9-000	BOLT, FLANGE, 6X14 (CT200)	1	1	1	1	1			
12	90020-ZW9-000	BOLT, FLANGE, 8X40	2	2	2	2	2			
13	91202-KJ9-003	OIL SEAL, 20X32X6	1	1	1	1	1			
14	91301-805-000	O-RING, 26X2.7	1	1	1	1	1			
15	91307-PK2-005	O-RING, 9.5X1.5 (HONDA KIKAKI)	1	1	1	1	1			
16	98059-55916	PLUG, SPARK (CR5EH-9)	2	2	2	2	2			
	98059-55926	PLUG, SPARK (U16FER9)	2	2	2	2	2			


2000.09.20 E

Page No.

Part catalogue structure



Ref. No.	Part No.	Description	Reqd. QTY						Serial No.	Parts catalogue code
			BF	BFP	BF	BFP	BF	BFP		
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2	2	2	2	2	2		
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER *NHS*	1	1	1	1	1	1		
3	12251-ZW9-003	GASKET, CYLINDER HEAD	1	1	1	1	1	1		
4	12310-ZW9-000	COVER COMP., HEAD	1	1	1	1	1	1		
5	12312-ZW9-000	PACKING, HEAD COVER	1	1	1	1	1	1		
6	15611-921-000	CAP, OIL (NO GAUGE)	1	1	1	1	1	1		
7	16617-ZW9-000	HOLDER, CABLE	1	1	1	1	1	1	SC,S6	
	16617-ZW9-010		1	1	1	1	1	1	1001800 LHC,LHD	



① Address number

- Address No. is provided (in place of the page No.) to help you refer to the part with the part No. or part name.

② Block title ③ Block number

④ Service item/Flat rate time

⑤ Reference number

- Title number marked with the parenthesis or parentheses indicates that it continues from the previous page.

⑥ Part number ⑦ Honda color code

⑧ Description

⑨ Assemblies

- Sections framed with broken lines in the exploded view drawings are available as complete assemblies. (Their individual parts can also be obtained.)

⑩ Color description

⑪ Note

- Notes are shown with the parentheses in the part name column.

⑫ Required quantity

- Required QTY shown in the parenthesis or parentheses indicates the optional part.
- Required QTY marked with "N" Indicates the optional part that should be selected as needed.
- Required QTY indicates the number of the part used in the block.

⑬ Serial number

⑭ Type

- When the type column is blank, it indicates that the part is applicable to all types.
- As the type of the actual unit may differ from the "parts catalogue, type" please refer to "Models, types and applicable serial numbers" for confirmation.

⑮

- Parts enclosed within a dotted line are covered in a different block.

⑯

- A hollow arrow indicates the block No. for the parts enclosed within a dotted line .

⑰

- A solid arrow indicates the block No. the part in question is connected to.

When the parts were revised



Be sure to check the serial number!!



Ref. No.	Part No.	Description	Reqd. QTY						Serial No.
			BF 99D1	BFP 99D1	BF 10D1	BFP 10D1	BF 10B1	BFP 10B1	
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2	2	2	2	2	2	
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER							
3	12251-ZW9-003	*NH8*.....DARK GRAY	1	1	1	1	1	1	
4	12310-ZW9-000	GASKET, CYLINDER HEAD	1	1	1	1	1	1	
5	12312-ZW9-000	COVER COMP., HEAD	1	1	1	1	1	1	
6	15611-921-000	PACKING, HEAD COVER	1	1	1	1	1	1	
7	16617-ZW9-000	CAP, OIL	1	1	1	1	1	1	
	16617-ZW9-010	(NO GAUGE)							
		HOLDER, CABLE (###)	1	1	1	1	1	1	
			1	1	1	1	1	1	

The number has been used from the initial model without revision.

When shown at the left side, it is applicable to the models of No.1001801 and the subsequent numbers.

When shown at the right side, it is applicable to the models up to No.1001800.



- The parts listed with "###" at the end of the parts name have limited supply period (parts not for sale).

Abbreviations used in the parts catalogue

- The following abbreviations are used in the parts name column.


A Ampere	FR.Front
A.C. Alternating current	IN.Inlet
ASSY. Assembly	L (100L) .Link (100 Links)
AT. Automatic transmission	L.Left
C.D.I. Capacitive discharge ignition	MMMillimeter
COMP. ... Complete	MT.Manual Transmission
D.C. Direct current	P.T.O.Power take off
EX. Exhaust	R.Right
G.F.C.I ... Ground fault circuit interruptor	RR.Rear
HEX. Hexagonal	STD.Standard
H.S.T. Hydrostatic transmission	T (22T) ...Tooth (22 Teeth)
	VVolt
	WWatt

How to check the part block and serial numbers




DVK9-B

②
CARBURETOR IDENTIFICATION
NUMBER



①
TYPE
ENGINE SERIAL NUMBER

DVK9-A



③
FRAME SERIAL NUMBER

DVK9-C

Models, parts catalogue codes and applicable serial numbers

- Models, parts catalogue codes and applicable serial Nos. given in this parts catalogue can be identified as follows.

Model	Type	Parts catalogue type	Engine		Applicable engine serial No.	Applicable frame serial No.	Applicable carburetor identification No.
			Model	Type			
UMK435T	UMST	UMST	GX35T	GY7	GCAMT-1000001~	HAAT-1000001~	WYB 14B
	UMT	UMT	GX35	GY5	GCACM-1100001~		
	UMTT	UMTT	GX35T	GY7	GCAMT-1000001~		
	U2ST	U2ST					
	U2T	U2T	GX35	GY5	GCACM-1100001~		
	U2TT	U2TT	GX35T	GY7	GCAMT-1000001~		

* Of carburetor identification numbers, only the portions underlined in the example below are used for registration.

WYB 14B

Features of each type

- See the following table for the features of each type. (Items in brackets are optional)

		Model	UMK435T					
		Type	UMST	UMT	UMTT	U2ST	U2T	U2TT
Cutter Blade	2-Blade cutter					●	●	●
	Mowing cutter		●	●	●			

Fuel hose, general purpose hoses and vinyl hose

- The standard part fuel hose, general purpose hose and vinyl hose may be substituted by the coiled bulk part.
- When ordering the standard part fuel hose, general purpose hose and vinyl hose use the bulk part number written in the parts catalog in brackets () underneath the part name.
- When exchanging the hose, cut and use at the specified length as mentioned in the part name.
(For the method of cutting the bulk part, and method of filling out orders etc., please refer to the instructions issued with the bulk part.)

Bulk part number of fuel hose, general purpose hose and vinyl hose.

Example: 9 5 0 0 1 - 7 5 0 0 1 - 5 0 M

Bulk part number:

Refers to the bulk part.

Marking code (fuel hose and general purpose hose)

Change code (Vinyl hose)

Indicates number mark or change sequence, however, the code for the bulk part must be strictly 0 (zero).

Types of code:

- Fuel hose
 - 2: Red outside braid (3 mm inside dia. only)
 - 5: Black inside braid
 - 3: Red (3 mm inside dia. only)
 - 4: Ash gray with red stripe (3 mm inside dia. only)
 - 6: Black

- General hose
 - 1: Ash gray
 - 2: Ash gray
 - 3: Black
 - 5: Black

- Vinyl hose
 - 1: Clear
 - 2: Black
 - 3: Light red
 - 6: Light red
 - 7: Pale black

Lengths:

001: 1 m (standard)
003: 3 m
008: 8 m

} Application or specification of some parts is not settled.

I.D code: (fuel hose and general purpose hose)

30: 3.0 mm
35: 3.5 mm
45: 4.5 mm

50: 5.0 mm
55: 5.3 mm, 5.5 mm
65: 6.5 mm

70: 7.0 mm
75: 7.3 mm, 7.5 mm
80: 8.0 mm

11: 11 mm
91: 12 (outside dia. 15) mm
92: 12 (outside dia. 16) mm

12: 12 (outside dia. 17) mm
14: 14 mm
17: 17 mm

ID./OD. code: (vinyl hose)

01: ID. 2.9, OD. 6.8 mm
03: ID. 3.0, OD. 6.0 mm
05: ID. 3.5, OD. 6.5 mm
07: ID. 4.0, OD. 7.0 mm
08: ID. 4.5, OD. 6.5 mm
09: ID. 4.5, OD. 8.0 mm

12: ID. 5.0, OD. 7.0 mm
10: ID. 5.0, OD. 8.0 mm
11: ID. 5.0, OD. 9.0 mm
14: ID. 6.0, OD. 9.0 mm
17: ID. 7.0, OD. 9.0 mm
19: ID. 7.0, OD. 11.0 mm

21: ID. 8.0, OD. 9.0 mm
23: ID. 8.0, OD. 12.0 mm
25: ID. 9.0, OD. 11.0 mm
27: ID. 9.0, OD. 13.0 mm
33: ID. 10.0, OD. 14.0 mm
36: ID. 11.0, OD. 13.0 mm

37: ID. 11.0, OD. 15.0 mm
38: ID. 12.0, OD. 13.0 mm
39: ID. 12.0, OD. 14.0 mm
40: ID. 12.0, OD. 16.0 mm
43: ID. 13.0, OD. 15.0 mm
45: ID. 14.0, OD. 18.0 mm

50: ID. 16.0, OD. 19.0 mm
55: ID. 17.5, OD. 20.5 mm
60: ID. 22.0, OD. 27.0 mm

Hose type:

- 1: Fuel hose
- 3: Vinyl hose
- 5: General hose


⊙ **CAUTION:** It is **DANGEROUS** to confuse the fuel hose with the general purpose hose or vinyl hose.

Never use a general purpose hose or vinyl hose in place of a fuel hose or vice versa. Always use the correct bulk part in the parts catalogue, according to the service manual or the instructions issued with the bulk part.

FLAT RATE SERVICE TIME

Flat rate service time (FRT) means the standard time required to service a product, which is listed in this manual to help the dealers control the actual working process and calculate the service charge by using it as a guide.

FRT setting system



* Float time is set by multiplying the net service time by a given coefficient.

Editorial style

The service items shown in the text are listed with the exchange work time for the repair sales parts as the subject. Other representative service items not using repair parts (removal/installation, adjustment, inspection/measuring, and other work) are listed collectively in the list in the preface, classified according to the work.

FRT setting standard

- Decimal system (in unit of 0.1) is adopted to set FRT as it is convenient to calculate the wage.
Example: (0.1) → 6 minutes, (0.2) → 12 minutes
[Labor cost per hour] x [FRT] = [Wage]
- FRT is set with a hand tool.
- Service items and FRT can be subject to change depending on development of tools and service equipment and improvement in service procedure.

Work procedure

- As the work procedure is set with the work time according to the method in the separate Service Manual, refer to this Manual as required.
- Work methods permitting servicing in the shortest time still permitting assurance of safe work and product warranty are used for the setting of service items not listed in the Service Manual.
- Work basically is to be performed by one person, and when two or more people are required, setting is done as the total time for the number of people.
- The set value for the technological level of the workers uses a person with three years of experience in the repair of Honda products as the standard.
- Special tools and service equipment used to set FRT are those specified or recommended in Service Manual.

Service item whose FRT is not presented

- Accessories and service parts that are not listed to use in this manual.
 - Locations with little aging deterioration or breakage during normal use.
 - Service work that can be finished by one touch.
 - Service work that is seldom done (i.e. extremely small causes of trouble and service frequency).
 - Products and parts whose location for installation differs according to its status of use and application.
- * When FRT is not presented, please calculate wages based on appropriate actual work time.

Operation not included of FRT

- Oil and coolant water draining, Waiting time for warming up operation and etc..
- Additional operation that involves removal/installation of standard exterior equipment.
- Indirect time spent for service by visiting the customer, trade-in, and delivery.
- Indirect time required for ordering and delivery of parts.
- Cost for grease, adhesive agent, etc. used for service work.

Explanation of FRT by using an example
(The example may differ from the actual presented items)

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
① ②	1111L1	(1, 3, 4, 7) VALVE, INTAKE4.1	②
③	1111L1A	• NOTE: OHV type • Includes: Engine removal and installation One head (intake all) add1.4	⑦ ⑤

- ① Reference No. of the illustration of part that shows location of the replacement work.
- ② FRT is an abbreviation of Flat Rate Time indicating the standard service time required for the replacement.
- ③ LON is an abbreviation of Labor Operation Number, and it is a classification of the service items by the work unit code.

The same operation code is used regardless of the models.

Standard operation is indicated with 6 digits code, and additional operation is indicated with 7 digits code.


- ④ Indicating the intake valve replacement and FRT4.1.
- ⑤ Indicating FRT1.4 that will be added when additional operation (whole intake side of one cylinder head) is done in association with intake valve replacement.

- ⑥ Indicating work condition or application condition of the service item.
- ⑦ Indicating work contents that are included in the service item.
- ⑧ Indicating a reference No. whose operation and time are the same as FRT4.1 for the intake valve.

(The application range is limited to the service items without an LON setting within a same block.)

How to refer to the service item by using the sample
 (intake valve replacement)

Open to the page of the block where the intake valve's spare part illustration is shown.



Look for the intake valve illustration, and refer to the service item and FRT that agree with the reference No.

Indication mark for the listing of service items that continues to the following page

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
2	1111L1	VALVE, INTAKE	4.1
	.	.	.
	.	.	.

+

Mark indicated at the last line.

Indication of the block with no setting of FRT

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
NO INFORMATION			

• LON code system

1	11	1	L1	A
a	b	c	d	e

- a) Category code..... Engine
- b) Location/function code Engine upper
- c) Operation code..... Replace
- d) Operation sequence number (Unit code can be shown with alphabet)
..... Intake valve
(No regular rule of code)
- e) Additional code One head (intake all)
(No regular rule of code)

1	11	1	L1	A
a		c		

a) Category codes and classification

Code	Category
1	Engine
2	Power drive
3	Fuel & Exhaust
4	Frame & Body
5	Steering
6	Electrical
7	Axle & Brake
8	Control system
9	-
0	Attachments

c) Operation codes and classification

Code	Operation category
1	Replace, Removal/Installation, Change
2	Overhaul
3	Adjust, Rotation
4	(Paint-related work: Top-coat)
5	Test, Inspect/diagnose, Measurement
6	(Overhaul-related work: Rebore)
7	(Overhaul-related work: Reseal)
8	(Resurface)
9	(Paint-related work: Refinish)
0	Repair, Cleaning, Air bleeding

Major service items without using spare parts

(1) Removal/Installation, (2) Adjustment, (3) Inspection/Measurement, (4) Overhaul, (5) Other work

E: Engine, T: Transmission, D: Drive system, B: Body and related parts

(1) Removal/Installation

Set with the parts configuration in the status of being removed from the product.

	LON	DESCRIPTION	FRT
E	1001A2	ENGINE-REMOVAL/INSTALLATION	0.2

(2) Adjustment

	LON	DESCRIPTION	FRT
E	1113A1	VALVE CLEARANCE-ADJUSTMENT NOTE: For 1 product	0.4
	3113A2	CARBURETOR IDLE-ADJUSTMENT	0.2
	8113B1	THROTTLE CABLE-ADJUSTMENT	0.1

(3) Inspection, Measurement, Cleaning

	LON	DESCRIPTION	FRT
E	1105A0	ENGINE OIL-INSPECTION	0.1
	3100A0	FUEL FILTER-CLEANING	0.3
	3120A0	AIR CLEANER-CLEANING INCLUDES: Air cleaner-inspection	0.1
	6140A0	SPARK PLUG-ADJUSTMENT/CLEANING NOTE: For 1 product	0.1
B	2165A0	BLADE CUTTER-INSPECTION	0.1

(4) Overhaul

Work condition: The required Measurements, inspections, adjustments, and cleaning/washing of each part are performed, including the main body removal/installation work and the replacement of defective parts.

	LON	DESCRIPTION	FRT
E	3112A0	CARBURETOR-OVERHAUL INCLUDES: All necessary adjustment	0.4

(5) Other work

	LON	DESCRIPTION	FRT
E	1101E1	ENGINE OIL-CHANGE INCLUDES: Engine oil-inspection	0.1


ENGINE GROUP

B13

E-2

CRANKCASE SET


C 1



E-7

CRANKSHAFT/PISTON


C 3



E-10

CAM PULLEY


C 4



E-11

RECOIL STARTER


C 6



E-12

FAN COVER/CLUTCH


C 7



E-14

CARBURETOR


C 8



E-15

AIR CLEANER


C10



E-16

MUFFLER


C11



E-17

FUEL TANK

C12



2


ENGINE GROUP

B14

E-19

C13

FLYWHEEL




VK98-E1900

E-27

C14

TOP COVER




VK98-E2700

E-28

C15

LABEL



VK98-E2800

2


FRAME GROUP

B15

F-1

HANDLE PIPE/THROTTLE LEVER

D 1




VK98-F0100

F-2

GEAR CASE

D 2




VK98-F0200

F-3

FRAME

D 3




VK98-F0300A

F-4

BLADE(UMST,UMT,UMTT)

D 4




VK98-F0400

F-4-1

BLADE(U2ST,U2T,U2TT)

D 5




VK98-F0401

F-28

LABEL

D 6




VK98-F2800

F-29

TOOL

D 7




VK98-F2900A

F-40

SHOULDER BELT

D 8




VK98-F4000A

3

E-2

CRANKCASE SET

C 1




Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	1101B7	CRANKCASEINCLUDES: Engine removal and installation (3)	1.7
2	1111D5	COVER, CYLINDER HEAD AND/OR PACKING, HEAD COVER	0.1
6	1111A2	ARM, ROCKER :INTAKEINCLUDES: Valve clearance adjustment	0.6
7	1111A1	ARM, ROCKER :EXHAUSTINCLUDES: Valve clearance adjustment	0.6
8	1111L9	LIFTER, VALVE :INTAKEINCLUDES: Valve clearance adjustment	0.6
9	1111M0	LIFTER, VALVE :EXHAUSTINCLUDES: Valve clearance adjustment	0.6
10	1171A4	TUBE, OIL (12,29)	0.4
11	1171A2	PLATE, OIL OUTLET VALVEINCLUDES: Engine removal and installation	1.3
16	1111K5	TUBE, BREATHER	0.1
+17	6141C1	PLUG, SPARK	0.1

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	10100-Z0Z-405 10100-Z3F-405	CRANKCASE SET	1	1183074	UMT,U2T
			1	1183075	UMST,UMTT,U2ST,U2TT
2	12310-Z0Z-000	COVER, CYLINDER HEAD	1		
3	12312-Z0Z-300	SEAL, HEAD COVER	1		
4	12314-Z0H-300	GROMMET, HEAD COVER	1		
5	12367-Z0H-000	FILTER, BREATHER	1		
6	14431-Z0H-003	ARM, IN. VALVE ROCKER	1		
7	14441-Z0H-003	ARM, EX. VALVE ROCKER	1		
8	14730-Z0Z-000	LIFTER COMP., IN. VALVE	1		
9	14740-Z0Z-000	LIFTER COMP., EX. VALVE	1		
10	15422-Z0Z-000	TUBE, OIL	1		
11	15510-Z0H-000	PLATE ASSY., OIL OUTLET VALVE	1		UMT,U2T
12	15571-ZM3-003	VALVE, OIL OUTLET	1		UMT,U2T
14	15600-ZM3-003 15600-Z3F-000	CAP ASSY., OIL FILLER	1		UMT,U2T
			1		UMST,UMTT,U2ST,U2TT
15	15625-ZE1-003 15625-Z0T-800	PACKING, OIL FILLER CAP	1		UMT,U2T
			1		UMST,UMTT,U2ST,U2TT
16	15721-Z0Z-000	TUBE, BREATHER	1		
17	31914-Z0H-003 31915-Z0H-003 31916-Z0H-003	PLUG, SPARK (CMR4H) (NGK) PLUG, SPARK (CMR5H) (NGK) PLUG, SPARK (CMR6H) (NGK)	(1) 1 (1)		
18	90009-Z0H-003	BOLT, SOCKET, 5X20	2		
19	90010-Z0Z-003	BOLT, SOCKET, 5X32	4		
20	90013-Z0H-004	SCREW, PAN, 4X8	2		

E-2

CRANKCASE SET

C 2




Ref. No.	L.O.N. (Relative ref. Number)	Description	F.R.T.
----------	-------------------------------	-------------	--------

+17		.INCLUDES: Spark plug check	
-----	--	-----------------------------	--

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
21	90013-Z0Z-003	SCREW, PAN, 4X8	2		
22	90017-Z0H-000	SCREW, TAPPET ADJUSTING	2		
23	90019-Z0H-003	BOLT, SOCKET, 5X12	2		
24	90206-ZM3-000	NUT, TAPPET ADJUSTING	2		
25	93500-03005-0A	SCREW, PAN, 3X5	1	-----	UMT,U2T
26	94305-40102	PIN, SPRING, 4X10	1		
27	95002-41200-08	CLAMP, TUBE (D12)	1		
28	95002-41300-04	CLAMP, TUBE (D13)	1		
29	15510-Z3E-000	PLATE ASSY., OIL OUTLET VALVE	1	-----	UMST,UMTT,U2ST,U2TT

2


FR.



VK98-E0700

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1		(2,3)	
1111J4		RING SET, PISTON	1.5
		.INCLUDES: Engine removal and installation	
1111J4F		.Replace 1 piston and/or pin and/or rod, connecting and/or bearing add	0.1
4	1101F0	CRANKSHAFT	1.5
		.INCLUDES: Engine removal and installation	
5	1101E5	OIL SEAL, CRANKSHAFT :REAR ...	1.4
		.INCLUDES: Engine removal and installation	
6	1101E4	OIL SEAL, CRANKSHAFT :FRONT ..	1.4
		.INCLUDES: Engine removal and installation	

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	13010-ZM5-000	RING SET, PISTON	1		
2	13101-Z0Z-000	PISTON	1		
3	13111-ZM5-000	PIN, PISTON	1		
4	13310-Z0Z-000	CRANKSHAFT COMP.	1		
5	91212-Z0H-003	OIL SEAL, 10X20X5	1	----- UMT,U2T	
	91212-Z3E-000		1	----- UMST,UMTT,U2ST,U2TT	
6	91214-ZM3-003	OIL SEAL, 15X25X6	1	----- UMT,U2T	
	91214-Z3F-000		1	----- UMST,UMTT,U2ST,U2TT	




VK98-E1000

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	1111K2	SEAL, INTAKE VALVE STEMINCLUDES: Engine removal and installation .INCLUDES: Valve clearance adjustment	1.5
3	1111N5	PULLEY, CAMSHAFTINCLUDES: Engine removal and installation	0.6
4	1111N6	BELT, TIMINGINCLUDES: Engine removal and installation	1.4
5	1111L1	VALVE, INTAKEINCLUDES: Engine removal and installation .INCLUDES: Valve clearance adjustment and reface	1.5
	1111L1E	.Replace intake and exhaust all add	0.1
6	1111L0	VALVE, EXHAUSTINCLUDES: Engine removal and installation .INCLUDES: Valve clearance adjustment and reface	1.5
	1111L0E	.Replace intake and exhaust all add	0.1

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	12209-Z0H-003	SEAL, VALVE STEM	1	-----	1183074 UMT,U2T
	12209-Z3E-000		1	-----	UMST,UMTT,U2ST,U2TT
			1	1183075	----- UMT,U2T
2	14126-Z0Z-003	ROLLER, 4X31.8	1		
3	14320-Z0Z-000	PULLEY COMP., CAMSHAFT	1		
4	14400-Z0Z-003	BELT, TIMING (76ZU7 G-300) ..	1		
5	14711-Z0Z-000	VALVE, IN.	1	-----	1183074 UMT,U2T
	14711-Z0Z-800		1	-----	UMST,UMTT,U2ST,U2TT
			1	1183075	----- UMT,U2T
6	14721-Z0Z-000	VALVE, EX.	1	-----	1183074 UMT,U2T
	14721-Z0Z-800		1	-----	UMST,UMTT,U2ST,U2TT
			1	1183075	----- UMT,U2T
7	14751-Z0Z-000	SPRING, VALVE	2		
8	14771-Z0H-000	RETAINER, VALVE SPRING	2		


FR.



VK98-E1000


Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
7	1111P3	SPRING, VALVE :INTAKEINCLUDES: Valve clearance adjustment .INCLUDES: Engine removal and installation	1.5
	1111P3A	.Replace intake and exhaust all add	0.1
	1111P4	SPRING, VALVE :EXHAUSTINCLUDES: Valve clearance adjustment .INCLUDES: Engine removal and installation	1.5
	1111P4A	.Replace intake and exhaust all add	0.1

FR.




Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	1121B9	STARTER, RECOIL	0.2
3	1121B1	REEL, RECOIL STARTER	0.3
5	1121B7	SPRING, RECOIL STARTER RETURN	0.3
6	1121A9	PULLEY, RECOIL STARTER	0.5
		.INCLUDES: Engine removal and installation	
9	1121B3	ROPE, RECOIL STARTER	0.3

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	28400-Z0Z-003	STARTER ASSY., RECOIL	1		
2	28414-Z0Z-000	CASE, RECOIL STARTER	1		
3	28421-ZM3-003	REEL, RECOIL STARTER	1		
4	28433-ZM3-003	GUIDE, ROPE	1		
5	28442-ZM3-003	SPRING, RECOIL STARTER	1		
6	28451-Z0H-003	PULLEY, RECOIL STARTER	1		
7	28459-Z0H-003	ARM, SWING	1		
8	28461-ZM3-003	KNOB, RECOIL STARTER	1		
9	28462-ZM3-003	ROPE, RECOIL STARTER	1		
10	90012-ZM3-003	SCREW, SETTING	1		
11	90018-Z0H-003	BOLT, SOCKET, 5X16	3		
12	91504-ZM3-003	COLLAR	1		
13	91506-ZM3-000	COLLAR A, HEAD COVER	3		




Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	1141G8	COVER, ENGINE COOLING FANINCLUDES: Engine removal and installation	0.3
2	2121F7	CLUTCH, CENTRIFUGALINCLUDES: Engine removal and installation	0.5

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	19611-Z0Z-000	COVER, FAN	1		
2	22000-Z0Z-003	CLUTCH ASSY.	1		
3	22253-Z0Z-003	BOLT, CLUTCH (8MM)	2	-----	UMT,U2T
	22253-Z3F-000		2	-----	UMST,UMTT,U2ST,U2TT
4	22254-ZM5-003	WASHER, CLUTCH (8X17)	2	-----	UMT,U2T
	22254-Z3F-000		2	-----	UMST,UMTT,U2ST,U2TT
5	22254-Z0Z-003	WASHER, WAVE (10MM)	2	-----	UMT,U2T
	22255-Z3F-000		2	-----	UMST,UMTT,U2ST,U2TT
6	90009-Z0H-003	BOLT, SOCKET, 5X20	3		



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
2		(19,22)	
3111B7		GASKET, CARBURETOR PUMP	0.4
5		(4,7)	
3111A0		BODY ASSEMBLY, PUMP	0.4
6		(1,3)	
3111A1		BODY, AIR PURGE	0.3
8		3111E3 VALVE, INLET NEEDLE	0.4
21		3111D5 PUMP, PRIMER	0.3
23		3111F3 CARBURETOR	0.2
24		3111C8 PACKING, CARBURETOR	0.2
25		(29)	
4141E3		SHROUD, ENGINE	0.2
28		3111C7 O-RING, CARBURETOR BODY	0.1
30		(14)	
3111C3		JET, MAIN	0.4

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	16010-ZM3-004	GASKET, METERING DIAPHRAGM ..	1		
2	16011-ZOH-013	GASKET, PUMP	1		
3	16013-ZOH-003	DIAPHRAGM ASSY., METERING ...	1		
4	16014-ZM3-004	DIAPHRAGM, PUMP	1		
5	16015-ZOH-013	BODY ASSY., PUMP	1		
6	16017-ZM3-004	BODY ASSY., AIR PURGE	1		
7	16018-ZM3-802	SCREEN, INLET	1		
8	16019-ZM3-004	VALVE, INLET NEEDLE	1		
9	16020-ZM3-004	SPRING, METERING LEVER	1		
10	16021-ZM3-004	SCREW, METERING LEVER PIN ...	1		
11	16022-ZM3-014	PIN, METERING LEVER	1		
12	16023-ZM3-004	LEVER, METERING	1		
13	16024-ZOH-003	RING, RETAINING	1		
14	16025-ZM3-004	O-RING	1		
15	16026-ZM3-004	COVER, PRIMER PUMP	1		
16	16027-ZM3-004	SWIVEL	1		
17	16028-ZM3-004	SCREW, THROTTLE COLLAR	2		
18	16029-ZM3-004	SCREW, PUMP COVER	4		
19	16030-ZM3-004	SPRING, PUMP	1		
20	16031-ZM3-004	WASHER	1		
21	16032-ZM3-004	PUMP, PRIMER	1		
22	16035-ZM3-802	FILTER, FUEL INLET	1		
23	16100-ZOZ-814	CARBURETOR ASSY. (WYB 14B) ..	1		
24	16221-ZOZ-000	PACKING, CARBURETOR	1		
25	19631-ZOZ-010	SHROUD	1		




Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			UMK	435T		
26	90014-ZOH-003	BOLT, 5X53	2			
27	90018-ZOH-003	BOLT, SOCKET, 5X16	2			
28	91301-ZM3-000	O-RING, 14.8X2.4	1			
29	91308-ZOH-003	O-RING, 12.3X2.4	1		----- UMT,U2T	
	91308-Z3E-000		1		----- UMST,UMTT,U2ST,U2TT	
30	99101-ZM5-0350	JET (#35)	(1)			
	99101-Z0Z-0360	JET (#36)	(1)			
	99101-Z0Z-0370	JET (#37)	1			

E-15

AIR CLEANER

C10

FR.



VK98-E1500

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	3121B8	ELEMENT, AIR CLEANER	0.1
2	3121A5	CASE, AIR CLEANER	0.1
3	3121B1	COVER, AIR CLEANER	0.1

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	17211-Z0Z-000	ELEMENT, AIR CLEANER	1		
2	17220-Z0Z-000	CASE COMP., AIR CLEANER	1		
3	17231-Z0Z-000	COVER, AIR CLEANER	1		
4	90009-Z0Z-003	BOLT, SOCKET, 5X25	1		
5	90018-Z0H-003	BOLT, SOCKET, 5X16	1		
6	94050-05000	NUT, FLANGE, 5MM	2		


2

E-16

MUFFLER

C11

FR.



VK98-E1600

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	3131C5	MUFFLER, EXHAUST	0.1
2	3131B6	GUIDE, AIR EXHAUST	0.1
3	3131G8	GUIDE, AIR EXHAUST :UNDER	0.1


Ref. No.	Part No.	Description	Reqd. QTY UMK 435T	Serial No.	Parts catalogue code
1	18310-Z0Z-010	MUFFLER COMP.	1		
2	18515-Z0Z-300	GUIDE, AIR	1		
3	18518-Z0Z-020	GUIDE COMP., UNDER AIR	1		
4	90001-Z0Z-003	BOLT, STUD 2,5X45.5	2		
5	90018-Z0H-003	BOLT, SOCKET, 5X16	2		
6	90136-SM4-901	NUT, SELF-LOCK, 5MM	2		

E-17

FUEL TANK

C12

FR.




VK98-E1700

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	3101J0	GROMMET, FUEL TUBE	0.2
2	3101H7	TANK, FUEL	0.2
5	3101A6	FILTER, FUEL	0.2
6	3101F1	TUBE, FUEL TANK	0.2
7	3101L8	TUBE, FUEL RETURN	0.2

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	17504-ZM3-003	GROMMET, FUEL TUBE	1		
2	17511-Z0Z-013	TANK, FUEL	1		
3	17533-Z0H-000	RUBBER, TANK MOUNTING	4		
4	17620-ZM3-816	CAP ASSY., FUEL TANK	1		
5	17672-Z0H-003	FILTER, FUEL	1		
6	17701-Z0Z-000	TUBE, FUEL TANK	1		
7	17702-Z0Z-J31	TUBE, FUEL RETURN	1		
8	91401-ZM3-003	CLIP, TUBE	2		

2

FR.



VK98-E1900

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	6141A5	COIL, IGNITION(ONE)INCLUDES: Engine removal and installation	0.3
3	2161B5	FLYWHEELINCLUDES: Engine removal and installation	0.6
4	6111B3	CORD, STOP SWITCH	0.1


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	30500-Z0Z-013	COIL ASSY., IGNITION	1	-----	UMT,U2T
	30500-Z3F-003		1	-----	UMST,UMTT,U2ST,U2TT
2	30522-Z0Z-000	CLIP, HIGH TENSION CORD	1	-----	UMT,U2T
	30522-Z3F-000		1	-----	UMST,UMTT,U2ST,U2TT
3	31110-Z0Z-003	FLYWHEEL COMP.	1	-----	UMT,U2T
	31110-Z3F-003		1	-----	UMST,UMTT,U2ST,U2TT
4	32195-Z0Z-J00	CORD, STOP SWITCH	1		
5	90012-Z0H-005	BOLT, SOCKET, 4X14	2		
6	94050-08000	NUT, FLANGE, 8MM	1		

E-27

TOP COVER

C14

FR.




VK98-E2700

Ref. No.	L.O.N.	(Relative ref. Number)	Description	F.R.T.
----------	--------	------------------------	-------------	--------

1	1111D6	COVER, ENGINE TOP		0.1
---	--------	-------------------	-------	-----

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	19720-Z0Z-000ZA	COVER COMP., TOP			
		R280.....POWER RED	1		
2	90015-Z0H-003	BOLT, TOP COVER	1		

2



Ref. L.O.N. (Relative ref. Number) F.R.T.
No. Description


NO INFORMATION

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	87135-ZE2-020	LABEL, E-SPEC (15.5X27.5) ...	1	-----	UMT,U2T
2	87521-Z0Z-000	MARK, EMBLEM	1	-----	UMT,U2T
	87521-Z3F-000		1	-----	UMST,UMTT,U2ST,U2TT
3	87531-Z0Z-000	MARK, HONDA	1	-----	
4	87601-Z0Z-J60	MARK, TYPE (GY5)	1	-----	UMT,U2T
	87601-Z3F-J80	MARK, TYPE (GY7)	1	-----	UMST,UMTT,U2ST,U2TT
5	87660-Z0Z-J00	MARK (4-STROKE)	1	-----	

F-1

HANDLE PIPE/THROTTLE LEVER

D 1



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	8111F5	TUBE, CORRUGATE	0.1
2	8101N3	LEVER ASSEMBLY, THROTTLE	0.4
3	8111C8	CABLE, THROTTLE	0.4
4	6151D9	SWITCH, ENGINE STOP	0.4
5	8101AG	PIPE ASSEMBLY, HANDLE	0.3
7		(6,8)	
	8101N6	HOLDER, HANDLE	0.1
9	4131E1	GRIP, HANDLE :RIGHT	0.5
10	4131E0	GRIP, HANDLE :LEFT	0.1


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	17735-VK9-A00	TUBE, CORRUGATE	1		
2	17850-VK9-A01	LEVER ASSY., THROTTLE	1		
3	17910-VK9-A00	CABLE COMP., THROTTLE	1		
4	35120-VK9-A01	SWITCH ASSY., ENGINE STOP ...	1		
5	53100-VK9-A00	PIPE ASSY., HANDLE	1		
6	53136-VK9-A01	HOLDER A, HANDLE	1		
7	53137-VK9-A01	HOLDER B, HANDLE	1		
8	53138-VK9-A01	HOLDER C, HANDLE	1		
9	53165-VK9-A00	GRIP, R. HANDLE	1		
10	53166-VK9-A00	GRIP, L. HANDLE	1		
11	90104-VK9-A01	BOLT, SOCKET, 6X30	6		
12	90651-MA6-720	BAND, WIRE HARNESS	1		
13	93893-05010-00	SCREW-WASHER, 5X10	1		
14	94002-06000-0S	NUT, HEX., 6MM	2		

3

F-2

GEAR CASE


D 2



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	2091J8	SHAFT, CUTTER BLADE GEAR	0.8
2	2161B0	CASE ASSEMBLY, CUTTER BLADE GEAR	0.2
3	2161B1	CASE, CUTTER BLADE GEAR	0.6
4	2091K2	PINION, CUTTER BLADE GEAR	0.4
5	2091J9	GEAR, CUTTER BLADE BEVEL	0.7
7	4151B8	DEFLECTOR, GRASS	0.1
15	2091K1	BEARING, CUTTER BLADE GEAR SHAFT :UPPER	0.7
	2091K3	BEARING, CUTTER BLADE GEAR PINION :INNER	0.4
16	2091K4	BEARING, CUTTER BLADE GEAR PINION :OUTER	0.4
17	2091K0	BEARING, CUTTER BLADE GEAR SHAFT :LOWER	0.7

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	23326-VK9-A02	SHAFT, GEAR	1		
2	41100-VK9-A02	CASE COMP., GEAR	1		
3	41101-VK9-A01	CASE, GEAR	1		
4	41131-VK9-A01	PINION, BEVEL	1		
5	41141-VK9-A01	GEAR, BEVEL	1		
6	76200-VK9-A01	DEFLECTOR ASSY., GRASS	1		
7	76245-VK9-A01	DEFLECTOR COMP., GRASS	1		
8	76248-VK9-A01	HOLDER, PROTECTOR	1		
9	90104-VK9-A01	BOLT, SOCKET, 6X30	3		
10	90115-VK9-A01	BOLT, SOCKET, 10X12	1		
11	93893-05010-00	SCREW-WASHER, 5X10	1		
12	94510-12000	CIRCLIP, EXTERNAL, 12MM	1		
13	94520-28000	CIRCLIP, INTERNAL, 28MM	1		
14	94520-35000	CIRCLIP, INTERNAL, 35MM	1		
15	96100-60010-00	BEARING, RADIAL BALL, 6001 ..	2		
16	96120-60010-00	BEARING, RADIAL BALL, 6001 ..	1		
17	96150-62020-10	BEARING, RADIAL BALL, 6202UU	1		

3



VK98-F0300A


Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	2121C0	OUTER, CLUTCHINCLUDES: Engine removal and installation	0.4
2	2121E8	HOUSING ASSEMBLY, CLUTCHINCLUDES: Engine removal and installation	0.3
3	2121B6	HOUSING, CLUTCHINCLUDES: Engine removal and installation	0.7
4	4101M4	PIPE, FRAMEINCLUDES: Engine removal and installation	0.5
5	2131J5	SHAFT, DRIVEINCLUDES: Engine removal and installation	0.2
6	4101C3	BRACKET, ENGINE MOUNTINGINCLUDES: Engine removal and installation	0.6
7	4101Q9	RUBBER, ENGINE MOUNTINGINCLUDES: Engine removal and installation	0.6
20	2121E7	BEARING, CLUTCH OUTERINCLUDES: Engine removal and installation	0.5

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	22100-VK9-A02	OUTER COMP., CLUTCH	1		
2	22260-VK9-A02	HOUSING ASSY., CLUTCH	1		
3	22261-VK9-A01	HOUSING, CLUTCH (A)	1		
4	40230-VK9-A00	PIPE ASSY., FRAME	1		
5	41411-VK9-A00	SHAFT, DRIVE	1		
6	50225-VK9-A01	BRACKET, ENGINE MOUNTING	1		
7	50237-VK9-A01	RUBBER, ENGINE MOUNTING	1		
8	50374-VK9-A00	HANGER (A)	1		
9	50376-VK9-A00	HANGER (B)	1		
10	50378-VK9-A00	HANGER (C)	1		
11	51511-VK9-A00	STAND	1		
12	90011-VK9-A01	BOLT, TAPPING, 5X12	2		
13	90102-VK9-A01	BOLT, SOCKET, 6X20	4		
14	90104-VK9-A01	BOLT, SOCKET, 6X30	1		
15	93893-05010-00	SCREW-WASHER, 5X10	1		
16	93893-05020-07	SCREW-WASHER, 5X20	1		
17	94510-15000	CIRCLIP, EXTERNAL, 15MM	1		
18	94520-35000	CIRCLIP, INTERNAL, 35MM	1		
19	94520-45000	CIRCLIP, INTERNAL, 45MM	1		
20	96130-62020-10	BEARING, RADIAL BALL, 6202 ..	1		

F-4

BLADE(UMST,UMT,UMTT)

D 4



VK98-F0400

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
3	2161B8	HOLDER, BLADE	0.2
5	2161A4	BLADE, CUTTER	0.1
	2161A4A	.Replace one cutter blade add	0.1
	2161N0	BLADE, CUTTER :ALL	0.2
7	2161M9	PLATE, BLADE HOLDER	0.3
8		(17)	
	7101C6	HOLDER, BEARING	0.3
9	2161N2	MOWING SET	0.2


3

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	21911-VK9-A01	GUARD, GRASS	1	-----	UMST,UMT,UMTT
2	21914-VK9-A31	GUARD, GRASS (C)	1	-----	UMST,UMT,UMTT
3	41125-VK9-A01	HOLDER A, BLADE	1	-----	UMST,UMT,UMTT
4	41126-VK9-A01	HOLDER B, BLADE	1	-----	UMST,UMT,UMTT
5	72511-VK9-A31	BLADE	3	-----	UMST,UMT,UMTT
6	72512-VK9-A31	PIN, 10MM	1	-----	UMST,UMT,UMTT
7	72615-VK9-A31	PLATE, BLADE HOLDER	1	-----	UMST,UMT,UMTT
8	72624-VK9-A31	HOLDER, BEARING	1	-----	UMST,UMT,UMTT
9	72800-VK9-A31	MOWING SET	1	-----	UMST,UMT,UMTT
10	90013-VK9-A31	BOLT, SOCKET, 6X12	6	-----	UMST,UMT,UMTT
11	90114-VK9-A31	BOLT-WASHER, 6X16	3	-----	UMST,UMT,UMTT
12	90301-VK9-A31	NUT, U, 6MM	6	-----	UMST,UMT,UMTT
13	90401-VK9-A31	WASHER	1	-----	UMST,UMT,UMTT
14	90501-VK9-A31	WASHER, SPRING, 6MM	6	-----	UMST,UMT,UMTT
15	93893-05010-00	SCREW-WASHER, 5X10	3	-----	UMST,UMT,UMTT
16	94510-15000	CIRCLIP, EXTERNAL, 15MM	1	-----	UMST,UMT,UMTT
17	96130-62020-10	BEARING, RADIAL BALL, 6202 ..	1	-----	UMST,UMT,UMTT

F-4-1

BLADE(U2ST,U2T,U2TT)

D 5



VK98-F0401

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
2	2161B9	HOLDER, BLADE(A)	0.1
4	2161A4	BLADE, CUTTER	0.1
6	2161N1	BLADE SET, CUTTER	0.1


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	21911-VK9-A01	GUARD, GRASS	1	-----	U2ST,U2T,U2TT
2	41125-VK9-A01	HOLDER A, BLADE	1	-----	U2ST,U2T,U2TT
3	41126-VK9-A01	HOLDER B, BLADE	1	-----	U2ST,U2T,U2TT
4	72511-VK9-A01	BLADE	1	-----	U2ST,U2T,U2TT
5	72623-VK9-A01	COVER, BOLT	1	-----	U2ST,U2T,U2TT
6	72800-VK9-A01	BLADE SET (2BLADE)	1	-----	U2ST,U2T,U2TT
7	90301-VK9-A01	NUT, FLANGE, 10MM	1	-----	U2ST,U2T,U2TT
8	93893-05010-00	SCREW-WASHER, 5X10	3	-----	U2ST,U2T,U2TT

3

F-28

LABEL

D 6



VK98-F2800

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
----------	--------	---------------------------------------	--------

NO INFORMATION


Ref. No.	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
			UMK	435T		
1	87150-VF9-A00	MARK, CAUTION	1			
2	87521-VK9-A00	MARK, EMBLEM	1			

3

F-29

TOOL

D 7



VK98—F2900A

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
----------	--------	---------------------------------------	--------

NO INFORMATION


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435T		
1	89101-VK9-A01	BAG, TOOL	1		
2	89216-VK9-A01	WRENCH, BOX (P16X17)	1		
3	89221-KW3-000	WRENCH, HEX., 4MM	1		
4	89221-MJ4-000	WRENCH, HEX., 5MM	1		
5	89226-KW7-900	SPANNER, 8X10	1		

3

F-40

SHOULDER BELT

D 8



VK98-F4000A

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
----------	--------	---------------------------------------	--------

NO INFORMATION

Ref. No.	Part No.	Description	Reqd. QTY UMK 435T	Serial No.	Parts catalogue code
1	60156-VK9-A01	SCREEN, DUST	1		
2	68150-VK9-A01	BELT ASSY., SHOULDER	1		
3	89104-VK9-A00	CARRY BAG	1		

3

PART NO. INDEX

E 1

Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.
10000				16020-ZM3-004	C8	23	9	22254-ZM5-003	C7	22	4	50000				89000			
10100-Z0Z-405	C1	16	1	16021-ZM3-004	C8	23	10	22255-Z3F-000	C7	22	5	50225-VK9-A01	D3	33	6	89101-VK9-A01	D7	37	1
10100-Z3F-405	C1	16	1	16022-ZM3-014	C8	23	11	22260-VK9-A02	D3	33	2	50237-VK9-A01	D3	33	7	89104-VK9-A00	D8	38	3
				16023-ZM3-004	C8	23	12	22261-VK9-A01	D3	33	3	50374-VK9-A00	D3	33	8	89216-VK9-A01	D7	37	2
				16024-Z0H-003	C8	23	13					50376-VK9-A00	D3	33	9	89221-KW3-000	D7	37	3
12000				16025-ZM3-004	C8	23	14	23000				50378-VK9-A00	D3	33	10	89221-MJ4-000	D7	37	4
12209-Z0H-003	C4	19	1	16026-ZM3-004	C8	23	15									89226-KW7-900	D7	37	5
12209-Z3E-000	C4	19	1	16027-ZM3-004	C8	23	16	23326-VK9-A02	D2	32	1								
12310-Z0Z-000	C1	16	2	16028-ZM3-004	C8	23	17					51000							
12312-Z0Z-300	C1	16	3	16029-ZM3-004	C8	23	18	28000								90000			
12314-Z0H-300	C1	16	4	16030-ZM3-004	C8	23	19					51511-VK9-A00	D3	33	11	90001-Z0Z-003	C11	26	4
12367-Z0H-000	C1	16	5	16031-ZM3-004	C8	23	20	28400-Z0Z-003	C6	21	1					90009-Z0H-003	C1	16	18
				16032-ZM3-004	C8	23	21	28414-Z0Z-000	C6	21	2	53000							
13000				16035-ZM3-802	C8	23	22	28421-ZM3-003	C6	21	3								
13010-ZM5-000	C3	18	1	16100-Z0Z-814	C8	23	23	28433-ZM3-003	C6	21	4	53100-VK9-A00	D1	31	5	90009-Z0Z-003	C10	25	4
13101-Z0Z-000	C3	18	2	16221-Z0Z-000	C8	23	24	28442-ZM3-003	C6	21	5	53136-VK9-A01	D1	31	6	90010-Z0Z-003	C1	16	19
13111-ZM5-000	C3	18	3					28451-Z0H-003	C6	21	6	53137-VK9-A01	D1	31	7	90011-VK9-A01	D3	33	12
13310-Z0Z-000	C3	18	4	17000				28459-Z0H-003	C6	21	7	53138-VK9-A01	D1	31	8	90012-Z0H-005	C13	28	5
				17211-Z0Z-000	C10	25	1	28461-ZM3-003	C6	21	8	53165-VK9-A00	D1	31	9	90012-ZM3-003	C6	21	10
				17220-Z0Z-000	C10	25	2	28462-ZM3-003	C6	21	9	53166-VK9-A00	D1	31	10	90013-VK9-A31	D4	34	10
14000				17231-Z0Z-000	C10	25	3									90013-Z0H-004	C1	16	20
14126-Z0Z-003	C4	19	2	17504-ZM3-003	C12	27	1	30000				60000				90013-Z0Z-003	C2	17	21
14320-Z0Z-000	C4	19	3	17511-Z0Z-013	C12	27	2	30500-Z0Z-013	C13	28	1	60156-VK9-A01	D8	38	1	90014-Z0H-003	C9	24	26
14400-Z0Z-003	C4	19	4	17533-Z0H-000	C12	27	3	30500-Z3F-003	C13	28	1					90015-Z0H-003	C14	29	2
14431-Z0H-003	C1	16	6	17620-ZM3-816	C12	27	4	30522-Z0Z-000	C13	28	2	68000				90017-Z0H-000	C2	17	22
14441-Z0H-003	C1	16	7	17672-Z0H-003	C12	27	5	30522-Z3F-000	C13	28	2	68150-VK9-A01	D8	38	2	90018-Z0H-003	C6	21	11
14711-Z0Z-000	C4	19	5	17701-Z0Z-000	C12	27	6												
14711-Z0Z-800	C4	19	5	17702-Z0Z-J31	C12	27	7	31000											
14721-Z0Z-000	C4	19	6	17735-VK9-A00	D1	31	1	31110-Z0Z-003	C13	28	3	72000				90019-Z0H-003	C2	17	23
14721-Z0Z-800	C4	19	6	17850-VK9-A01	D1	31	2	31110-Z3F-003	C13	28	3	72511-VK9-A01	D5	35	4	90102-VK9-A01	D3	33	13
14730-Z0Z-000	C1	16	8	17910-VK9-A00	D1	31	3	31914-Z0H-003	C1	16	17	72511-VK9-A31	D4	34	5	90104-VK9-A01	D1	31	11
14740-Z0Z-000	C1	16	9					31915-Z0H-003	C1	16	17	72512-VK9-A31	D4	34	6				
14751-Z0Z-000	C4	19	7	18000				31916-Z0H-003	C1	16	17	72615-VK9-A31	D4	34	7	90114-VK9-A31	D4	34	11
14771-Z0H-000	C4	19	8	18310-Z0Z-010	C11	26	1					72623-VK9-A01	D5	35	5	90115-VK9-A01	D2	32	10
				18515-Z0Z-300	C11	26	2	32000				72624-VK9-A31	D4	34	8	90136-SM4-901	C11	26	6
				18518-Z0Z-020	C11	26	3	32195-Z0Z-J00	C13	28	4	72800-VK9-A01	D5	35	6	90206-ZM3-000	C2	17	24
15000												72800-VK9-A31	D4	34	9	90301-VK9-A01	D5	35	7
15422-Z0Z-000	C1	16	10	19000				35000								90301-VK9-A31	D4	34	12
15510-Z0H-000	C1	16	11	19611-Z0Z-000	C7	22	1	35120-VK9-A01	D1	31	4	76000				90401-VK9-A31	D4	34	13
15510-Z3E-000	C2	17	29	19631-Z0Z-010	C8	23	25					76200-VK9-A01	D2	32	6	90501-VK9-A31	D4	34	14
15571-ZM3-003	C1	16	12	19720-Z0Z-000ZA	C14	29	1	40000				76245-VK9-A01	D2	32	7	90651-MA6-720	D1	31	12
15600-Z3F-000	C1	16	14									76248-VK9-A01	D2	32	8				
15600-ZM3-003	C1	16	14	21000				40230-VK9-A00	D3	33	4					91000			
15625-Z0T-800	C1	16	15	21911-VK9-A01	D4	34	1					87000				91212-Z0H-003	C3	18	5
15625-ZE1-003	C1	16	15					41000								91212-Z3E-000	C3	18	5
15721-Z0Z-000	C1	16	16	21914-VK9-A31	D4	34	2					87135-ZE2-020	C15	30	1	91214-Z3F-000	C3	18	6
								41100-VK9-A02	D2	32	2	87150-VF9-A00	D6	36	1	91214-ZM3-003	C3	18	6
16000				22000				41101-VK9-A01	D2	32	3	87521-VK9-A00	D6	36	2	91301-ZM3-000	C9	24	28
16010-ZM3-004	C8	23	1	22000-Z0Z-003	C7	22	2	41125-VK9-A01	D4	34	3	87521-Z0Z-000	C15	30	2	91308-Z0H-003	C9	24	29
16011-Z0H-013	C8	23	2	22100-VK9-A02	D3	33	1					87521-Z3F-000	C15	30	2	91308-Z3E-000	C9	24	29
16013-Z0H-003	C8	23	3	22253-Z0Z-003	C7	22	3	41126-VK9-A01	D4	34	4	87531-Z0Z-000	C15	30	3	91401-ZM3-003	C12	27	8
16014-ZM3-004	C8	23	4	22253-Z3F-000	C7	22	3					87601-Z0Z-J60	C15	30	4	91504-ZM3-003	C6	21	12
16015-Z0H-013	C8	23	5	22254-Z0Z-003	C7	22	5	41131-VK9-A01	D2	32	4	87601-Z3F-J80	C15	30	4	91506-ZM3-000	C6	21	13
16017-ZM3-004	C8	23	6	22254-Z3F-000	C7	22	4	41141-VK9-A01	D2	32	5	87660-Z0Z-J00	C15	30	5				
16018-ZM3-802	C8	23	7					41411-VK9-A00	D3	33	5								
16019-ZM3-004	C8	23	8																

PART NO. INDEX

E 2

Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.
93000																			
93500-03005-0A	C2	17	25																
93893-05010-00	D1	31	13																
	D2	32	11																
	D3	33	15																
	D4	34	15																
	D5	35	8																
93893-05020-07	D3	33	16																
94000																			
94002-06000-0S	D1	31	14																
94050-05000	C10	25	6																
94050-08000	C13	28	6																
94305-40102	C2	17	26																
94510-12000	D2	32	12																
94510-15000	D3	33	17																
	D4	34	16																
94520-28000	D2	32	13																
94520-35000	D2	32	14																
	D3	33	18																
94520-45000	D3	33	19																
95000																			
95002-41200-08	C2	17	27																
95002-41300-04	C2	17	28																
96000																			
96100-60010-00	D2	32	15																
96120-60010-00	D2	32	16																
96130-62020-10	D3	33	20																
	D4	34	17																
96150-62020-10	D2	32	17																
99000																			
99101-20Z-0360	C9	24	30																
99101-20Z-0370	C9	24	30																
99101-2M5-0350	C9	24	30																

F 1

5

PART NAME INDEX

F 2

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
O-RING, 12.3X2.4	C9	24	29	SPRING, METERING LEVER	C8	23	9				
O-RING, 14.8X2.4	C9	24	28	SPRING, PUMP	C8	23	19				
OUTER COMP., CLUTCH	D3	33	1	SPRING, RECOIL STARTER	C6	21	5				
[P]				SPRING, VALVE	C4	19	7				
PACKING, CARBURETOR	C8	23	24	STAND	D3	33	11				
PACKING, OIL FILLER CAP	C1	16	15	STARTER ASSY., RECOIL	C6	21	1				
PINION, BEVEL	D2	32	4	SWITCH ASSY., ENGINE STOP	D1	31	4				
PIN, 10MM	D4	34	6	SWIVEL	C8	23	16				
PIN, METERING LEVER	C8	23	11	[T]							
PIN, PISTON	C3	18	3	TANK, FUEL	C12	27	2				
PIN, SPRING, 4X10	C2	17	26	TUBE, BREATHER	C1	16	16				
PIPE ASSY., FRAME	D3	33	4	TUBE, CORRUGATE	D1	31	1				
PIPE ASSY., HANDLE	D1	31	5	TUBE, FUEL RETURN	C12	27	7				
PISTON	C3	18	2	TUBE, FUEL TANK	C12	27	6				
PLATE ASSY., OIL OUTLET VALVE	C1	16	11	TUBE, OIL	C1	16	10				
	C2	17	29								
PLATE, BLADE HOLDER	D4	34	7	[V]							
PLUG, SPARK	C1	16	17	VALVE, EX.	C4	19	6				
PULLEY COMP., CAMSHAFT	C4	19	3	VALVE, INLET NEEDLE	C8	23	8				
PULLEY, RECOIL STARTER	C6	21	6	VALVE, IN.	C4	19	5				
PUMP, PRIMER	C8	23	21	VALVE, OIL OUTLET	C1	16	12				
[R]				[W]							
REEL, RECOIL STARTER	C6	21	3	WASHER	C8	23	20				
RETAINER, VALVE SPRING	C4	19	8		D4	34	13				
RING SET, PISTON	C3	18	1	WASHER, CLUTCH	C7	22	4				
RING, RETAINING	C8	23	13	WASHER, SPRING, 6MM	D4	34	14				
ROLLER, 4X31.8	C4	19	2	WASHER, WAVE	C7	22	5				
ROPE, RECOIL STARTER	C6	21	9	WRENCH, BOX	D7	37	2				
RUBBER, ENGINE MOUNTING	D3	33	7	WRENCH, HEX., 4MM	D7	37	3				
RUBBER, TANK MOUNTING	C12	27	3	WRENCH, HEX., 5MM	D7	37	4				
[S]											
SCREEN, DUST	D8	38	1								
SCREEN, INLET	C8	23	7								
SCREW-WASHER, 5X10	D1	31	13								
	D2	32	11								
	D3	33	15								
	D4	34	15								
	D5	35	8								
SCREW-WASHER, 5X20	D3	33	16								
SCREW, METERING LEVER PIN	C8	23	10								
SCREW, PAN, 3X5	C2	17	25								
SCREW, PAN, 4X8	C1	16	20								
	C2	17	21								
SCREW, PUMP COVER	C8	23	18								
SCREW, SETTING	C6	21	10								
SCREW, TAPPET ADJUSTING	C2	17	22								
SCREW, THROTTLE COLLAR	C8	23	17								
SEAL, HEAD COVER	C1	16	3								
SEAL, VALVE STEM	C4	19	1								
SHAFT, DRIVE	D3	33	5								
SHAFT, GEAR	D2	32	1								
SHROUD	C8	23	25								
SPANNER, 8X10	D7	37	5								

1

FOREWORD INDEX

2

ENGINE GROUP

3

FRAME GROUP

4

PART NUMBER INDEX

5

PART NAME INDEX





PARTS CATALOGUE NEWS

Honda Motor Co., Ltd. Service Division

PARTS CATALOGUE - CORRECTED

Printed in Japan


CODE NO.	18VK9602
PARTS CATALOGUE TITLE	UMK435T
NEWS NO.	001

(THAILAND-KD)

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
					UMK 435T		

E-7 CRANKSHAFT/PISTON

Ref. No.	LON	(Relative ref. Number) Service item	F. R. T.
4	1101R3	CRANKSHAFT ASSEMBLY INCLUDES: Engine removal and installation	1. 4
7	1101F0	CRANKSHAFT INCLUDES: Engine removal and installation	1. 6



E-7	7	D	13310-Z0Z-305	CRANKSHAFT COMP.	(1)	-----	UMST, UMTT, U2ST, U2TT
-----	---	---	---------------	-----------------------	-----	-------	------------------------

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE

April 16, 2006



PARTS CATALOGUE NEWS

Honda Motor Co., Ltd. Service Division

PARTS CATALOGUE - CORRECTED

Printed in Japan

CODE NO.	18VK9602
PARTS CATALOGUE TITLE	UMK435T
NEWS NO.	002

(THAILAND-KD)

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
					UMK 435T		
E-28	1	L	87135-ZE2-020	LABEL, E-SPEC (15.5X27.5)	1	----- 1240539	UMT, U2T

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE

September 03, 2006



PARTS CATALOGUE NEWS

Honda Motor Co., Ltd. Service Division

PARTS CATALOGUE - CORRECTED

Printed in Japan

CODE NO.	18VK9602
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	003

(THAILAND-KD)

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY UMK 435T	Serial No.	Parts catalogue code
E-11	5	E	28442-ZM3-003	*PARTS NO. DELETION			
		D	28442-ZOH-003	SPRING, RECOIL STARTER	1		

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE

October 22, 2006



PARTS CATALOGUE NEWS

Honda Motor Co., Ltd. Service Division

PARTS CATALOGUE - CORRECTED

Printed in Japan


CODE NO.	18VK9602
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	004

(THAILAND-KD)

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
					UMK 435T		

E-14 CARBURETOR

ILLUSTRATION CORRECTED



NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE

November 02, 2006



PARTS CATALOGUE NEWS

Honda Motor Co., Ltd. Service Division

PARTS CATALOGUE - CORRECTED

Printed in Japan

CODE NO.	18VK9602
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	005

(THAILAND-KD)

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
					UMK 435T		
E-2	20		90013-Z0H-004	SCREW, PAN, 4X8	2	-----	UMT, U2T
					2	-----	1088910 UMST, UMTT, U2ST, U2TT
	A		90013-Z3E-003		2	1088911 -----	UMST, UMTT, U2ST, U2TT
	21		90013-Z0Z-003	SCREW, PAN, 4X8	2	-----	UMT, U2T
					2	-----	1088910 UMST, UMTT, U2ST, U2TT
	A		90013-Z3F-003		2	1088911 -----	UMST, UMTT, U2ST, U2TT
E-7	5		91212-Z3E-000	OIL SEAL, 10X20X5	1	-----	1088910 UMST, UMTT, U2ST, U2TT
	A		91212-Z3E-003		1	1088911 -----	UMST, UMTT, U2ST, U2TT
	6		91214-Z3F-000	OIL SEAL, 15X25X6	1	-----	1088910 UMST, UMTT, U2ST, U2TT
	A		91214-Z3F-003		1	1088911 -----	UMST, UMTT, U2ST, U2TT
E-10	1		12209-Z3E-000	SEAL, VALVE STEM	1	-----	1088910 UMST, UMTT, U2ST, U2TT
					1	1183075 -----	UMT, U2T
	A		12209-Z3E-003		1	1088911 -----	UMST, UMTT, U2ST, U2TT
E-19	5		90012-Z0H-005	BOLT, SOCKET, 4X14	2	-----	UMT, U2T
					2	-----	1088910 UMST, UMTT, U2ST, U2TT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE

PARTS CATALOGUE NEWS

BOOKNo. : 18VK9602

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
					UMK 435T 2		
		A	90012-Z3E-003		2	1088911 -----	UMST, UMTT, U2ST, U2TT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE

March 11, 2007



PARTS CATALOGUE NEWS

Honda Motor Co., Ltd. Service Division

PARTS CATALOGUE - CORRECTED

Printed in Japan

CODE NO.	18VK9602
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	006

(THAILAND-KD)

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
					UMK 435T		
E-10	4		14400-Z0Z-003	BELT, TIMING (76ZU7 G-300) ...	1	-----	UMT, U2T
					1	-----	1022910 UMST, UMTT, U2ST, U2TT
	A		14400-Z3F-003		1	1022911 -----	UMST, UMTT, U2ST, U2TT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE

April 08, 2007



PARTS CATALOGUE NEWS

Honda Motor Co., Ltd. Service Division

PARTS CATALOGUE - CORRECTED

Printed in Japan

CODE NO.	18VK9602
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	007

(THAILAND-KD)

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
					UMK 435T		

PARTS NAME CORRECTED

E-16	4	T	90001-Z0Z-003	BOLT, <u>STUD, 5X56.5</u>	2	-----	UMT, U2T
		D	90001-Z0Z-013		2	-----	UMST, UMTT, U2ST, U2TT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE

April 27, 2008



PARTS CATALOGUE NEWS

Honda Motor Co., Ltd. Service Division

PARTS CATALOGUE - CORRECTED

Printed in Japan

CODE NO.	18VK9602
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	008

(THAILAND-KD)

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY UMK 435T	Serial No.	Parts catalogue code
E-12	2		22000-Z0Z-003	CLUTCH ASSY.	1	-----	UMT, U2T
					1	----- 1373007	UMST, UMTT, U2ST, U2TT
	A		22000-Z3F-004	CLUTCH ASSY. (FCC)	1	1373008 -----	UMST, UMTT, U2ST, U2TT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
T:APPLICATION CORRECTION Z:REMARKS CHANGE