


Installation and Operation Manual

AA22 Series PA Driver/Siren Control



SM33-2

ISSUE 4.01

Northern Airborne Technology Ltd. 1925 Kirschner Road Kelowna, BC, Canada. V1Y 4N7 Telephone (250) 763-2232 Facsimile (250) 762-3374

Issued on the authority of Northern Airborne Technology Ltd.

Copyright 2008



IMPORTANT INFORMATION

This manual has been produced to provide information unique to the AA22 Series PA Driver/Siren Control. Some of this information has been published previously in the SM02 Service manual (AA20/22/23 PA110/220 Series Loudhailer / PA systems).

Earlier versions of the AA22 may not be covered by the information in this manual. Please refer to SM02, or contact the Technical Support Department at NAT Ltd.



Prepared B y: NAT 287	Checked By:	NAT 284	NAT 255	Approved By: NAT 114
--	-------------	------------	------------	----------------------------

The status of this installation and operation manual is controlled by issue shown on the title page. The status of each section is controlled by revision shown in the footer of each page. All revisions affecting sections of this manual have been incorporated into the latest issue.

	ISSUE/REVISION RECORD								
Manual Issue Number									
4.01	Section 1 Rev: 1.00 Section 2 Rev: 1.00 Section 3 Rev: 1.00	Update to current templates. Updated Section 2 with the latest drawings.	Jun 25, 2008						

Installation and Operation Manual ENG-FORM: 820-0114.DOT

CONFIDENTIAL AND PROPRIETARY TO NORTHERN AIRBORNE TECHNOLOGY LTD.

: nat

AA22 Series PA Driver/Siren Control SM33-2 Installation and Operation Manual

Table of Contents

Section	Title	Page
1.	Description	
1.1	Introduction	1-1
1.2	Product Description	1-1
1.3	Design Features	1-1
1.4	Specifications	1-1
1.4.1	Electrical Specifications	1-1
1.4.2	Physical Specifications	1-2
1.4.3	Environmental Specifications	1-2
1.5	Unit Nomenclature	1-2
2.	Installation	
2.1	Introduction	2-1
2.1	Unpacking and Inspection	2-1
2.2.1	Warranty	2-1
2.3	Continued Airworthiness	2-1
2.4	Installation Procedures	2-2
2.4.1	Warnings	2-2
2.4.2	Cautions	2-2
2.4.3	Cabling and Wiring	2-2
2.4.4	Post Installation Checks	2-3
2.5	Adjustments and Connections	2-4
2.6	Accessories Required But Not Supplied	2-5
2.7	Installation Drawings	2-5
3.	Operation	
3.1	Introduction	3-1
3.2	General Information	3-1
3.3	Controls and Indicators	3-1
3.3.1	Power Up	3-1
3.3.2	Mode Switch	3-1
3.3.3	Volume Control	3-2
3.3.4	Siren Button	3-2
3.3.5	Remote Power Switch	3-2

CONFIDENTIAL AND PROPRIETARY TO NORTHERN AIRBORNE TECHNOLOGY LTD.

: inat

AA22 Series PA Driver/Siren Control SM33-2 Installation and Operation Manual

Section 1 Description

1.1 Introduction

Information in this section consists of product description, design features and specifications for the AA22 Series PA Driver/Siren Control. All derivative product information shall be contained in the applicable manual supplement, which may be obtained from NAT as required.

Review all notes, warnings and cautions.

1.2 Product Description

The AA22 Series PA Driver/Siren Control is a compact, self-contained, Dzus-mounted unit. The AA22 is a line driver for remote mounted power amplifiers. The AA22-110 or AA22-160 is typically used with the PA110 or PA220, while the AA22-492 or AA22-493 is typically used with the PA250 or PA700.

1.3 Design Features

Microphone interfacing is accomplished from either an AA9x/AMS4x series audio controller, or a 'carbon equivalent' microphone. A radio audio input is provided to allow for radio 'rebroadcast' operation. The siren is adjustable for tone, rate and level. Provision is made for external power switching to activate PA110/220 power amplifiers.

All external connectors, switches and relay contacts are gold plated for maximum reliability. Switches and relays are sealed. G10-FR flame retardant circuit boards are post coated for maximum moisture resistance and corrosion prevention. Relays are sealed, high vibration rated (50g shock) and dry nitrogen filled.

1.4 Specifications

1.4.1 Electrical Specifications

	Power		+22 to 32 Vdc (28 Vdc nom) at 250 mA max (excl. I Internally grounded case	amps).
	Panel	Lamps	2 ea. type #387 for 28 Vdc operation Maximum lamp load 80 mA	
	Inputs			
	-	Mic	0.25 Vrms at 150 Ω	
		PA and Radio	2.5 Vrms at 3.3 Ω	
		Circuitry	Single-ended	
	Microp	hone	Industry standard 'carbon equivalent' or amplified d microphone preferred	ynamic
			Min. 200 mV output required into 150 Ω	
			David Clark M1/DC, M4, M7 recommended	
Continu	. 1 Dou	1.00	looue 4	Dogo 1



		70 mA nominal current consumption		
	AA22-160	Wail/Yelp swept siren, adjustable rate/tone Mode select switch, PA/Radio monitor 6 Vrms nominal audio output into 600 Ohms 6 Vrms nominal siren output into 600 Ohms		
	AA22-110	Standard swept siren, adjustable rate/tone Mode select switch, PA/Radio monitor >50 mW output into 150 Ohms 6 Vrms nominal siren output into 600 Ohms 70 mA nominal current consumption PA and Siren override at all times +28 Vdc switched power output Use with PA110 and PA220 series amplifiers		
1.5	Unit Nomenclature			
	Qualification	DO-160C Env. Cat. B1-BA[MN]XXXXXABBBBXXXXX		
	Shock	12g (any axis)		
	Humidity	95%		
	Altitude	25,000 feet max.		
	Temperature	-20 to +55°C (ambient)		
1.4.3	Environmental Speci	fications		
Weight 1.00 lbs (0.45 kg) excluding mating connector				
	Mounting	Standard Dzus Mounting (four fasteners)		
	Width	5.75" (146.1 mm) front panel 4.96" (126.0 mm) rear enclosure		
	Depth	6.32" (160.5 mm) behind panel, excluding mating connectors		
	Height	1.11" (29.2 mm)		
1.4.2	Physical Specification	ns		
	Key Logic	Ground-seeking inputs for all lines		
	Power Key	Switched +28 Vdc available to activate remote amplifiers		
	Output Circuitry	6 Vrms @ 1 kHz into 600 Ω ground referenced Single-ended		

	+28 Vdc switched power output Use with PA110 and PA220 series amplifiers Can be selected as a radio with keyline serving as siren key
AA22-163*	Same as AA22-160, with locking PA/RADIO select switch
AA22-165*	Same as AA22-160, with 28 Vdc NVG-suitable lighting
AA22-167*	Same as AA22-160, with 5 Vdc NVG-suitable lighting
AA22-170*	Same as AA22-163, with 28 Vdc NVG-suitable lighting
AA22-492	Wail/Yelp swept siren, adjustable rate/tone Mode select switch, PA/Radio monitor 500 mVrms nominal audio output into 600 Ohms 450 mVrms nominal siren output into 600 Ohms Siren override at all times 70 mA nominal current consumption Used with PA250 and PA700 series amplifiers Can be selected as a radio with keyline serving as siren key
AA22-493	Wail/Yelp swept siren, adjustable rate/tone Mode select switch 100 mVrms nominal audio output into 600 Ohms 90 mVrms nominal siren output into 600 Ohms Siren override at all times 80 mA nominal current consumption Used with PA250 and PA700 series amplifiers Can be selected as a radio with keyline serving as siren key
AA22-495*	Same as AA22-492, with 28 Vdc NVG-suitable lighting
AA22-592*	Same as AA22-492, with 5 Vdc lighting
AA22-594*	Same as AA22-492, with 5 Vdc NVG-suitable lighting

* These products are included in this section for reference only. For more detailed information on these and other AA22 products, contact the Product Support Department at NAT Ltd.

Section 1 ends

: inat

AA22 Series PA Driver/Siren Control SM33-2 Installation and Operation Manual

Section 2 Installation

2.1 Introduction

Information in this section consists of unpacking and inspection procedures, installation procedures, postinstallation checks and installation drawings for the AA22 Series PA Driver/Siren Control.

Review all notes, warnings and cautions.

2.2 Unpacking and Inspection

Unpack the equipment carefully and locate the warranty card. Inspect the unit visually for damage due to shipping and report all such claims immediately to the carrier involved. Check that all items listed below are present before proceeding and report any shortage immediately to your supplier:

- Warranty Card
- Operators Manual
- Certificate of Conformity or Release Certification

2.2.1 Warranty

All Northern Airborne Technology Ltd. products are warranted for 2 years from date of installation by an authorized NAT dealer, to be free of defects in workmanship or performance. This warranty covers all materials and labour, but is exclusive of any transport to deliver the defective unit to and from NAT or its designated warranty repair center, or any labour to remove or re-install the defective unit in the aircraft. Contact NAT for any questions regarding this warranty, its applicability to your units and/or for return authorization. NAT is the final arbitrator concerning warranty administration. Units which have been physically damaged, burned, immersed in water or otherwise abused beyond the scope of normal use will not be considered for warranty. **WARRANTY IS VOID UNLESS THE PRODUCT IS INSTALLED BY AN AUTHORIZED NAT DEALER**. Product for which a warranty card is not returned shall be warranted from date of manufacture.

2.3 Continued Airworthiness

Maintenance of the AA22 Series PA Driver/Siren Control is 'on condition' only. Periodic maintenance of this product is not required.

: inat

AA22 Series PA Driver/Siren Control SM33-2 Installation and Operation Manual

2.4 Installation Procedures

2.4.1 Warnings

WARNING:

High volume settings can cause hearing damage. Set the headset volume control to the minimum volume setting prior to conducting tests, and slowly increase the headset volume to a comfortable listening level.

2.4.2 Cautions

CAUTION:

Never ground any output line from the AA22 or permanent damage may result. Use of a fully floating audio wattmeter or transformer-coupled meter is recommended. Always check ADF and compass calibration after installing external speakers or "PA" amplifiers. Significant single cycle errors may be caused by the concentration of steel and magnetic material.

2.4.3 Cabling and Wiring

All wire shall be selected in accordance with the original aircraft manufacturer's Maintenance Instructions or AC43.13-1B Change 1, Paragraphs 11-76 through 11-78. Unshielded wire types shall qualify to MIL-W-22759 as specified in AC43.13-1B Change 1, Paragraphs 11-85, 11-86, and listed in Table 11-11. For shielded wire applications, use Tefzel MIL-C-27500 shielded wire with solder sleeves (for shield terminations) to make the most compact and easily terminated interconnect. Follow the connector map in Section 2.7 as required.

Allow 3" from the end of the shielded wiring to the shield termination to allow the connector hood to be easily installed. Reference the interconnect drawing in Section 2.7 for shield termination details. Note that the hood is a "clamshell" hood, and is installed after the wiring is complete. Aircraft harnessing shall permit the unit to be lowered from the panel for easy access to all side adjustments. Do NOT mount the unit until all adjustments have been performed.

Maintain wire segregation and route wiring in accordance with the original aircraft manufacturers Maintenance Instructions.

Unless otherwise noted, all wiring shall be a minimum of 22 AWG, except power and ground lines, which shall be a minimum of 20 AWG. Reference the Interconnect drawing for additional specifications. Check that the ground connection is clean and well secured, and that it shares no path with any electrically noisy aircraft accessories such as blowers, turn and bank instruments or similar loads. Power to this unit must be supplied from a separate circuit breaker or fuse (fast blow), and not attached to any other circuit breaker without additional protection. Verify that the selected circuit breaker size and wire gauge are adequate for the installation using the techniques specified in AC43.13-1B Change 1, Paragraphs 11-47 through 11-51 and 11-66 through 11-69.

: nat

AA22 Series PA Driver/Siren Control SM33-2 Installation and Operation Manual

2.4.4 Post Installation Checks

2.4.4.1 Voltage/Resistance Checks

Do not attach the AA22 until the following conditions are met.

Check the following:

- a) Check P101, pin 1 and 2 for +28 Vdc relative to ground.
- b) Check P101, pin 14, 15 and 16 for continuity to ground (less than 0.5Ω).
- c) Check P101, pin 3 for the presence of the lamp dimmer voltage.

Check the following for AA20-030 and AA20-430

d) Check P101, pin 10 for continuity to ground (less than 0.5Ω). This ground is installation specific and may be a 'hard' ground or supplied by a momentary switch (siren trigger).

2.4.4.2 Operational Checks

The PA system is not intended to be operated in a linear volume manner (i.e., it is not like a stereo system). The PA is designed to provide high levels of audio power under difficult conditions and does so by sacrificing some of the high fidelity for a higher average power output. The volume control on the AA22 is not intended to provide linear operations from the PA system and will result in broken and sporadic output from the PA when insufficient levels are delivered to the AA22 and/or to the power amplifier unit from the AA22.

For most RADIO and PA (voice) operations, it is suggested that the AA22 volume control be set to maximum (fully cw). If the system is overdriving, reduce the AA22 volume setting.

To check the system, the aircraft must be moved outside and away from as many reflective surfaces as possible. It is not recommended to operate the PA microphone on the ground, as a high risk exists for audio coupling and feedback. However, if the test is to be conducted on the ground, the aircraft should be positioned on a grassy surface to help reduce the distortion produced by sound reflected from concrete or asphalt. It is also beneficial to stuff the speaker projectors with soft rubberized foam to reduce the risk of feedback and distortion.

Advise all nearby personnel that PA system tests are to be done.

Start by checking the Siren Circuit for proper operation and tone/rate adjustment. The Siren always operates at 100% output from the AA22 and should drive the PA's to full output on audio peaks. The Level trimpot of the AA22 will be set at the factory to provide rated output at full front panel volume control adjustment.

Once the siren operation is satisfactory, you may try RADIO operations through the AA22. To achieve full output capability from the AA22, a signal of 2.5 Vrms must be delivered to the AA22 Radio audio input and the AA22 volume must be set to maximum. Lower levels of input signal or volume settings will result in poor output audio (very broken).

For PA (voice) tests, it is best that the aircraft is flown in an approximately 200 foot hover and commands are given to a human ground target for visual response to the commands. Remember, the human target should be positioned in the area that the speaker system is designed to project the audio to. This will depend on speaker orientation and the height of the aircraft. Remove all

CONFIDENTIAL AND PROPRIETARY TO NORTHERN AIRBORNE TECHNOLOGY LTD.

sound absorbing material from the speakers before flying the aircraft. To achieve the best operation, all voice commands must be spoken slowly and clearly, with extra emphasis on each word.

To determine the operational capability of the system, put the aircraft in a hover and with the target properly positioned, provide PA instruction to the target to accomplish a certain task that will give visual cue to the flight crew that the target has understood the instructions (i.e., "touch your head", "sit down", "turn around", etc.)

2.4.4.3 Power On Checks

Power up the aircraft's systems and confirm normal operation of all functions of the AA22. Refer to Section 3 (Operation) for specific operational details.

- a) Turn on all of the radios and other accessories required for this system. Check that the power ON LED on the AA22 illuminates when the power switch is up.
- b) Key the siren using the front panel button or remote siren key. The siren should sound and the level should be at maximum volume (the front panel level control does not affect the siren). If the siren (rate or tone) needs adjustment there are two trimpots on the left side of the AA22.
- c) Select the rest of the audio system as required to allow connection of the pilot's mic to the 'PA' and key the cyclic switch for transmit. The mic audio should be heard on the 'PA' speakers. Adjust the front panel level control for the desired volume.
- d) Check preset adjustments are completed before aircraft departure.
- **Notes:** 1. Note that PA audio has priority in the AA22 system and it will be heard even if the panel switch is selected to 'RADIO'. Check for correct radio operation and note what volume settings will produce a suitable external paging level..
 - 2. A faint audio signal may be heard at the speaker (even when the system is not paging) due to the very high gain of this system and stray coupling in the wiring. It should not be audible in flight.

Upon satisfactory completion of all performance checks, make all required log book entries, electrical load, weight and balance amendments and other documentation as required by your local regulatory agency before releasing the aircraft for service.

2.5 Adjustments and Connections

If any preset requires adjustment, be sure this is carried out before the aircraft leaves and that the unit and its mating connector are secured before departure.

If the siren does not suit the specific requirements of a given installation, the following adjustments are available:

- 1. Base tone setting potentiometer marked TONE.
- 2. Sweep rate setting potentiometer marked RATE.

These controls are accessible through holes on the left side of the unit as shown in Figure 1.

: inat

AA22 Series PA Driver/Siren Control SM33-2 Installation and Operation Manual



Figure 1: Tone and Rate Controls

2.6 Accessories Required But Not Supplied

Installation kit p/n AA20-IKC (crimp) is required to complete the installation.

AA20-IKC 25-pin D-min Female Crimp Kit (NAT Part No. D25SL-IKC) consists of

Quantity	Description	NAT Part No.
1	D-min 25 Socket Housing	20-21-025
25	MS Crimp Socket	20-26-901
1*	Jack Screw Set	20-27-002
1*	Lock Clip Set	20-27-004
1	50 Pin Connector Hood	20-29-026
* Use as required.		

2.7 Installation Drawings

Use of the "#" symbol in the REV. column indicates that the document is listed elsewhere in the manual. Refer to the applicable NAT Part No. to locate the referenced document.

DOCUMENT	REV.	DESCRIPTION	ТҮРЕ	SERIAL NO.
AA22-110				
AA22\110\403-0	1.02	PA Driver/Siren System	Interconnect	Up to 4019
AA22\110\403-0	1.10	PA Driver/Siren System	Interconnect	4020 and up
AA22\110\405-0	1.02	PA Driver/Siren System	Connector Map	All
AA22\110\905-0	1.02	PA Driver/Siren System	Faceplate	Up to 4126
AA22\110\905-0	1.10	PA Driver/Siren System	Faceplate	4127 and up
AA22\160\922-0	1.00	PA Driver/Siren System	Mechanical Installation	All
AA22-160				
AA22\160\403-0	1.01	PA Driver/Siren System	Interconnect	Up to 2900
AA22\160\403-0	1.10	PA Driver/Siren System	Interconnect	2901 and up
AA22\160\405-0	1.02	PA Driver/Siren System	Connector Map	All
AA22\160\905-0	1.02	PA Driver/Siren System	Faceplate	Up to 4126
AA22\160\905-0	1.10	PA Driver/Siren System	Faceplate	4127 and up
AA22\160\922-0	#	PA Driver/Siren System	Mechanical Installation	


;‡;nat

AA22 Series PA Driver/Siren Control SM33-2 Installation and Operation Manual

AA22-492

AA22\492\403-0	1.10	PA Driver/Siren System	Interconnect	All
AA22\492\403-1	1.10	PA Driver/Siren System	Interconnect	All
AA22\492\403-2	1.10	PA Driver/Siren System	Interconnect	All
AA22\492\405-0	1.11	PA Driver/Siren System	Connector Map	All
AA22\492\905-0	1.02	PA Driver/Siren System	Faceplate	Up to 4126
AA22\492\905-0	1.10	PA Driver/Siren System	Faceplate	4127 and up
AA22\492\922-0	1.00	PA Driver/Siren System	Mechanical Installation	All
AA22-493		-		
AA22\493\403-1	1.00	PA Driver/Siren System	Interconnect	All
AA22\493\403-2	1.00	PA Driver/Siren System	Interconnect	All
AA22\493\405-0	1.01	PA Driver/Siren System	Connector Map	All
AA22\493\905-0	1.00	PA Driver/Siren System	Faceplate	Up to 4126
AA22\493\905-0	1.10	PA Driver/Siren System	Faceplate	4127 and up
AA22\492\922-0	#	PA Driver/Siren System	Mechanical Installation	· -

Section 2 ends following the above documents



	REVISIONS		
REV	DESCRIPTION	DATE	ΒY
1.01	FORMAT CHANGES	APR 4/95	LH
1.02	NOTES 2 – 5 ADDED, FORMAT CHANGES,		
	DRAWING CORRECTIONS	AUG 14/98	MWS
1.10	REFER TO DOCCR02098 FOR DETAILS.	FEB 25/08	MWS

NOTES:

1.

2.

/3.

<u>/4.</u>

 \int_{5}

ALL WIRES SHOULD BE 22 AWG UNLESS OTHERWISE SPECIFIED. ALL UNSHIELDED WIRE SHALL BE SELECTED IN ACCORDANCE WITH AC43.13-1B CHANGE 1, PARAGRAPHS 11-76 THROUGH 11-78. WIRE TYPES SHOULD BE TO MIL-W-22759 AS SPECIFIED IN AC43.13-1B CHANGE 1, PARAGRAPHS 11-85, 11-86 AND LISTED IN TABLE 11-11. ALL SHIELDED WIRE/CABLE SHOULD BE IN ACCORDANCE WITH MIL-C-27500.

- GROUNDING PIN 10 WILL TRIGGER SIREN.
 - PARALLEL RADIO INPUT (IF USED) WITH PILOT H/S.
 - UP TO 5W PA INPUT FROM EXISTING SYSTEM.
 - PIN 25 MUST BE GROUNDED AT AUDIO CONTROLLER OR OTHER SINGLE POINT.


DEFINITIONS:

RESERVED: MAY BE CONNECTED AND USED IN THE FUTURE. THE CIRCUITRY MAY BE PRESENT OR ADDED TO ACTIVATE THE FUNCTION. THE PIN MAY BE USED FOR TEST PURPOSES. THERE IS NO EXTERNAL CONNECTION.

CONFIDENTIAL AND PROPRIETARY TO NAT LTD.

DESIGNED		ΚV		nor	THEDN	AIDBO	DDNF	TECHN	NIACV	מידו
DRAWN		ΚV		ARBORNE TECHNOLOGY LTD.						
DATE	JŲ	IL <u>26/9</u> 0	TITLE	ſ				SYSTEM		
CHECKED		NAT 255		PA DRIVER/SIREN SYSTEM						
APPROVED		NAT 114	size A	CAGE CODE 3AB01	PART		22-11	0	REV. 1.10	SHEET 1/2
FILE	40	3-0.DWG	DWG.	DWG. TYPE INTERCONNECT DWG. NO. AA22\110\403-C				403–0		

	REVISIONS		
REV	DESCRIPTION	DATE	BY
1.01	FORMAT CHANGES	FEB 14/96	MWS
1.02	NOTES REMOVED, FORMAT CHANGES,		
	DRAWING CORRECTIONS.	AUG 14/98	MWS



P101

MATING CONNECTOR




PROPRIETARY AND CONFIDENTIAL TO NAT LTD.

DESIGNED	KV		nat	NORTH	IFRN	AIRBO	INNE	TECH	NOLOGY	ITD
DRAWN	MWS			NONTI		AINDO	JIVINE	I BUIL	NOTOGI	LID.
DATE	NOV 29/90	TITLE			P۵		R /SIR	FN		
UNEUKED	NAT (NAT) 214 106)	PA DRIVER/SIREN SYSTEM							
	NAT	SIZE	CAGE (CODE	PART	NO.			REV.	SHEET
APPROVED	107	A	A 3AB01			AA22-110				1/1
FILE 405-	-0102.DWG	DWG.	TYPE	CONN	ECTOR	MAP	DWG. N	IO. AA:	22\110\40	5-0

REVISIONS	
REV DESCRIPTION	DATE BY
1.01 FORMAT CHANGES	FEB 26/96 TGM
	AUG 5/98 MWS
	AUG 5/98 MWS
PROPRIETARY AND CONFIDENTIAL T DESIGNED KV DRAWN KV DATE JAN 25/90 TITLE PA DRIVER CHECKED NAT CHECKED NAT APPROVED NAT 107 SIZE CAGE CODE PART NO. APPROVED NAT 107 A GRI CAGE CODE PART NO. ABD1 AA22 FILE 905-0102.DWG DWG. TYPE FACEPLATE DI	RNE TECHNOLOGY LTD. /SIREN M REV. SHEET


	REVISIONS		
REV	DESCRIPTION	DATE	ΒY
1.01	FORMAT CHANGES.	FEB 26/06	TGM
1.02	ADDED SHEET 2, FORMAT CHANGES.	AUG 5/98	MWS
1.10	ECR #1079 – REMOVED "-110".		
	DOCCR01656 – FORMAT CHANGES.	APR 15/08	MWS





CONFIDENTIAL	AND	PROPRIETARY	то	NAT	LTD.	

DESIGNED	κv		nat North	IFRN AIRRO	ORNE	TECHNO	IOCY	ITD			
DRAWN	κv			ILINI AIND	JIVINE	I BOIINO	LOGI	LID.			
DATE	JAN 25/90	TITLE	TLE PA DRIVER/SIREN SYSTEM								
CHECKED	NAT 255		FRONT VIEW								
APPROVED	(NAT 131)	size A	cage code 3AB01	PART NO.	22—110)	REV. 1.10	SHEET $1/3$			
FILE	905-0.DWG	DWG. T	YPE	FACEPLATE	DWG. NO	D. AA2	22\110\	905-0			

ENG-FORM: \905's\AA22-xxx.905-0110.DWT







	REVISIONS		
REV	DESCRIPTION	DATE	BY
1.01	FORMAT CHANGES.	FEB 14/96	MWS
1.02	ECR #1475 - NOTES MOVED TO INTERCONNECT DWG,		
	FORMAT CHANGES.	MAY 9/00	TAT



25 PIN FEMALE D-MIN MATING CONNECTOR

+28 >DC POWER	+28 VDC PCWER		+28 VDC LIGHTS	SW-TCH POWER OUT			AUD-O H-			SW-FCH POWER OUT		~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	シードヨト トロイ		RAD-0 RX	FA		M - C			
	2 C C C C	0 15	3 0 10		0 0 17	5 0 18		2 2 9	7 0 20		0 21	9) 2		23	11 0 2		2		$\Big)$		41 _O
	POWER GROUZD	POWER GROUND			SHIELD	GROUND			GROUND		GROUND			R A D I O R X	F /	>	M C				

VIEW IS FROM REAR OF AIRFRAME CONNECTOR


PROPRIETARY AND CONFIDENTIAL TO NAT LTD.

DESIGNED	KV		nat North	IFRN AIRRO	ABNE T	FCHNO	IOCV	מידו		
DRAWN	MWS			IEIM AIND		Echno	LOG1	LID.		
DATE	NO <u>V 29/9</u> 0	TITLE		PA/S	IREN					
CHECKED	NAT 223		PA/SIREN SYSTEM							
	(NAT)	SIZE	CAGE CODE	PART NO.			REV.	SHEET		
APPROVED	107	A	3AB01	AA2	AA22-160					
FILE 405-	-0102.DWG	DWG.	TYPE CONN	ECTOR MAP	DWG. NO.	AA22	160\40	5-0		

Confidential and Proprietary to NAT

DESIGNED	KV		nat North	IFRN	AIPBO) PNF	TECHN	OLOCY	מידו	
DRAWN	KV				AIND	JIMIL	IECHN	OFOGI	LID.	
DATE	JUL 25/90	TITLE					EN			
CHECKED	NAT PROD 133	-	PA DRIVER/SIREN SYSTEM							
APPROVED	(NAT 107)	size A	cage code 3AB01	PART		2–16	0	REV. 1.02	SHEET 1/2	
FILE 905-	-0102.DWG	DWG.	TYPE FA	CEPLAT	E	DWG. N	IO. AA22	\160\90	5-0	

	REVISIONS										
REV	DESCRIPTION	DATE	ΒY								
1.01	FORMAT CHANGES.	APR 4/95	LH								
1.02	ECR #873, KNOB TYPE, ENGRAVED TEXT CHANGED.	JUL 4/97	MWS								
1.10	ECR #1079 – REMOVED "-160".										
	DOCCR01656 – FORMAT CHANGES.	APR 15/08	MWS								



CONFIDENTIAL	AND	PROPRIETARY	ТО	NAT	LTD.	
--------------	-----	-------------	----	-----	------	--

DESIGNED	K١	V	**** *	SAL NORT	HEBN AIR	BORNE	TECHNO	IOCY	ITD			
DRAWN	K١	V		CARTERN AIRBORNE TECHNOLOGY LTD.								
DATE	JUL 2	<u>5/9</u> 0	TITLE	LE PA DRIVER/SIREN SYSTEM								
CHECKED	NA 25			FRONT VIEW								
APPROVED	(NA 13		size A	cage code 3AB01	PART NO.	\22—16	0	REV. 1.10	SHEET 1/3			
FILE 905-0.DWG DWG. TYPE F.				FACEPLAT	E DWG. 1	NO. AA2	22\160\	905–0				

ENG-FORM: \905's\AA22-xxx.905-0110.DWT

REVISIONS									
REV	DESCRIPTION	DATE	ΒY						
1.01	ECR #1481 – CHANGED NOTES 1, 3 & 7; ADDED NOTES 8 & 9; FORMAT CHANGES.	SEP 26/00	ТАТ						
1.10	DOCCR01476 — CHANGED TO SHOW OPTIONAL LO POWER PA CONNECTIONS. UPDATED TEMPLATE.	JUN 5/06	ТАТ						

AA22-492 INSTALLATION NOTES

NOTES:

- ALL WIRES SHOULD BE 22 AWG UNLESS OTHERWISE SPECIFIED. ALL UNSHIELDED WIRE SHALL BE SELECTED IN ACCORDANCE WITH AC43.13-1B CHANGE 1, PARAGRAPHS 11-76 THROUGH 11-78. WIRE TYPES SHOULD BE TO MIL-W-22759 AS SPECIFIED IN AC43.13-1B CHANGE 1, PARAGRAPHS 11-85, 11-86 AND LISTED IN TABLE 11-11. ALL SHIELDED WIRE/CABLE SHOULD BE IN ACCORDANCE WITH MIL-C-27500.
- OPTIONAL. PARALLEL TO HEADPHONE (1 ONLY) CONNECTION FOR MONITORING RADIOS VIA EXTERNAL P.A. SPEAKER.

3 OR CARBON-EQUIVALENT/AMPLIFIED DYNAMIC MICROPHONE.

- /4 MIC INPUT LO (PIN 25) MUST GO TO EXTERNAL
- GROUND TO EXCITE MICROPHONE, IF NOT PROVIDED BY AUDIO SYSTEM.
- 5 FOR CYCLIC-SWITCH KEYING, WIRE AS SHOWN. FOR FRONT-PANEL AUTO-KEYING, GROUND PIN 10.
- 6 Shield to reduce interference with other systems.

/7 ISOLATED TRANSFORMER OUTPUT. 'AUDIO OUT LO' MUST BE TERMINATED AT P1 'C'.

- 8 SWITCH POWER OUT (PIN 8) RATED 400mA @ 28VDC.
- $\cancel{9}$ K1 RELAY NAT P/N 65-80-200 OR EQUIVALENT.
- FLT1 RF FILTER ŃAT P/N 22-00-003A OR EQUIVALENT.
- 10 UP TO 5W PA INPUT FROM EXISTING SYSTEM.

DEFINITIONS:


- N/C: NO CONNECTION. THE PIN IS <u>NOT</u> CONNECTED TO ANYTHING INTERNALLY, AND THEREFORE SHALL HAVE NO CONNECTION EXTERNALLY.
- N/C SPARE: NO CONNECTION INTERNALLY, BUT A SPARE WIRE SHALL BE INSTALLED IN THE WIRE HARNESS.


RESERVED: MAY BE CONNECTED AND USED IN THE FUTURE. THE CIRCUITRY MAY BE PRESENT OR ADDED TO ACTIVATE THE FUNCTION. THE PIN MAY BE USED FOR TEST PURPOSES. THERE IS NO EXTERNAL CONNECTION.


RESERVED SPARE: RESERVED, BUT INSTRUCTIONS SHALL BE FOLLOWED TO ACTIVATE (RSV SP) THE CIRCUITRY. A SPARE WIRE <u>SHALL</u> BE INSTALLED IN THE WIRE HARNESS.

	CONFIDENTIAL AND PROPRIETART TO NAT LTD.									
DESIGNED	RL	• • مقربه	ART NORT	HERN AIRB		HNC	NOCY	ITD		
DRAWN	TAT			IIERN AIND	JUNE IEU	line	LOG I	LID.		
DATE	M <u>AY 26/</u> 06									
CHECKED	NAT 255		SYSTEM							
	(NAT)	SIZE	CAGE CODE	PART NO.			REV.	SHEET		
APPROVED	(131)	А	3AB01	AA2	2-492		1.10	1/3		
FILE 403-0.DWG DWG. TYPE INTERCONNECT DWG. NO. AA22\492\403-						403–0				

CONFIDENTIAL AND PROPRIETARY TO NAT LTD.








- 5 UP TO 5W PAGE INPUT.
- 6 MIC INPUT TYP. 250mV FOR FULL OUTPUT. BIASED.
- MUST GO TO EXTERNAL GROUND TO EXCITE MIC.
- 8 ISOLATED TRANSFORMER OUTPUT. MUST PROVIDE GROUND AT P.A. END.


DESIGNED	_	*	nat NORTH	IFRN AIRRO	DNF TF	CHNC	MOCV	מידד
DRAWN	KEH	*****					LOG I	LID.
DATE JAN 10/89 TITLE PA/SIREN SYSTEM								
CHECKED	201							
	(NAT)	SIZE	CAGE CODE	PART NO.			REV.	SHEET
APPROVED	107	A	3AB01	AA2	2-492		1.11	1/1
FILE 405-	-0111.DWG	DWG.	TYPE CONN	ECTOR MAP	DWG. NO.	AA22	492\40	5-0


					REVISION	NS			
	REV			DESCRIPTION			DATE		ΒY
	1.01	FORMAT	CHAN	GES.			APR 5	/95	LH
	1.02	UPDATE		URRENT NAT F	ORMAT.		NOV 16	/98	TAT
								<u>\</u>	
(()) VOL PA		(ج) SI	REN 🕀		Γ ^{ON} ٦))	
				\sim	-			1	
AA22-492 🖁 🤇))) (}	W	AIL (C YELP	$\langle \cdot \rangle$	$(A) \otimes $	k nat	2	
	C			\bigcirc	C				
(010		()FF		POWER))	
		PROP	RIFTA	RY AND CO		ITIAL TO NA			
DESIGN	-D	-							
DRAWN		_	×.	nat Norti	HERN .	AIRBORNE T	ECHNO	LOGY	LTD.
DRAWN	1 4								
		<u>N 2</u> 5/91			F	PA/SIREN			
		14 105	<u>, U</u>			SÝSTEM			
				0.4.05			I .		011555
APPROV	/ed [NAT)	SIZE	CAGE CODE	PART N				SHEET
		107	A	3AB01		AA22-492		1.02	1/1
FILE S	905-01	02.DWG	DWG.	TYPE FA	ACEPLATE	DWG. NO.	AA22\4	192\90	5-0


SEV DESCRIPTION Date BY 1.02 UPDATE TO CURRENT NAT FORMAT NOV 16/98 TAT 1.02 UPDATE TO CURRENT NAT FORMAT NOV 16/98 TAT 1.00 DECCR0356 - ADDD SHEETS 2 & 3, FORMAT DHO'S APR 15/08 WWS Image: Street in the street in			REVISIONS		
CONFIDENTIAL AND PROPRIETARY TO NAT LTD. CONFIDENTIAL AND PROPRIETARY T		REV		DATE	BY
Ind Confidential Confidential and Proprietary to Nat Ltd. Decorport O PA Siren Siren O O Are 15/08 MWS Work Vol. PA Siren Siren O O Are 15/08 MWS Work Vol. PA Siren Siren O O Are 15/08 MWS Work Vol. PA Siren Siren O O Are 15/08 MWS Work Vol. PA Siren Siren O O Are 15/08 MWS Work Vol. PA Siren Siren O O Are 15/08 MWS Work O 10 Rabio OFF POWER Are 15/08 Are 15/08 Disconsol OFF POWER O O F POWER T Disconsol OFF POWER T T T T T T Disconsol T T T T T T T T T T <td></td> <td></td> <td></td> <td></td> <td></td>					
1.10 ICCR #1079 - REMOVED "-492", DOCCR02523 - ADDED ANNUNCIATOR HOLE. APR 15/08 MWS Image: Street in the street in					
CONFIDENTIAL AND PROPRIETARY TO NAT LTD.					
Image: Solution of the state of the sta			DOCCR01656 - ADD'D SHEETS 2 & 3, FORMAT CHG'S	6. APR 15/08	MWS
DESIGNED – DRAWN – PA DRIVER/SIREN SYSTEM CHECKED NAT 255 TITLE PA DRIVER/SIREN SYSTEM FRONT VIEW APPROVED NAT SIZE CAGE CODE PART NO. REV. SHEET		P		AA22	
DESIGNED – DRAWN – DATE JAN 25/91 CHECKED NAT 255 APPROVED (NAT) SIZE CAGE CODE PART NO. APPROVED (NAT) SIZE CAGE CODE PART NO. REV. SHEET					
DESIGNED – DRAWN – DATE JAN 25/91 CHECKED NAT 255 APPROVED (NAT) SIZE CAGE CODE PART NO. APPROVED (NAT) SIZE CAGE CODE PART NO. REV. SHEET					
DESIGNED – DRAWN – DATE JAN 25/91 CHECKED NAT 255 APPROVED (NAT) SIZE CAGE CODE PART NO. APPROVED (NAT) SIZE CAGE CODE PART NO. REV. SHEET			CONFIDENTIAL AND DOODDIETADY TO M		
DRAWN – DATE JAN 25/91 TITLE PA DRIVER/SIREN SYSTEM CHECKED NAT 255 FRONT VIEW APPROVED (NAT) SIZE CAGE CODE PART NO. REV. SHEET			CONFIDENTIAL AND PROPRIETARY TO NA	AT LID.	
DATE JAN 25/91 TITLE PA DRIVER/SIREN SYSTEM CHECKED NAT 255 FRONT VIEW APPROVED NAT SIZE CAGE CODE PART NO. REV. SHEET		ED	- MORTHFRN AIRROPNE "	FECHNOLOGY	LTD
CHECKED NAT 255 FRONT VIEW	DRAWN			L DOILIOUNDUG I	<u>пт</u> р,
CHECKED NAT 255 FRONT VIEW		AI,	N 25/91 TITLE		
APPROVED NAT SIZE CAGE CODE PART NO. REV. SHEET			NAT FRONT VIEW	YSTEM	
	APPROV	/ED (\sim		SHEET 1/3
FILE 905-0.DWG DWG. TYPE FACEPLATE DWG. NO. AA22\492\905-0		905	-O.DWG DWG. TYPE FACEPLATE DWG. NO	AA22\492\	905-0


ENG-FORM: \905's\AA22-xxx.905-0110.DWT











Confidential and Proprietary to NAT

DESIGNED	κv			IFPN AIPPO	DANE TE	CHNO	JOCY	ITD		
DRAWN	TGM		nat Northern Airborne technology LTD							
DATE	MAR 25/97	TITLE	TLE PA/SIREN SYSTEM							
CHECKED	NAT PRO	þ.		I A/ SINEN	SISILIV					
CHLORED	105									
	NAT	SIZE	CAGE CODE	PART NO.			REV.	SHEET		
APPROVED	(107)	A	3AB01	AA2	2-493		1.00	1/2		
FILE 905-	905-0100.DWG DWG. TYPE FACEPLATE DWG. NO. AA22\493\905-C					5-0				

				REVISIONS		
	REV		DESCRIPTION		DATE	BY
	1.10	ECR #1079 -	REMOVED "-49	93".		
		DOCCR01656	- FORMAT CHA	NGES.	APR 15/08	MWS
VOL		Sire				
	(\mathcal{C})	WAIL (@		$\mathbb{C}(\mathbb{A}) \otimes$	AA22	
0 10		OF	F	POWER		
		01		- OWER		
		CONFIDENT	TAL AND P	ROPRIETARY TO	NAT LTD.	
	DESIGNED	KV	nat NORT	HERN AIRBORN	E TECHNOLOG	Y LTD
	DRAWN					
	CHECKED	NAT 255	P	A DRIVER/SIREN FRONT VIE		
	APPROVED 7	235 NAT SIZE 131 A	CAGE CODE 3AB01	PART NO.	493 REV.	SHEET) 1/3
		-0.DWG DWG.		FACEPLATE DWG		
ENG-EORM: \905's\AA22-xxx 905-0110 DWT	1					1

ENG-FORM: \905's\AA22-xxx.905-0110.DWT

;;;nat

AA22 Series PA Driver/Siren Control SM33-2 Installation and Operation Manual

Section 3 Operation

3.1 Introduction

Information in this section consists of functional and operational procedures for the AA22 Series PA Driver/Siren Control.


3.2 General Information

The AA22 PA Driver/Siren Control provides a central adjustment for external aircraft loudhailer functions. The AA22 is only a line driver and must have at least one external amplifier in the system. When turned on, the system is ready for operation and will accept audio feeds or a microphone input. An internally generated siren is also available and adjustable through the side of the controller. When the AA22 is turned on, a 'POWER KEY' signal is generated. This signal is used to turn on the 'PA' amp. The high current DC to operate the PA110/220 is supplied by the aircraft.

3.3 Controls and Indicators

3.3.1 Power Up

To activate the AA22 PA Driver/Siren Control, flip the POWER toggle switch up, to the ON position. The LED adjacent to the switch should illuminate.



3.3.2 Mode Switch

The Mode switch is a two-position toggle switch used to select between PA and Radio operation.

3.3.2.1 PA Operation

For external loudhailer systems, set the Mode switch on the AA22 to PA. Key the microphone through the cyclic switch or hand mic switch, and speak in a firm, clear manner. For best results, over-emphasize each word.

Section 3 Rev: 1.00 ENG-FORM: 806-0111.DOT

3.3.2.2 Radio Operation

To set the system for radio rebroadcast functions, set the Mode switch on the AA22 to RADIO. All audio delivered from the source (typically pilot's or copilot's headset) will be broadcast through the PA system, if provision for this is made at the time of installation.

3.3.3 Volume Control

The VOL control pot on the front of AA22 sets the volume level. For external loudhailer and rebroadcast operations, the volume should always be set between half and full level.

3.3.4 Siren Button

3.3.4.1 AA22-110

The siren is activated by depressing the momentary push-button SIREN control on the front of the AA22, or by using a remote keying switch. The siren will sound only as long as the button is depressed. Level setting is automatic and need not be adjusted.

3.3.4.2 AA22-160, AA22-492 and AA22-493

On these models, the front-panel SIREN button is replaced by a WAIL/OFF/YELP switch. This allows the operator to disable the siren, or select the required siren mode from the front panel of the AA22.

3.3.5 Remote Power Switch

Remote power switching for the power amplifiers is provided as a switched +28 Vdc output from the AA22.

Section 3 ends