# Service Information User's Guide



# CONTENTS

Introduction
Starting & Using SI
Finding Documents
Navigating & Printing
Viewing Documents
Other Options

©2004 GM Service and Parts Operations

# Service Information User's Guide

The Service Information (SI) User's Guide provides a comprehensive overview of SI software.

Everything contained in this manual is based on the latest product information available at the time of publication. The right is reserved to make changes at any time without notice.

No part of this publication may be reproduced, stored in any retrieval system, or transmitted in any form by any means, including but not limited to electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of GM Service and Parts Operations. This includes all text, tables, illustrations, and charts.

Requests for permission should be sent to:

**General Motors Corporation** Service and Parts Operations **Product Engineering** 37350 Ecorse Road Romulus, MI 48174-1376 U.S.A.

© 2003 GM Service and Parts Operations. Printed in the U.S.A. All rights reserved.

Microsoft Windows screen captures are used for instructional purposes.



# **Customer Support Overview**

To obtain assistance with a question or problem concerning the operation of your SI software, telephone the GM-Techline Customer Support Center.

### **Before Calling**

Before making a call to the Customer Support Center, be sure to have the following information ready:

- Dealership name, address and dealer code number
- Telephone number where the technician may be reached
- Tell when the problem occurred, and whether CD or Web usage
- List any error messages
- Give vehicle entry information

# Making the Call

The GM Service and Parts Operations **Techline Customer Support Center** telephone lines operate from 8:00 a.m. to 8:00 p.m. (Eastern Standard Time) Monday to Friday.

In the **United States** and **Canada** to contact Customer Support, dial:

• English: 1-800-828-6860 (option 1)

• French: 1-800-503-3222

• Customer Support fax line: 248-265-9327

For International Customer Support, fax all questions or comments to the customer support fax line.

A GM-Techline Customer Support representative will answer questions and make suggestions; and also will record each problem, question, or suggestion into a special problem tracking system. Any problems that cannot be resolved over the phone will be directed to the appropriate group for resolution.

# **Software License Agreement**

Please read this license agreement carefully before proceeding to operate the software. Rights to the software are offered only on the condition that the customer agrees to all terms and conditions of the license agreement. Proceeding to operate the equipment indicates your acceptance of these terms and conditions:

- 1. USE: Customer may use the software only on the computer system on which it was originally installed. Customer may not reverse assemble or decompile software unless authorized by law.
- 2. OWNERSHIP: Customer agrees that it does not have any title or ownership of the software, other than ownership of the physical media. Customer acknowledges and agrees that the software is copyrighted and protected under the copyright laws. Customer acknowledges and agrees that the software may have been developed by a third party software supplier named in the copyright notices included with the software, who shall be authorized to hold the Customer responsible for any copyright infringement or violation of this agreement.
- 3. TERMINATION: General Motors may terminate this software license for failure to comply with any of these terms provided GM has requested Customer to cure the failure and Customer has failed to do so within thirty (30) days of such notice.

# **Using This Manual**

To increase effectiveness with the Service Information (SI) software, users should familiarize themselves with the format and information contained in this guide.

### **IMPORTANT**

SI figures and illustrations are hyperlinked to the text of this manual. To view a figure, simply click on its description, which is shown in blue text. After viewing the figure, click on the rainbow-colored arrow at the lower left-hand corner of the screen to return to your place in the manual.

# **SI Overview**

SI is the software delivery tool for General Motors service information. SI contains General Motors service information including service manuals, owner's manuals, bulletins, and campaigns.

SI is available on the Internet and on CDs. SI is formatted in hypertext markup language (HTML), which can be viewed on any computer with an Internet browser, such as Microsoft® Internet Explorer.

# **Finding Information on SI**

Search for information in the following ways:

- Vehicle year, make, and model
- VIN number
- Keyword search
- Document number

You can find details about searching for service information beginning on page 5.

# **Printing from SI**

Connect to a printer. Print from the File menu, the Printer icon on the toolbar, or the Print button on the selected document.

# **Apache Server Application**

Apache is a powerful UNIX-based hypertext transfer protocol (http) server application that organizes the complex functions of **SI**. Apache must be running in order for **SI** to operate.

The Apache server application installs from the SI installation CD-ROM automatically. If you have Windows 2000 or XP, Apache runs transparently in the background.

After SI has been installed, Apache will start automatically every time the terminal is booted.

### Do not close Apache.

**Note**: If the Apache application is accidentally closed, the terminal must be rebooted in order to restart Apache and run SI.

# Starting SI

You can access **SI** in three basic ways: on the Internet, by installing CDs, or by GM ACCESS (Canada).

### Web Access

- Open your Internet browser and enter http://service.gm.com in the address bar. At the GM Service and Parts Operations home page, click the **Service Information** tab (Figure 1).
- Click the underlined text **Service Information** at the next screen (Figure 2).
- Enter your user identification and password at the *Enter Network Password* screen (Figure 3) to open the Service Information home page (Figure 4).

# **Compact Disks**

- Install the SI application and data on your computer using the latest CDs and installation instructions.
- Double-click the "eSI" icon on the Desktop (Figure 5) to open the Service Information home page.

### **GM Access**





• Double-click the "eSI" Service Information icon to open the Service Information home page.



Figure 1 **GM Service and Parts Operations home page** 



Figure 4 Service Information system home page



Figure 2 Service Information selected



Figure 5 Service Information icon on Desktop screen



Figure 3 Enter Network Password screen

# SI's Home Page

The Service Information home page is shown in Figure 4. Wherever your search leads you within the SI system, you can return to the home page by clicking the Home icon.

When you need information for a specific vehicle, use the upper half of the SI home page to initiate a search for GM service publications on the vehicle. A full description of this method begins on page 6.

Use the **lower half** of the **SI home page** to select **other options**:



Unit repair manuals are published for specific engines, transmissions, and other components. Select the **Unit Repair** Manual icon to see a list of available manuals. See page 11 for details.



If you have the ID number for a specific bulletin or campaign that you want to view, select the **Number Search** icon to enter the number and see the document. See page 12 for details.



The Latest News icon allows you to review the latest released documents. Select the time period you wish to review, from two to eight weeks. See page 12 for details.



Select the YPK icon and enter your desired Year range + Platform + **Keyword** to find bulletins. campaigns, and preliminary information. See page 13 for details.



Operating instructions and other helpful hints are located under the Question Mark or Help icon. See page 14 for details.

These links are also shown as bracketed text at the bottom of the screen, and are available for selection on most pages within the SI system. Clicking one of these icons or text links will open the start page for the particular function, no matter where you are within the system.

Language Note: SI's default language is English. You can select a different language from the drop-down menu at the **upper right** of the **SI home page** (Figure 4). If you are using CDs, you must first install the data CDs for the desired language before this option is available.

# **Accessing GM Service Publications for Specific Vehicles**

Follow the steps below and on the continuing pages to access service manuals, bulletins, and other publications available for a specific GM vehicle.

- 1. At the **SI** home page (Figure 4), you can initiate a vehicle specific search in two ways (Figure 6):
  - Select the vehicle year, make, and model from the respective drop-down menus and click **Next**, or
  - Click the line of bracketed text near the top of the screen to open the vehicle identification number (VIN) entry screen (Figure 7), enter the VIN, and then click **Submit**.
- 2. At the publication selection screen for the specified vehicle (Figure 8) you can select available options for the various types of publications, listed below.
  - Service Manual/Bulletins, which contain information on all optional and standard equipment for the specified vehicle (see Figure 9 and pages 7 to 10 for examples)
  - Unit Repair (see page 15)
  - Owner's Manual (see page 15)
  - Owner's Manual Supplement (see page 16)
  - Owner's Warranty Books (see page 16)

Subsequently in your search, you can return to the vehicle's publication selection screen (Figure 8) by clicking on the Publications icon, shown here.



3. After selecting a specific vehicle publication, a search screen similar to the one shown in Figure 9 gives you the option of entering keywords or selecting a category (see pages 7 and 8).



Figure 6 Enter VIN or "build" the vehicle



Figure 8 Publication selection screen for specified vehicle



Figure 7 VIN entry screen



Figure 9 SI search screen

### **Searching for Service Information Using Keywords**

1. At the search screen (Figure 9), type a word or phrase in the search field. Enter three words or fewer to optimize system performance.

**Note**: If you want to see a list of valid words and phrases, click on one of the lists named below the search field (e.g. Keyword, Symptom, or DTC), then click **Back** or **Previous Page** to return to the search screen.

- 2. Click **Search** (or press the Enter key), and every document with a title that contains the requested keyword(s) will appear. In the example shown in Figure 10, the user typed "engine electrical" in the search field, and then clicked the search button. The program automatically adjusted the search term to "electrical engine" to facilitate the database search. Figure 11 shows the resulting document list.
- 3. Click on the **title** of the document you wish to view.





# **Searching for Service Information by Category**

Using this method, you make on-screen selections, "drilling down" from a general category to a more specific subcategory and eventually to the precise information for which you are searching. (As you click your way toward the final document, the path you chose is displayed near the top of the screen.)

- 1. At the search screen (Figure 9), select one of the categories listed at the left. In the Figure 12 example, the user selected "Steering" from the available categories.
- 2. At the next search screen(s), select from among the subcategories listed for your chosen category. In the example, the user selected "Steering Wheel and Column" (Figure 13) and subsequently "Diagnostic Information and Procedures" (Figure 14) from the available options.

**Note**: After you select the primary category (e.g. Steering), the keyword search function offers you the option of searching the "Entire manual" or "This section only" (see Figure 13).

3. When you reach a document selection screen, click on the title of the document you wish to view. In the example shown in Figure 15, the user has selected the document "Lock System Does Not Lock," which is a troubleshooting table (Figure 16).



Figure 12

Steering selected from the category list on the first search screen (for service manual and bulletins)



Figure 13

Steering Wheel and Column selected from the category list on the next screen



Figure 14

Diagnostic Information and Procedures selected from the category list on the next screen



Figure 15

Lock System Does Not Lock selected from the document selection screen



Figure 16

Lock System Does Not Lock document displayed

# **Navigating and Printing Service Information Documents**

The Document ID number appears at the top of your selected document. Use the Print button at the upper right to print the page, if desired. Use the Back and Forward buttons to return to the previous page or to advance to the next page (Figure 17).

Links are shown in blue text. The cursor changes to a hand when over a link. Click the link to open it. Links change color after they have been opened (Figure 16).

Scroll through the document using the scroll bar to the right of the document page. You can also use the Page Up and Page Down keys, or the arrow keys on your keyboard.



Figure 17 Document ID number, Back, Forward, and Print buttons indicated

# **Viewing Service Information Documents**

Many documents contain images for which special viewing functions are available. For example, selecting Repair Instructions on the 2004 Cadillac SRX Steering Wheel and Column screen (Figure 18), and then selecting Ignition Switch Replacement on the resulting document selection screen (Figure 19) opens an illustrated repair instructions document (Figure 20).

Clicking the magnifying glass icon below each illustration opens an image viewing screen (Figure 21) with a special set of tools for viewing the image in more detail.



The image viewing toolbar icons are described in Figure 22.

**Note**: One of the tools, the mobile magnifier, is especially useful for viewing schematic drawings like the example shown in Figure 23.



Figure 18

Repair Instructions selected from category list for the 2004 Cadillac SRX steering wheel and column



Figure 19

Ignition Switch Replacement document selected



Figure 20

Illustrated repair instructions



Figure 21

Image viewing screen showing toolbar



Figure 22

Description of SI image viewing toolbar icons



Figure 23

Sample schematic drawing showing the mobile magnifier tool function

# **Other Options**

Other search options are available if you are not looking for service information for a specific vehicle. These options are described on page 5 as a group, and individually beginning below.

# Finding Information in Unit Repair Manuals

Click the Unit Repair icon, which occurs on the SI home page (Figure 4).



- 2. At the Unit Repair Manual selection screen (Figure 24), click the desired manual.
- 3. Click the desired category from those listed on the next screen (Figure 25), or search the whole unit repair manual by keyword (optional).
- 4. Click a subcategory from those listed on subsequent screens (Figure 26), narrowing your search to the final subcategory (Figure 27) to select and view the document you seek (Figure 28, Figure 29).



Figure 24
Unit Repair Manual selection screen



Figure 25
2004 Unit Repair category selection screen



Figure 26 Unit repair subcategory selection screen



Figure 27
Unit repair final category selection screen



Figure 28
Unit repair document selection screen



Figure 29 Unit repair document

# Finding Information by a Number Search

1. Click the Number Search icon, which occurs on the **SI** home page and at the top of many other search screens throughout the system.



- 2. At the document number entry screen (Figure 30), enter the ID number of the document you seek.
  - **Note**: You can omit dashes between numbers. You can also omit letters, or enter them in upper or lower case. For example, 980-08B can be written 98008b or 98008.
- 3. Click Search for Matching Document to open the corresponding document (Figure 31).



Figure 30

Document number entry screen



Figure 31
Document with corresponding number displayed

# **Finding the Newest Publications**

1. Click the Latest News icon, which occurs on the **SI** home page and at the top of many other search screens throughout the system.



- 2. Click to view the document of your choice.
  - **Note**: The screen shows bulletins, campaigns, and preliminary information released during the past four weeks. Narrow your search by selecting a two-week period from the drop-down menu, as shown in Figure 32, or select a longer time period (six or eight weeks) to broaden your search. In the example, the user selected one of the bulletins (Figure 33), which subsequently appears on the screen (Figure 34).



Figure 32
Documents released during past four weeks



Figure 34
Selected document displayed



Figure 33
Search narrowed to most recent documents

# Finding Information by a Year Range + Platform + Keyword Search

1. Click the Y+P+K icon, which occurs on the **SI** home page and at the top of many other search screens throughout the system.



- 2. At the Y+P+K entry screen (Figure 35):
  - Select a beginning model year
  - Select an ending model year
  - Select a vehicle platform
  - Enter a keyword or keywords\*
  - Click Submit
- 3. Select from among the resulting document list for your criteria (Figure 36) to view the document of your choice (Figure 37).








Figure 36
Documents hit list resulting from Y+P+K search

<sup>\*</sup>You may enter one, two, or three words in the Keyword field. If you enter the keywords "fuel" and "pump," the search engine will look for "fuel pump." Select a button to match **All** or **Any** of the entered words.

# **Finding Assistance**

1. Click the Help icon, which occurs on the SI home page and at the top of many other search screens throughout the system.



2. Select from the SI Help topics listed (Figure 38) to view your selection (Figure 39).



Figure 38 Service Information Help topics



Figure 39 "Contacting Us for Assistance" displayed

### **Unit Repair Selection**

This selection provides unit repair information. Complete specifications, component locator, repair instructions, and special tools and equipment for the specified vehicle are all covered under this selection.

- 1. Click the Unit Repair option, which appears on a vehicle's publication selection screen (Figure 8).
- 2. Click on the desired unit repair title from the resulting category list.
- 3. Repeat the previous step as your search narrows (Figure 40).
- 4. Select a document to view from the document list offered.



Figure 40
Example of a unit repair selection screen

### **Owner's Manual Selection**

This selection provides specific owner's manual information for the vehicle requested. Complete owner's manual coverage is provided for seats and restraint systems, instrument panels, vehicle features and controls, service and care, maintenance schedules, and customer assistance information.

- 1. Click the Owner's Manual option, which appears on the publication selection screen if the owner's manual is available for the vehicle requested (Figure 8).
- 2. Click on the desired owner's manual title from the resulting category list.
- 3. Repeat the previous step as your search narrows.
- Select a document to view from the document list offered.

# **Owner's Manual Supplement Selection**

This selection provides supplemental owner's manual information for the vehicle requested—for example, how to operate a vehicle's air conditioning, cellular phone, radio, navigation, voice recognition system, etc.


- 1. Click the Owner's Manual Supplement option, which appears on the publication selection screen if an owner's supplement is available for the vehicle requested (Figure 8).
- 2. Click on the desired owner's manual supplement title from the resulting category list.
- 3. Repeat the previous step as your search narrows.
- Select a document to view from the document list offered.


# Owner's Warranty Book(s) Selection

This selection provides warranty and owner assistance information. Complete warranty coverage, new vehicle limited warranty, emission control systems warranties, and owner warranty assistance information are all covered under this selection for the vehicle requested.

- 1. Click the Owner's Warranty Books option, which appears on the publication selection screen if a warranty book is available for the vehicle requested (Figure 8).
- Click on the desired warranty book title from the resulting category list (Figure 41).
- 3. Repeat the previous step as your search narrows.
- 4. Select a document to view from the document list offered.







# **Enter Network Password** Please type your user name and password. Site: service.gm.com SI2000 User Name Realm User Name Password Save this password in your password list Cancel OK.











My Computer

Outlook Express





My Documents

TIS 2000

**E** 

Internet Explorer



Start Apache



Network Neighborhood







Service Information



**Service Information icon** 



Online Services



Acrobat Reader 5.0











### Service Information Home


Click this line to enter the VIN.

To View a Service Publication, First Select the Year, Make and Model of the Vehicle and click on 'Next'



Year.

















### You have selected the:

### 2004 Cadillac SRX

### Select a vehicle publication to view:

#### Service Manual/Bulletins

E SUV GMT265

### Unit Repair

Unit Repair

#### Owner's Manual

Cadillac SRX Owner Manual

### Owner's Manual Supplement

Cadillac SRX Entertainment and Navigation System

#### Owner's Warranty Books

Cadillac Warranty and Owner Assistance Information Canadian Cadillac Warranty

Optional Vehicle Information



# To find Service Information:

Select a category from the list...





2004 Cadillac SRX

Match All or Any of these words:



Select a category:

- <u>Bulletins By Category</u>
- <u>View All Bulletins</u>
- <u>Campaigns</u>
- ■Preliminary Information
- ▶Preface
- ■General Information
- ≥HVAC
- ≥Steering
- **≥**Suspension
- <u>Driveline/Axle</u>
- **Brakes**
- ≥<u>Engine</u>
- ≥Transmission/Transaxle
- **≥**Body
- Restraints
- **≥**Vehicle Control Systems
- ≥ Accessories



Search

Enter a keyword...
(Type a word or phrase in the

blank field or select from the Keyword, Sympton, or DTC list.)




and click Search.

Note: Bulletins, Campaigns and Preliminary Information may take longer to open.





# The user types the term "engine electrical" in the search field and clicks the Search button.



Keyword List Symptom List DTC List

The program automatically adjusts the search term to "ELECTRICAL ENGINE."

### Select a category:

- **Bulletins By Category**
- **SView All Bulletins**
- **∑**Campaigns
- ■Preliminary Information
- **≥**Preface
- <u>■General Information</u>
- ≥HVAC
- ≥ Steering
- ≥Suspension
- **Brakes**
- ≥ Engine
- <u>Transmission/Transaxle</u>
- **≥**Body
- ≥ Restraints
- Accessories



Note: Bulletins, Campaigns and Preliminary Information may take longer to open.







### Search Results


Searching for the following words: 'ELECTRICAL ENGINE'



# **Engine Electrical**


- Engine Electrical Connector End Views
- 2. Engine Electrical Component Views
- 3. Diagnostic System Check Engine Electrical
- Symptoms Engine Electrical
- Diagnostic Starting Point Engine Electrical







### 2004 Cadillac SRX



Keyword List Symptom List DTC List

### Select a category:

- <u>Bulletins By Category</u>
- <u> View All Bulletins</u>
- ▶Campaigns
- Preliminary Information
- ≥Preface
- <u>Seneral Information</u>
- ≥HVAC
- <u>≥Steering</u>




**Steering category selected** 

- SuSpension
- Driveline/Axle
- ≥Brakes
- ≥ Engine
- <u>▶Transmission/Transaxle</u>





# 2004 Cadillac SRX - Steering



Keyword search options:

"Entire manual" or "This section only"

### Select a category:

- <u>Bulletins By Category</u>
- <u> View All Bulletins</u>
- ≥ Campaigns
- Preliminary Information
- ▶Power Steering System
- <u>Steering Wheel₁and Column</u>
- <u> ≥Variable Effort Sceering</u>




**Steering Wheel and Column** category selected

Note: Bulletins, Campaigns and Preliminary Information may take longer to open.





### 2004 Cadillac SRX - Steering - Steering Wheel and Column



Keyword List Symptom List DTC List

### Select a category:

- Specifications
- Schematic and Routing Diagrams
- ■Component Locator
- <u>□Diagnostic Information and Procedures</u>
- ■Repair Instructions
- Description and Operation
- Special Tools and Equipment



Diagnostic Information and Procedures category selected






2004 Cadillac SRX - Steering - Steering Wheel and Column - Diagnostic Information and Procedures

### Select a document to view:

- Symptoms Steering Wheel and Column
- Steering Column Tilt Function Inoperative
- Ignition Can/Cannot Be Turned Off with Transmission in Any Gear
- Dock System Does Not Unlock
- 🔝 <u>Lock System DoeရှာNot Lock</u>
- 🔝 <u>Lock System Stick<del>s</del> in Start</u>
- Key Cannot Be Removed in the Off Lock Position
- High Lock Effort
- Noise in Steering Column
- 🚺 <u>Looseness in Steering Column</u>

The user has selected the document Lock System Does Not Lock.







# **Lock System Does Not Lock**

Step	Action	Yes	No	
DEFINITION: The lock system will not allow the key to be turned to the OFF lock position.				
1	Did you review the Steering Wheel and Column Description and Operation?	Go to Step 2	Go to Steering Wheel and Column Description and Operation	
2	Verify that the lock system does not lock.  Does the lock system operate normally?	System OK	Go to <u>Step 3</u>	
3	Inspect for a faulty lock cylinder or release button.  Is the lock cylinder or release button damaged?	Go to Step 7	Go to <u>Step 4</u>	
4	Inspect the shift linkage adjustment.  Is the shift linkage adjusted incorrectly?	Go to Step 8	Go to <u>Step 5</u>	










📒 Local intranet



# Service and Parts Operations



# 2004 Cadillac SRX - Steering - Steering Wheel and Column





Keyword List Symptom List DTC List

## Select a category:

- Specifications
- Schematic and Routing Diagrams
- Component Locator
- Diagnostic Information and Procedures
- <sup>©</sup>Repair<u>, Instructions</u>
- <u> Descrí∭ion and Operation</u>
  - cial Tools and Equipment







# **Ignition Switch Replacement**


## **Tools Required**

J 42759 Ignition Switch Connector Release Tool

## Removal Procedure

#### Caution

Refer to SIR Caution in Cautions and Notices.








- Disable the SIR system.
- 2. Remove the theft deterrent control module. Refer to Theft Deterrent Control Module Replacement in Theft Deterrent.
  - Rotate the key alarm connector (1) 90 degrees.
- 4. Gently pull the key alarm connector (1) out of the ignition lock cylinder case assembly (2).























1:1





## **Return to Arrow Cursor**

Returns to an arrow cursor from a previously selected magnifying glass or image mover.



## Fit to Screen

Resizes the image to fit your screen.



## **Magnifying Glass Plus (+)**

Enlarges image size.



## Fit to Height

Resizes the image to fit the height of your screen, regardless of width.



## Magnifying Glass Minus (-)

Decreases image size.



## Fit to Width

Resizes the image to fit the width of your screen, regardless of height.



## Mobile Magnifier

Allows the user to scan a magnified image. Press and hold the left mouse button.



## **Original Image**

Restores the original image.



## **Image Mover**

Allows the user to move the image while in an enhanced mode.




## **Print**


Prints the page.



**Service Information image viewing icons** 







# Service and Parts Operations














To view a Unit Repair Manual, click on the desired manual from the list below:


- ≥1997 Transmissions
- ≥1998 Transmissions
- ≥1999 Transmissions
- ≥2000 Transmissions
- ≥2001 Unit Repair
- ≥2002 Unit Repair
- ≥2003 Unit Repair
- ≥2004 Upit Repair


[HOME] [NUMBER SEARCH] [LATEST NEWS] [BULLETIN SEARCH] [HELP]



























must be carried. Follow the instructions below in order to repair the twisted/shielded cable.

h



















#### Documents which have arrived in the last 4 weeks

## **Bulletins**

## **Body and Accessories**

- #03-08-49-014A Fuel Gauge Fluctuates Between E and 1/4 Tank, Goes from 1/4 to Empty Too Quickly, Excessive Empty Fuel Reserve (Reprogram PCM) - (Oct 2, 2003)
- 2. #03-07-30-047 Diagnostic Information for Various Shift Conditions Inadvertent IP Switch Activation -(Oct 2, 2003)
- 3. #03-08-58-005 Wind Noise at Highway Speeds from Base of Driver Side (Left) A-Pillar Near VIN Plate Area (Seal Area with Seam Sealer) - (Oct 2, 2003)
- 4. #03-08-66-011 SMA Spare Tire Carrier May Rattle Over Rough Surfaces, T-Pin Lock Difficult to Remove (Install Revised Latch Isolator and Verify Installation fo Anti-Rotation Bolts in Hinge Bracket) - (Oct 2, 2003)
- #03-08-51-002 Warranty Admin. Changes to Paint Claim Submission Process Paint Mix Time Must Be Entered on Each Line - (Oct 2, 2003)

## Transmission/Transaxle

- #PI01395A Shifter Adjustment for Manual Driver Shift Control 5L40E 5L50E adjust indicator inoperative manual transmission - (Oct 1, 2003)
- #PI01129A Allison LCT1000 Serviceability delay default drive DTC engage forward gear inoperative intermittent LCT 1000 loss MIL operation part repair reverse shift TCM transmission slip - (Sep 25,
- 3. #PI01385 4T40E Surge, Slip Condition Under Load in 2nd, 3rd and/or 4th body chuggle fourth hesitation hot LG8 miss second shift third valve - (Sep 25, 2003)
- #PI01373 Service VME High Effort to Move Shift Lever 4T40E 4T45E hard (Sep 18, 2003)


To see the documents which have arrived during a different time interval, please select the time from the list below, and press Submit:



Submit

[HOME] [NUMBER SEARCH] [LATEST NEWS] [BULLETIN SEARCH] [HELP]





## **Bulletins**


## **Body and Accessories**


- #03-08-49-014A Fuel Gauge Fluctuates Between E and 1/4 Tank, Goes from 1/4 to Empty Too Quickly. Excessive Empty Fuel Reserve (Reprogram PCM) - (Oct 2, 2003)
- 2. #03-07-30-047 Diagnostic Information for Variou hift Conditions Inadvertent IP Switch Activation (Oct 2. 2003)
- #03-08-58-005 Wind Noise at Highway Speeds from Base of Driver Side (Left) A-Pillar Near VIN Plate Area (Seal Area with Seam Sealer) - (Oct 2, 2003)
- 4. #03-08-66-011 SMA Spare Tire Carrier May Rattle Over Rough Surfaces, T-Pin Lock Difficult to Remove (Install Revised Latch Isolator and Verify Installation fo Anti-Rotation Bolts in Hinge Bracket) - (Oct 2, 2003)
- 5. #03-08-51-002 Warranty Admin. Changes to Paint Claim Submission Process Paint Mix Time Must Be Entered on Each Line - (Oct 2, 2003)
- #03-08-42-006A Info Tail Lamp Circuit Board Now Available for Service Use (Oct 1, 2003)
- #03-08-67-007 Creak in Roof (Install Insulator) (Oct 1, 2003)
- 8. #03-08-57-004 Wet Front Floor Carpet (Install Plastic Nuts in A-Pillar or Apply Weatherstrip Adhesive) (Oct 1. 2003)
- 9. #02-T-20 SMU for 2002 VUE Body Electrical Diagnostics Service Manuals Regarding AM/FM Stereo with Cassette and 6-Disc CD Player Check Charts - (Sep 30, 2003)
- 10. #00-T-17C Headliner Sags or Hangs Too Low at Rear of Sunroof Opening (Sep 30, 2003)
- 11. #02-T-05 SMU for 2000-2001 L-Series Body/Electrical Volume II Service Manuals Regarding Front Seat Cushion Cover/Pad Removal and Installation - (Sep 30, 2003)
- 12. #03-08-48-006 Repair Information for Reconnection of Rear Window Defroster Contact or Tab (Sep 29, 2003)


## **Brakes**

 #03-05-25-008 Intermittent/Constant ABS MIL Illuminated (Replace Both Froth Wheel Speed Harnesses) - (Oct 1, 2003)













# Service and Parts Operations



## Search Results

# Searching for the following word: 'ABS'

- #PI01398 Rattle Resonance Rear of Vehicle During Acceleration absorber accelerate axle bracket damper differential exhaust insulator launch moan mount noise torque transmission turn vibration weight - (Oct 1, 2003)
- #PI01320 Service VME Brake Squeal and Brake Dust Accumulation ABS TCS wheel -(Aug 18, 2003)
- 3. #02-06-03-006A No Start, No Crank, Battery, Batteries, Generator, Gages, SES, SIR, Brak Security, Theft, ABS, Hot, DIC Messages, Lamp, Light, Battery and Generator Diagnostic Testing, and Cadillac Roadside Service (Nov 26, 2002)
- #02-06-03-011 Electrical System Diagnostic Work Sheet, No Start, No Crank, Battery, Batteries, Generator, Gages, SES, SIR, Brake, Security, Theft, ABS, Hot DIC Messages, Lamp, Light, Battery/Generator Diag. Testing - (Oct 30, 2002)
- #02-06-03-012 Proper Diagnostic Procedures for No Start, No Crank, Battery, Batteries, Generator, Gauges, SES, SIR, Brake, Security, Theft, ABS, Hot, DIC Messages, Lamp, Light, Battery and Generator Diag. Testing - (Oct 25, 2002)



[HOME] [NUMBER SEARCH] [LATEST NEWS] [BULLETIN SEARCH] [HELP]

Forward ->

# No Start, No Crank, Battery, Batteries, Generator, Gages, SES, SIR, Brake, Security, Theft, ABS, Hot, DIC Messages, Lamp, Light, Battery and Generator Diagnostic Testing, and Cadillac Roadside Service #02-06-03-006A - (11/26/2002)

No Start, No Crank, Battery, Batteries, Generator, Gages, SES, SIR, Brake, Security, Theft, ABS, Hot, DIC Messages, Lamp, Light, Battery and Generator Diagnostic Testing, and Cadillac Roadside Service, Warranty Claims Procedure (Proper Diagnostic Procedures)

1997-2003 Passenger Cars and Trucks (Except Electric Vehicles)

2003 HUMMER H2

This bulletin is being revised to clarify the Service Procedures and update the Warranty Section. Please discard Corporate Bulletin Number 02-06-03-006 (Section 06 -- Engine).

IF YOU WISH TO PRINT THE ELECTRICAL SYSTEM DIAGNOSTIC WORK SHEET ONLY, YOU MAY REFER TO CORPORATE BULLETIN NUMBER 02-06-03-011.

#### Condition

Some customers may have comments regarding any one or more of the following conditions:

- 1. Intermittent illumination of one or more of the following instrument panel warning lamps:
  - o SES light
  - o Generator light
  - o SIR light
  - o Brake light
  - o Security, theft light
  - o ABS light
  - o Hot light
- 2. Gage readings which seem to be incorrect.
- 3. Erratic RPM display on the Tachometer.
- 4. Engine is difficult /hard to start.
- 5. Engine will not crank.
- Check Generator displayed on the Driver Information Center.
- The transmission shifts hard.









# Service Information (SI) Help Topics

## Select a help topic to view:

- Release Note
- Minimum Requirements to run SI
- How to zoom on an image [Plugin Support]
- Internet Browser Maintenance
- Contacting us for Assistance
- Explanation of Toolbar Icons
- View current data version

[SERVICE INFORMATION HOME]



