# **BASIC OPERATION**

# **VALUE-ADDED FEATURES**

## CONTACTS

## **Creating Entries**

Select Contacts > New Contact, enter the name, press OK Key ( ). You can now assign a Contact type, Number, Address, Voice name or Speed dial number. When you finish press Left Soft Key (**o**) under Save.

Accessing Contacts Press Menu Key ( ), select Contacts - or during a call, press Menu Key (1), select Contacts.

### **RING TONES**

Setting Ring Tones Press Menu Key (1), select Ring Tones, scroll through the list of ring tones and select the one you want to assign. Select the features you want to assign the ring tone to (phone call, call alert, message, etc). When you finish, press Left Soft Key (**o**) under Done.

## MENU SHORTCUTS

Creating Shortcuts Go the menu item you want to create a shortcut for, press and hold Menu Key ( until a confirmation screen appears, press Left Soft Key (●) under Yes, select Key > press the number key you want to assign to the shortcut > enter voice tag for shortcut. Press Left Soft Key (O) under Done.



## **Location Based Services**

Navigation help including maps and directions, traffic advisories and roadside assistance.

# **Multimedia Services**

**Downloading Ring Tones** Downloading Images Downloading Java Applications



## **Push-To Features**

Push-To-Talk Push-To-Send Pictures Push-To-Send Contacts


## **Entertainment Mute**

This feature will automatically mute the car's entertainment system during a call.



www.hellomoto.com





Motorola M710 iDEN Fixed Mobile Car Phone

Short User's Guide

# **GETTING TO KNOW THE M710**

# INITIAL SET-UP

# **CALL MANAGEMENT**



## SIM CARD ACTIVATION

**Inserting your SIM** With your phone powered off, insert the SIM card into the SIM card socket at the right side of the phone.

## POWER CONTROL

Turning On/Off

The phone powers on and off automatically using the car's ignition sensor. For manual operation press and hold the power key ( ) until the display panel lights on/off.

## **VOLUME CONTROL**

Ring Tone Volume When no call is active, press either of the Volume Keys (1) on the side of the phone to set the Ring Tone Volume.

Call Volume

During a call, press either of the Volume Keys ( ) on the side of the phone to adjust the Call

Muting Microphone During a call, press the Right Soft Key (©) under Mute. To turn off, press the Right Soft Key (0)

under Unmute.

To set the Key Volume sound level, press Menu Key (19), select Settings > Volume > Keypad.

### OTHERS

**Key Volume** 

Setting Menu View Press Menu Key ( ), select Settings > Display/Info > Menu View. To choose a list, select List View; to choose large icons, select Icon View.

### **PHONE CALLS**

Answering a call

Press Send Key ( ) - or - press OK Key ( ) or - press Right Soft Key (O) under YES - or press the external PTT button.

**Ending a Call** 

Press End Key ( ) - or - press the external PTT or the Smart Key (---).

Making a Call

For Phone Calls: Enter the number you want to call, press Send Key ( ) - or - press OK Key

For Private Calls: Enter the Private ID you want to call, press and hold the external PTT button installed in your car - or - the Smart Key ( Begin talking after your phone emits a chirping sound. Release the PTT button or Smart Key ( ) to listen.

### CALL ALERTS

Sending Call Alerts Enter the Private ID you want to call, press Right Soft Key ( ) under Alert. "Ready to Alert" appears on the display. Press the external PTT button until Alert Successful appears on the display.

Receiving Call Alerts

To answer a call alert, press the external PTT button to make a Private call to the sender. To gueue a call alert, press Right Soft Key ( ) under Queue.

To clear a call alert, press OK Key (ok) - or press Right Soft Key (O)under Clear.

## **VOICE ACTIVATION**

**Assigning Voice** Name

Press Menu Key ( ), select Contacts > select Entry (or create New Contact) > select Edit > select Options > select Voice Name. Say and repeat the name you want to assign to the number. When you finish, press Right Soft Key (O) under Back.

**Activating Name** Dialing

When Voice Name is stored in the phone entry, press the external PTT or the Smart Key (-), say the entry Voice Name clearly into the microphone. The phone repeats the Voice Name and automatically dials the associated number.

## RECENT CALLS

Received/Dialed Calls

Press the Menu Key ( ), select Recent Calls > scroll through the list using the 4-Way Navigation Key ( ) for received and dialed calls and call alerts.

<sup>\*</sup> Various phone menus and features are operator dependent