



LASERJET ENTERPRISE M4555

MFP SERIES

For the complete PDF manual
please visit www.LaserPros.com.

Service Manual





HP LaserJet Enterprise M4555 MFP Series

Service Manual

Copyright and License

© 2011 Copyright Hewlett-Packard Development Company, L.P.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

The information contained herein is subject to change without notice.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Part number: CE502-90971

Edition 1, 4/2011

Trademark Credits

Intel® Core™ is a trademark of Intel Corporation in the U.S. and other countries.

Microsoft®, Windows®, Windows® XP, and Windows Vista® are U.S. registered trademarks of Microsoft Corporation.

ENERGY STAR® and the ENERGY STAR® mark are registered U.S. marks.

Conventions used in this guide

 **TIP:** Tips provide helpful hints or shortcuts.

 **NOTE:** Notes provide important information to explain a concept or to complete a task.

 **CAUTION:** Cautions indicate procedures that you should follow to avoid losing data or damaging the product.

 **WARNING!** Warnings alert you to specific procedures that you should follow to avoid personal injury, catastrophic loss of data, or extensive damage to the product.

Table of contents

1 Theory of operation	1
Basic operation	2
Sequence of operation (product)	2
Sequence of operation (scanner)	3
Formatter-control system	4
Sleep delay	4
Image Resolution Enhancement technology	4
Input/output	5
Memory	5
Hard disk	5
Random-access memory	5
Firmware	5
Nonvolatile memory	5
HP Memory Enhancement technology	6
CPU	6
P/L overview	6
PML	6
Control panel	6
Scanner interface	6
Engine-control system	7
DC controller PCA	7
Motors and fans	8
Motor and fan functions	9
Ambient-temperature detection	10
High-voltage power supply	11
Fuser control	12
Fuser temperature control	13
Fuser failure detection	14
Other functions	15
Low-voltage power supply	16
Overcurrent/overvoltage protection	17
Safety	17

Sleep mode	18
Power supply detection	18
Image-formation system	19
Print cartridge	21
Memory tag	21
Cartridge-presence detection	21
Toner detection	22
Electrophotographic process	22
1. Primary charge (conditioning)	22
2. Laser-beam exposure (writing)	23
3. Developing	23
4. Transfer	24
5. Separation	25
6. Fusing	25
7. Drum cleaning	26
Laser/scanner system	26
Laser/scanner assembly failure detection	28
Safety	28
Pickup, feed, and delivery system	29
Pickup-and-feed block	33
Cassette pickup	34
Cassette media-size detection and cassette-present detection	35
Cassette lift-up operation	36
Cassette media-presence detection	36
Multifeed prevention	37
Tray 1 pickup	38
Tray 1 media-presence detection	39
Fusing-switchback and delivery block	43
Fusing	43
Pressure roller pressurization and depressurization control	44
Switchback and delivery control	45
Face-down delivery	46
Face-up delivery	47
Output bin media-full detection	48
Duplex block	49
Duplex side registration adjustment operation	49
Jam detection	52
No pick jam 1	53
No pick jam 2	54
No pick jam 3	54
Feed stay jam	54

Fuser delay jam	55
Fuser stay jam	55
Fuser wrap jam	55
Fuser output delay jam 2	55
Fuser output stay jam 2	55
Duplex re-pickup jam 1	55
Fuser output delay jam 3	56
Fuser output stay jam 3	56
Residual paper jam	56
Door open jam	56
Other functions	57
Tray 3 (1 x 500-sheet feeder)	58
500-sheet feeder motor control	59
500-sheet feeder pickup and feed	60
Cassette media-size detection and cassette presence detection	60
Cassette lift-drive operation	60
Jam detection	61
Additional trays	62
Motor control	65
Paper-deck pickup and feed operation	66
Cassette media-size detection and cassette presence detection	68
Cassette lift-drive operation	69
Jam detection	69
HP stapling mailbox	70
Motor control	73
Failure detection	74
Delivery operation	74
Staple operation	76
Stapler	81
Output bin 3 lift operation	82
Stacker mode	83
Mailbox/job separator mode	84
Jam detection	85
Automatic delivery	86
Laser/scanner system	87
Document feeder/scanner assembly	89
Scanner subsystem	89
Document feeder/scanner motor and fan control	90
Legal detection sensor	91
Fan timing sequence	91
Optical assembly operation	92

Image data path	92
Document feeder/scanner paper path and sensors	93
Document feeder pickup mechanism	94

2 Removal and replacement 95

Introduction	97
Removal and replacement strategy	98
Electrostatic discharge	99
Required tools	100
Service approach	101
Before performing service	101
After performing service	101
Post-service test	101
Print-quality test	101
Print cartridge	102
Staple cartridge (for models with a stapler/stacker)	106
Control panel	108
Transfer roller	111
Output bin and bin base assembly	112
Duplex accessory	113
Fuser-entrance guide	114
Remove the fuser-entrance guide	114
Fuser	115
Remove the fuser	115
Tray 1 separation roller	116
Envelope feeder cover	117
Tray 1 pickup and feed rollers	118
Tray 2, 3, 4, or 5 pickup, feed, and separation rollers	119
Scanner filter cover and scanner filter	120
Interface formatter PCA	121
Hard drive	123
Remove the SSD	123
Remove the encrypted HDD	124
Installing a replacement hard drive	126
HDD firmware upgrade	127
SSD firmware upgrade	128
Fax accessory PCA	129
Document feeder tray extender	130
Document feeder pickup roller cover	131
Document feeder pickup roller	132
Document feeder pickup roller pad and spring	133

Covers and document feeder	134
Identification and location (product base)	134
Scanner rear cover	136
Tray 1 cover	137
Cassette-door-open detection switch	139
Left-rear corner cover	141
Remove the left-rear corner cover	141
Front cover	143
Front-right cover	144
Remove the front-right cover	144
Front-upper cover	146
Remove the front-upper cover	146
Image scanner right cover	148
Image scanner cable cover	150
Rear-right cover	151
Rear-left cover	152
Remove the rear-left cover	152
Rear-top cover	154
Remove the rear-top cover	154
Right-lower door	156
Remove the right-lower cover	156
Document-feeder hinge cover	158
Remove the document-feeder hinge cover	158
Reinstall the document-feeder hinge cover	160
Document feeder	161
Remove the document feeder	161
Image scanner left cover	164
Remove the image scanner left cover	164
Main assemblies	165
Registration assembly	165
Switchback upper guide assembly	166
Reinstall the switchback upper guide assembly	167
Switchback assembly	168
Remove the switchback assembly	168
Laser/scanner assembly	171
Remove the laser/scanner assembly	171
Cartridge sensor assembly	173
Remove the cartridge sensor assembly	173
Environmental sensor	174
Remove the environmental sensor	174
DC controller shield-plate assembly	176

Remove the DC controller shield-plate assembly	176
DC controller	178
Remove the DC controller	178
Tray 1 pickup assembly	180
Remove the Tray 1 pickup assembly	180
Connector PCA	183
Remove the connector PCA	183
Feed motor (M101)	185
Remove the feed motor	185
Drum motor (M102)	186
Remove the drum motor	186
Fuser motor (M299)	187
Remove the fuser motor	187
Main fan (FN101)	188
Remove the main fan	188
Reinstall the main fan	189
Laser/scanner fan (FN102)	190
Remove the laser/scanner fan	190
Reinstall the laser/scanner fan	191
Cartridge front-side fan (FN103)	192
Remove the cartridge front-side fan	192
Reinstall the cartridge front-side fan	193
Low-voltage power supply fan (FN104)	194
Remove the low-voltage power supply fan	194
Reinstall the low-voltage power supply fan	195
Switchback fan (FN105)	196
Remove the switchback fan	196
Reinstall the switchback fan	197
Cartridge fan (FN301)	198
Remove the cartridge fan	198
Reinstall the cartridge fan	199
Interlock switch (SW101)	200
Remove the interlock switch	200
Output accessory detection switch (SW104)	202
Remove the output accessory detection switch	202
Low-voltage power supply	204
Remove the low-voltage power supply	204
Cassette lifter assembly	207
Remove the cassette lifter assembly	207
Lifter drive assembly	209
Remove the lifter drive assembly	209

Engine power supply	212
Remove the engine power supply	212
Feed roller assembly	217
Remove the feed roller assembly	217
Pickup drive assembly	218
Remove the pickup drive assembly	218
Cassette pickup assembly	219
Remove the cassette pickup assembly	220
Document feeder	222
Paper present flag	222
Document feeder scanner lid	223
Remove the document feeder scanner lid	223
Reinstall the document feeder scanner lid	225
Document feeder front cover	226
Document feeder rear cover	228
Document feeder jam-access cover	231
Remove the document feeder jam-access cover	231
Document feeder tray assembly	232
Remove the document feeder tray assembly	232
Document feeder internal assembly	233
Remove document feeder internal assembly	233
Document feeder PCA	235
Remove the document feeder PCA	235
Document feeder cable	236
Remove the document feeder cable	236
Reinstall the document feeder cable	237
Document feeder left hinge	238
Remove the document feeder left hinge	238
Document feeder right hinge	239
Remove the document feeder right hinge	239
Document feeder fan	240
Remove the document feeder fan	240
Document feeder motor	241
Remove the document feeder motor	241
Document feeder motor	242
Remove the document feeder motor	242
Document feeder open sensor	243
Remove the document feeder open sensor	243
Document feeder jam access plate	244
Remove the document feeder jam access plate	244
Base assembly	245

Remove the base assembly	245
Scanner	246
Scanner assembly	246
Remove the scanner	246
Scanner connector board (SCB) PCA	249
Remove the SCB PCA	249
Scanner release assembly	251
Remove the scanner release assembly	251
Scanner 24 V and communication cable	252
Remove the scanner 24 V and communication cable	252
Tub top	255
Remove the tub top	255
Interconnect board and size sensor	256
Remove the interconnect board and size sensor	256
Inverter	259
Remove the inverter	259
Inverter fan	261
Remove the inverter fan	261
Optical assembly	262
Remove the optical assembly	262
Motor assembly	266
Remove the motor assembly	266
Scanner fan	268
Remove the scanner fan	268
Optional 500-sheet paper feeder assembly	270
Rear cover (500-sheet paper feeder)	270
Right-front cover (500-sheet paper feeder)	271
Left cover (500-sheet paper feeder)	272
Remove the left cover (500-sheet paper feeder)	272
Right cover (500-sheet paper feeder)	273
Remove the right cover (500-sheet paper feeder)	273
Front cover (500-sheet paper feeder)	274
Pickup assembly (500-sheet paper feeder)	275
Remove the pickup assembly (500-sheet paper feeder)	275
Lifter assembly (500-sheet paper feeder)	278
Remove the lifter assembly (500-sheet paper feeder)	278
Lifter-drive assembly (500-sheet paper feeder)	280
Remove the lifter-drive assembly (500-sheet paper feeder)	280
Pickup motor assembly (500-sheet paper feeder)	281
Remove the pickup motor (500-sheet paper feeder) assembly	281
Controller PCA (500-sheet paper feeder)	282

Remove the controller PCA (500-sheet paper feeder)	282
Optional paper feeder assemblies (1 x 500-sheet and 3 x 500-sheet)	283
Front door (optional paper feeder)	283
Rear cover (optional paper feeder)	285
Right-front cover (optional paper feeder)	286
Right door (optional paper feeder)	287
Left cover (optional paper feeder)	289
Remove the left cover (optional paper feeder)	289
Right cover (optional paper feeder)	291
Remove the right cover (optional paper feeder)	291
Rear-right cover (optional paper feeder)	292
Remove the rear-right cover (optional paper feeder)	292
Pickup assembly (optional paper feeder)	293
Remove the pickup assembly (optional paper feeder)	293
Lifter assembly (optional paper feeder)	296
Remove the lifter assembly (optional paper feeder)	296
Lifter-drive assembly (optional paper feeder)	297
Remove the lifter-drive assembly (optional paper feeder)	297
Pickup motor assembly (optional paper feeder)	298
Remove the pickup motor assembly (optional paper feeder)	298
Controller PCA (optional paper feeder)	299
Remove the controller PCA (optional paper feeder)	299
Stapler/stacker	301
SSMBM front cover	301
SSMBM rear cover	302
SSMBM handle assembly	303
Remove the SSMBM handle assembly	303
SSMBM top cover	305
Remove the SSMBM top cover	305
SSMBM output bin 3	306
SSMBM output bin assembly cover	308
Remove the SSMBM output bin assembly cover	308
SSMBM PCA	310
SSMBM output bin sensor PCA	312
Remove the SSMBM output bin sensor PCA	312
SSMBM stapler assembly	313
Remove the SSMBM stapler assembly	313
SSMBM jogger assembly	314
Remove the SSMBM jogger assembly	314
SSMBM output bin solenoid	316
Remove the SSMBM output bin solenoid	316

SSMBM output bin assembly	318
Remove the SSMBM output bin assembly	318
SSMBM stage top assembly	320
Remove the SSMBM stage top assembly	320
Reinstall the SSMBM stage top assembly	329
SSMBM stage assembly	330
Remove the SSMBM stage assembly	330
SSMBM output bin 3 drive assembly	333
Remove the SSMBM output bin 3 drive assembly	333
3 Problem solving	337
Solve problems checklist	338
Administration Menu Map	340
Current settings page	340
Troubleshooting process	341
Problem-solving flowchart	341
Determine the problem source	344
Pre-troubleshooting checklist	345
Troubleshooting flowchart	347
Power subsystem	348
Power-on checks	348
Power-on troubleshooting overview	348
Control-panel checks	350
Scanning subsystem	351
Tools for troubleshooting	352
Component diagnostics	352
LED diagnostics	352
HP Jetdirect Inside LEDs	352
Heartbeat LED	353
Connectivity LED	353
Fax LED (fax models only)	353
Engine diagnostics	353
Early boot diagnostic test	353
Engine test	354
Formatter test	355
Half self-test	355
Drum rotation test	356
Paper-path test	357
Manual sensor test	357
SW1 right lower door	359
SW105 right upper door	360

SW101 cartridge door (top cover)	361
SR10 Tray 5 feed	362
SR7 Tray 4 feed	363
SR4 Tray 3 feed	364
PS102 pre-feed	365
PS103 TOP	366
PS106/108 paper width	367
PS700/PS699 fuser output	368
PS110 intermediate switchback	369
PS111 inverter media stay	370
PS113 duplex refeed	371
PS112 output	372
PS104 output bin full	373
Tray/Bin manual sensor test	374
PS1802 envelope feeder paper	376
PS114 Tray 1 paper	377
PS101 Tray 2 paper	378
PS107/PS907 Tray 2 paper surface	379
SW102 Tray 2 paper size	380
SR3 Tray 3 paper	381
SR1/SR2 Tray 3 paper surface	381
SW2 Tray 3 paper size	381
SR4 Tray 3 feed	382
SR6 Tray 4 paper	383
SR5/SR8 Tray 4 paper surface	383
SW3 Tray 4 paper size	383
SR7 Tray 4 feed	384
SR11 Tray 5 paper	385
SR9/SR12 Tray 5 paper surface	385
SW4 Tray 5 paper size	385
SR10 Tray 5 feed	386
PS104 output bin full	387
SW1 power switch	388
SW103 face up bin	389
SW104 output accessory	390
SW700 engine test	391
Paper path sensor test	391
Print/stop test	392
Scanner tests	392
Scanner component tests	393
Scanner sensor tests	394

Document feeder paper present sensor	394
Document feeder Y (length) sensor	395
Document feeder jam cover sensor	396
Flatbed Y (length) sensor	397
Flatbed cover angle sensor	398
Flatbed cover sensor	399
Document feeder registration sensor	400
Document feeder exit sensor	401
Document feeder read sensor	402
Component tests	403
Control-panel tests	403
Component test (special-mode test)	403
Stapler/stacker	404
Diagrams for troubleshooting	405
Block diagrams	405
Sensors	405
Switches (product base)	408
Solenoids (product base)	409
Clutch (product base)	410
Motors	411
Fans (product base)	415
Main assemblies	416
Main PCAs (product base)	423
Rollers (product base)	424
DC controller connections	425
Scanner controller board (SBC) connectors	427
General timing chart	428
General circuit diagrams	430
Internal print-quality test pages	437
Print-quality-troubleshooting pages	437
Cleaning page	438
Configuration page	438
Configuration page	438
HP embedded Jetdirect page	440
Embedded protocol page	441
Finding important information on the configuration pages	442
Print-quality troubleshooting tools	443
Repetitive defects ruler	443
Control panel menus	443
Administration menu	445
Reports menu	445

General Settings menu	446
Copy Settings menu	449
Scan/Digital Send Settings menu	452
Fax Settings menu	454
Open From USB Settings menu	458
Print Settings menu	458
Print Options menu	459
Display Settings menu	460
Manage Supplies menu	462
Manage Trays menu	463
Stapler/Stacker Settings menu	463
Network Settings menu	464
Troubleshooting menu	468
Device Maintenance menu	470
Backup/Restore menu	470
Calibrate/Cleaning menu	470
USB Firmware Upgrade menu	471
Service menu	471
Interpret control-panel messages, status-alert messages, and event code errors	472
10.OX.Y0 Supply memory error	472
10.23.50	472
10.23.51	473
10.23.52	473
10.23.70 Printing Past Very Low	473
10.XX.33 Used Supply In Use	473
10.XX.34 Used Supply In Use	474
10.XX.40 Genuine HP Supplies Installed	474
10.XX.41 Unsupported Supply In Use	474
10.XX.70 Printing past very low	475
10.YY.15 Install <supply>	475
10.YY.35 Incompatible <supply>	475
11.00.YY Internal clock error	476
13.00.00	476
13.00.EE	476
13.A3.FF	476
13.D3.DZ	477
13.E5.FF	477
13.EA.EE	477
13.EE.FF	477
13.FF.EE	478
13.FF.FF	478

13.WX.EE	478
13.WX.FF	478
13.WX.YZ Fuser Area Jam	479
13.WX.YZ Fuser wrap jam	479
13.WX.YZ Jam below control panel	480
13.WX.YZ Jam in lower bin area	480
13.WX.YZ Jam in Tray 1	480
13.WX.YZ Jam in Tray <X>	480
13.WX.YZ Jam inside envelope feeder	480
13.WX.YZ Jam inside left cover	481
13.WX.YZ Jam inside right door	481
13.WX.YZ Jam inside top cover	481
13.WX.YZ Jams inside lower right door	481
14.00.XX	481
20.00.00 Insufficient memory: <Device> To continue, touch "OK"	482
21.00.00 Page Too Complex	482
30.01.YY Scanner Failure	482
31.01.02 Jam in document feeder	486
31.01.03 Document feeder pick error	487
31.01.0X	487
32.08.AX	488
32.1C.XX	488
32.21.00	495
33.01.XX	495
33.XX.YY Used board/disk	495
40.00.01 USB I/O buffer overflow To continue, touch "OK"	496
40.00.02 Embedded I/O buffer overflow To continue, touch "OK"	496
40.00.03 EIO <X> buffer overflow To continue, touch "OK"	496
40.00.04 EIO <X> bad transmission To continue, touch "OK"	496
40.00.05 Embedded I/O bad transmission To continue, touch "OK"	496
41.02.00 Error	497
41.03.YZ Unexpected size in envelope feeder To use another tray, touch "Options"	497
41.03.YZ Unexpected size in tray <X>	498
41.05.YZ Unexpected type in tray <X>	499
41.XX.YZ Error To continue, touch "OK"	501
42.XX.YY	502
47.00.XX	502
47.01.XX	502
47.02.XX	503
47.03.XX	503

47.04.XX	503
47.05.00	503
47.06.XX	503
47.WX.YZ Printer Calibration Failed To continue, touch "OK"	504
49.XX.YY To continue turn off then on	505
50.WX.YZ Fuser error To continue turn off then on	505
51.00.YY Error	507
52.XX.00 Error To continue turn off then on	508
54.XX.YY Error	508
55.00.YY DC controller error To continue turn off then on	509
55.0X.YY DC controller error To continue turn off then on	509
56.00.YY Error To continue turn off then on	509
57.00.0Y Error To continue turn off then on	510
58.00.0Y Error To continue turn off then on	511
59.00.YY error To continue turn off then on	512
59.0X.50 Error To continue turn off then on	512
59.0X.60 Error To continue turn off then on	513
59.A2.0x Error	513
60.00.0Y Tray <Y> lifting error	514
62.00.00 No system To continue turn off then on	515
65.X0.A1 Output accessory disconnected	515
66.80.YY Stapler/Stacker failure	516
69.11.YY Error To continue turn off then on	518
70.00.00 Error To continue turn off then on	518
79.XX.YY Error To continue turn off then on	518
80.0X.YY Embedded JetDirect error	519
81.YY.ZZ EIO-1 Card Failure	520
82.73.46 OR 82.73.47	522
98.00.01 Corrupt data in firmware volume	522
98.00.02 Corrupt data in solutions volume	522
98.00.03 Corrupt data in configuration volume	523
98.00.04 Corrupt data in job data volume	523
99.00.01 Upgrade not performed file is corrupt	523
99.00.02 Upgrade not performed timeout during receive	523
99.00.03 Upgrade not performed error writing to disk	524
99.00.04 Upgrade not performed timeout during receive	524
99.00.05 Upgrade not performed timeout during receive	524
99.00.06 Upgrade not performed error reading upgrade	524
99.00.07 Upgrade not performed error reading upgrade	525
99.00.08 Upgrade not performed error reading upgrade	525
99.00.09 Upgrade canceled by user	525

99.00.10 Upgrade canceled by user	525
99.00.11 Upgrade canceled by user	526
99.00.12 Upgrade not performed the file is invalid	526
99.00.13 Upgrade not performed the file is invalid	526
99.00.14 Upgrade not performed the file is invalid	526
99.00.2X	527
99.09.60 Unsupported disk	527
99.09.61 Unsupported disk	528
99.09.62 Unknown disk	528
99.09.63 Incorrect disk	528
99.09.64 Disk malfunction	528
99.09.65 Disk data error	528
99.09.66 No disk installed	529
99.09.67 Disk is not bootable please download firmware	529
99.XX.YY	529
<binname> full Remove all paper from bin	529
<Supply> low OR Supplies low	530
<Supply> very low OR Supplies very low	530
[File System] device failure To clear touch "OK"	531
[File System] file operation failure To clear touch "OK"	531
[File System] file system is full To clear touch "OK"	531
[File System] is not initialized	531
[File System] is write protected	531
Accept bad signature	531
ADF not detected	532
Bad optional tray connection	532
Calibration reset pending	532
Canceling	532
Canceling... <jobname>	533
Cartridge Low	533
Cartridge Memory Abnormal	533
Cartridge Out	533
Checking engine	534
Checking paper path	534
Chosen personality not available To continue, touch "OK"	534
Cleaning do not grab paper	534
Cleaning... ..	534
Clearing event log	535
Clearing paper path	535
Close lower right door	535
Close right upper cover	535

Close stapler/stacker multi bin mailbox door	536
Close top cover	536
Cooling device	536
Creating cleaning page... ..	536
Data received To print last page press "OK"	536
Document feeder pick error	537
EIO <X> disk initializing	537
EIO <X> disk not functional	537
EIO <X> disk spinning up	537
Event log is empty	538
Expected drive missing	538
External device initializing	538
Fax is disabled – ignoring call	538
FIM Load Error Send full FIM on <X> port	538
Flatbed cover open	539
Fuser Kit low	539
Fuser Kit very low To continue, touch "OK"	539
Gateways failed	539
Gateways OK	540
Genuine HP cartridge installed	540
Genuine HP supply installed	540
HP Secure hard drive disabled	540
Incompatible <Supply>	540
Incompatible supplies	541
Initializing... ..	541
Install fuser unit	541
Install supplies	541
Install supply	542
Internal disk device failure To clear touch "OK"	542
Internal disk file operation failed	542
Internal disk file system is full	542
Internal disk is write protected	542
Internal disk not found	543
Internal disk not functional	543
Internal disk not initialized	543
Internal disk spinning up	543
Jam in document feeder	543
Job not stapled due to mixed sizes	544
Load Tray <X>: [Type], [Size]	544
Load Tray <X>: [Type], [Size] To use another tray, press "OK"	544
Loading program <XX>	545

Manually feed output stack Then touch "OK" to print second side	545
Manually feed: <Type><Size>	545
Manually feed: <Type><Size> To use another tray, press "OK"	546
Moving solenoid	546
Moving solenoid and motor	546
No job to cancel	546
NON HP SUPPLY INSTALLED	546
Output Bin Full	547
Paused... ..	547
Performing Paper Path Test... ..	547
Please Wait... ..	547
Printing Configuration... ..	548
Printing Event Log... ..	548
Printing File Directory... ..	548
Printing Font List... ..	548
Printing Fuser Test Page... ..	548
Printing Help Page... ..	548
Printing Menu Map... ..	549
Printing Registration Page... ..	549
Printing stopped	549
Printing Supplies Status Page... ..	549
Printing Usage Page... ..	549
Printing...engine test	550
Processing duplex job Do not grab paper until job completes	550
Processing job from tray <X>... Do not grab paper until job completes	550
Processing... ..	550
Processing... copy <X> of <Y>	550
RAM disk device failure To clear touch "OK"	551
RAM disk file operation failed To clear touch "OK"	551
RAM disk file system is full To clear touch "OK"	551
RAM disk is write protected To clear touch "OK"	551
RAM disk not initialized	551
Ready	552
Ready <IP Address>	552
Reattach output bin	552
Receiving Upgrade	552
Remove one print cartridge	552
Remove USB accessory	553
Replace <Supply>	553
Replace supplies	553
Resend external accessory firmware	554

Resend Upgrade	554
Restore Factory Settings	554
ROM disk device failed To clear touch "OK"	554
ROM disk file operation failed To clear touch "OK"	555
ROM disk file system is full To clear touch "OK"	555
ROM disk is write protected To clear touch "OK"	555
ROM disk not initialized To clear touch "OK"	555
Rotating Motor	555
Scanner Failure	556
Size Mis-Match	558
Size mismatch in Tray <X>	558
Sleep mode on	558
Staple Cartridge low	559
Staple Cartridge very low	559
Stapler/Stacker staple jam	559
Supplies low	559
SUPPLY MEMORY WARNING	559
The unit has corrupt data	560
Tray <X> empty: [Type], [Size]	560
Tray <X> lifting	561
Tray <X> open	561
Tray <X> overfilled	562
Type mismatch Tray	562
Unsupported drive installed To continue, touch "OK"	563
Unsupported supply in use OR Unsupported supply installed To continue, touch "OK"	563
Unsupported tray configuration	563
Unsupported USB accessory detected Remove USB accessory	564
Upgrade Error	564
USB accessory not functional	564
USB hubs are not fully supported Some operations may not work properly	564
USB is write protected To clear touch "OK"	564
USB needs too much power	565
USB needs too much power Remove USB and Then Turn Off then On	565
USB not initialized	565
USB storage accessory removed Clearing any associated data	565
USB storage device failure To clear touch "OK"	565
USB storage file operation failed To clear touch "OK"	566
USB storage file system is full To clear touch "OK"	566
Used supply installed To continue, touch "OK" OR Used supply in use	566
Waiting for tray <X> to lift	566

Windows Login Required to Use this Feature	566
XX.YY.ZZ Scanner Failure	567
Event-log messages	569
Print an event log	570
View an event log	570
Clear an event log	571
Clear jams	572
Common causes of jams	572
Common causes of jams (no pick 1)	572
Common causes of jams (no pick 2)	574
Common causes of jams (no pick 3)	575
Duplex re-pickup jam 1	577
Feed stay jam 1	578
Fuser output delay jam 1	578
Fuser output delay jam 2	579
Fuser output delay jam 3	580
Fuser output stay jam 1	581
Fuser output stay jam 2	581
Fuser output stationary jam 3	582
Fuser wrap jam 1	582
Residual paper jam 1 / Residual paper jam 2	582
Staple stacker multi-bin mailbox feed delay jam 1	583
Staple stacker multi-bin mailbox feed delay jam 2	583
Staple stacker multi-bin mailbox feed stay jam 1	584
Staple stacker multi-bin mailbox feed stay jam 2	584
Staple stacker multi-bin mailbox feed stay jam 3	584
Staple stacker multi-bin mailbox residual paper jam	585
Jam locations	586
Clear jams in the document feeder	587
Clear paper jams in the stapler (for models with a stapler/stacker)	588
Clear staple jams (for models with a stapler/stacker)	589
Clear jams in the output bin area	592
Clear jams from under the top cover	592
Clear jams in the right door	594
Clear jams in Tray 1	595
Clear jams in Trays 2, 3, 4, or 5	599
Clear jams in the lower right door (Trays 3, 4, or 5)	600
Clear jams in the fuser	601
Clear jams in the registration area	605
Change jam recovery	607
Paper does not feed automatically	608

Product feeds multiple sheets	608
Use manual print modes	609
Solve image-quality problems	611
Print quality examples	611
Clean the product	615
Clean the paper path	615
Clean the scanner glass	615
Solve performance problems	617
Solve connectivity problems	618
Solve direct-connect problems	618
Solve network problems	618
Service mode functions	619
Service menu	619
Product resets	622
Restore factory settings	622
Hard-disk initialization	622
NVRAM initialization	622
Service ID	623
Cold reset	624
Preboot menu options	625
Solve fax problems	632
Is your fax set up correctly?	632
What type of phone line are you using?	632
Are you using a surge-protection device?	632
Are you using a phone company voice-messaging service or an answering machine?	633
Does your phone line have a call-waiting feature?	633
Check fax accessory status	633
Fax feature is not operating	634
General fax problems	634
Problems with receiving faxes	635
Problems with sending faxes	636
Error codes	637
Fax error messages	638
Send-fax messages	639
Receive-fax messages	641
Fax reports	642
Fax activity log	642
Billing code report	643
Blocked fax list report	643
Speed dial list report	643

Fax call report	643
Clear the fax activity log	644
Service settings	644
Settings in the Troubleshooting menu	644
Settings in the Resets menu	644
Firmware upgrades	645
Solve e-mail problems	646
Validate the SMTP gateway address	646
Validate the LDAP gateway address	646
Product updates	647
Determine the installed revision of firmware	647
Perform a firmware upgrade	647
Use the HP Embedded Web Server	647
Use a USB storage device with the preboot menu	648
Use a USB storage device with the Device Maintenance menu	649

4 Parts and diagrams 651

Order parts by authorized service providers	652
Order parts, accessories, and supplies	652
Supplies part numbers	652
Customer-self repair parts	652
Service replacement parts	654
Accessories part numbers	654
Related documentation and software	655
Fasteners used in this product	656
How to use the parts lists and diagrams	658
Assembly locations	659
Base product (no optional trays or accessories)	659
Base product (with optional trays or accessories)	661
Covers (and upper plate assembly)	664
Product base	664
Upper plate assembly	666
Internal components	668
Internal components (1 of 5)	668
Internal components (2 of 5)	670
Internal components (3 of 5)	672
Internal components (4 of 5)	674
Internal components (5 of 5)	676
High-voltage power supply	678
Cassette assembly (Tray 2)	680
Paper pickup assembly	682

Reverse assembly	684
Paper feed roller assembly	686
Registration assembly	688
MP (Tray 1) pickup assembly	690
Duplex assembly	692
Fuser assembly	694
PCAs (product base)	696
Input devices	698
1x500-sheet feeder	698
Covers (1x500)	698
Main body (1x500)	700
1x500/3x500-sheet paper deck	702
Covers (1x500/3x500)	702
Main body (1x500/3x500; 1 of 2)	704
Main body (1x500/3x500; 2 of 2)	706
Output devices	708
Stapler stacker multi-bin mailbox (MBM)	708
Covers (MBM)	708
Main body (MBM)	710
Main body (MBM; 1 of 2)	710
Main body (MBM; 2 of 2)	712
Document feeder and scanner	714
Document feeder (scanner lid)	714
Document feeder (whole unit)	714
Document feeder components (1 of 5)	716
Document feeder components (2 of 5)	718
Document feeder components (3 of 5)	720
Document feeder components (4 of 5)	722
Document feeder components (5 of 5)	724
Scanner assembly	726
Scanner assembly (whole unit)	726
Scanner components (1 of 8)	728
Scanner components (2 of 8)	730
Scanner components (3 of 8)	732
Scanner components (4 of 8)	734
Scanner components (5 of 8)	736
Scanner components (6 of 8)	738
Scanner components (7 of 8)	740
Scanner components (8 of 8)	742
Alphabetical parts list	744
Numerical parts list	756

Appendix A Service and support	767
Hewlett-Packard limited warranty statement	768
HP's Premium Protection Warranty: LaserJet print cartridge limited warranty statement	770
Data stored on the print cartridge	771
End User License Agreement	772
OpenSSL	775
Customer self-repair warranty service	776
Customer support	777
 Appendix B Product specifications	 779
Physical specifications	780
Power consumption, electrical specifications, and acoustic emissions	780
Environmental specifications	780
 Appendix C Regulatory information	 781
FCC regulations	782
Environmental product stewardship program	783
Protecting the environment	783
Ozone production	783
Power consumption	783
Toner consumption	783
Paper use	783
Plastics	783
HP LaserJet print supplies	784
Return and recycling instructions	784
United States and Puerto Rico	784
Multiple returns (more than one cartridge)	784
Single returns	784
Shipping	784
Non-U.S. returns	785
Paper	785
Material restrictions	785
Disposal of waste equipment by users in private households in the European Union	786
Chemical substances	786
Material Safety Data Sheet (MSDS)	786
For more information	786
Declaration of conformity	788
Declaration of conformity (fax models)	790
Certificate of Volatility	792
Types of memory	792

Volatile memory	792
Non-volatile memory	792
Hard-disk-drive memory	792
Safety statements	793
Laser safety	793
Canadian DOC regulations	793
VCCI statement (Japan)	793
Power cord instructions	793
Power cord statement (Japan)	793
EMC statement (China)	794
EMC statement (Korea)	794
EMI statement (Taiwan)	794
Laser statement for Finland	794
GS statement (Germany)	795
Substances Table (China)	795
Restriction on Hazardous Substances statement (Turkey)	796
Additional statements for telecom (fax) products	797
EU Statement for Telecom Operation	797
New Zealand Telecom Statements	797
Additional FCC statement for telecom products (US)	797
Telephone Consumer Protection Act (US)	798
Industry Canada CS-03 requirements	798
Japan Telecom Mark	799
Vietnam Telecom wired marking for ICTQC Type approved products	799
Index	801

For the complete PDF manual
please visit www.LaserPros.com.

