



MOTOROKR[™] EQ7

Quick Start Guide

 **Bluetooth**



Figure 1




Figure 2



Figure 3



Figure 4



European Union Directives Conformance Statement



Hereby, Motorola Inc., declares that this MOTOROKR™ EQ7 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (the R&TTE Directive) at www.motorola.com/rtte.

Caring for the Environment by Recycling



When you see this symbol on a Motorola product, do not dispose the product with household waste.



Recycling Mobile Phones and Accessories

Do not dispose of mobile phones or electrical accessories, such as chargers or headsets, with your household waste. In some countries or regions, collection systems are set up to handle electrical and electronic waste items. Contact your regional authorities for more details. If collection systems aren't available, return unwanted mobile phones or electrical accessories to any Motorola Approved Service Centre in your region.

FCC Notice to Users

Users are not permitted to make changes or modify the device in any way. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. See-47-CFR-Sec.-15.21.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See-47-CFR-Sec.-15.19(3).

Welcome

The **MOTOROKR™** EQ7 High-Performance Bluetooth® Stereo Speaker System lets you enjoy your music with legendary JBL® loudspeaker technology. The EQ7 not only delivers wireless music in rich, full sound and elegant style; it also serves as a speakerphone for phone calls—all at an extended range.

- **Wireless music in premium sound**—Motorola wireless technology coupled with high-bandwidth, low-distortion JBL loudspeakers and acoustic design.
- **Easy to use**—music controls that light up during wireless audio connection, and status indicators for Bluetooth connection, audio mute, and power.
- **True wireless freedom**—take your music with you with the extended wireless range of up to 100m/330ft.*

* Wireless range can vary depending on Bluetooth class of source device, and be subject to interference from obstructions such as walls or other electronic devices.

Before you begin

See figure 1 on page 1

Take a moment before you get started to familiarize yourself with the components of your speaker system.

1. Power Button
2. Power Port
3. Audio Port
4. Battery Compartment (on bottom)
5. Microphone
6. Power Indicator Light
7. Call Button
8. Volume Up Button
9. Forward Button
10. Play/Pause Button (for music)
Microphone Mute Button (for calls)
11. Reverse Button
12. Volume Down Button
13. Microphone Mute Indicator Light
14. Bluetooth Indicator Light

Charge your speaker system

See figure 2 on page 2

You can power your speaker system using:

- the included charger.
- 4 AA alkaline batteries. Remove battery door (by turning to unlock symbol), insert batteries, and reattach battery door (by aligning the triangle on the door with unlock symbol and turning to lock symbol).

Turn it on & off

See figure 3 on page 2

To turn your speaker system on and off, press the Power button on the rear. The Power indicator light is steadily lit when the speaker system is on.

Connect your speaker system

Connect wirelessly

To listen to your music via Bluetooth wireless connection, as well as make and receive handsfree calls, you need to pair (link) your speaker system with your Bluetooth phone and/or music device.

1. Turn off any Bluetooth devices previously paired with your speaker system.
2. Turn on the Bluetooth feature on your Bluetooth phone or music device.
3. Turn on your speaker system.
The Bluetooth indicator flashes to indicate your speaker system is in discoverable mode.
4. Place phone or music device in Bluetooth search mode.
The phone or music device searches for your speaker system.
5. Select **Motorola EQ7** from search results on your phone or music device and confirm pairing following the on-screen instructions.
6. If prompted, enter **0000** passkey.

When your speaker system successfully pairs and connects with your phone or music device, the Bluetooth indicator changes from flashing blue to steadily lit. Music playing from your connected music device source is heard on your speaker system.

After successfully pairing your speaker system and Bluetooth device, you don't need to repeat these steps. For each use, ensure that your speaker system is turned ON and that your device's Bluetooth feature is ON.

Some music devices will automatically attempt to play music when the EQ7 re-connects to it.

Connect wirelessly to 2 devices (multipoint connection)

To connect to phone and music device at the same time:

1. Pair and connect to your phone first (see section “Connect Wirelessly”).
2. Turn off your phone and your speaker system.
3. Turn your speaker system back on. The Bluetooth indicator flashes to indicate the speaker system is in discoverable mode.
4. Turn on your music device. Make sure the Bluetooth feature is turned on in the device. The music device searches for your speaker system.
5. Complete steps 5 & 6 on section “Connect Wirelessly” to pair and connect your music device and speaker system successfully.
6. Turn off your speaker system.
7. Turn your phone back on and make sure the Bluetooth feature is turned on in both the phone and music device.
8. Turn your speaker system back on. It should now connect to both devices.

Connect with a cable

To listen to your music using a wired connection, connect your music device to the Audio port on your speaker system using the included audio cable.

See figure 4 on page 2

Notes:

- The Audio port functions as an input port from a music device only (not as a headphone jack).
- Playback controls provided on your speaker system cannot be used when listening to music input from wired connection.
- In wired connection, if no audio is heard turn up volume on music device.

Control your tunes

See figure 1 on page 1

Playback controls on your speaker system can be used when listening to wireless music streaming from a Bluetooth-enabled music device that also provides remote control capabilities (AVRCP).

When remote control capabilities are not supported by your music device, the EQ7 simply acts as a speaker system, and music should be controlled from your music device.

	Short press —play/pause music Long press —stop music
	Short press —skip to previous track Long press —rewind track*
	Short press —skip to next track Long press —fast-forward track*
 or 	Short or long press —decrease or increase volume**

* If your music player supports this feature


** You'll hear a tone when maximum or minimum volume is reached on your speaker system. The volume setting on your music device may impact volume on your speaker system.

Make and receive handsfree calls

To make and receive calls using the speaker system, a Bluetooth handsfree (HFP) connection must be established with your phone. A handsfree connection with your phone is indicated when the Call button is steadily lit.

Make a call

Using the speaker system to make a call, you can redial the last dialed number or make a voice dial call (if your phone supports this feature). When making a voice dial call, the microphone on the speaker system is enabled, and you hear a prompt from your phone.

	Short press —make a voice dial call (you hear a prompt from your phone) Long press —redial last number
--	---

Receive a call

When there's an incoming call, the Call button flashes on your speaker system, and you hear a ring tone over your speaker system. If wireless streaming music is playing when a call is received, it is paused until the call ends. If music is playing over a wired connection, it is muted when a call is received.

	Short press —answer call
 or 	Long press on either button —reject call

While on a call

When a call is active, the Call and Microphone Mute (Play/Pause) buttons are steadily lit on your speaker system.

 or  **Short or long press**—adjust call volume


 **Short press**—mute call

 **Microphone Mute Indicator**

 **Short press**—end call

When the call is muted, the Microphone Mute indicator light is on.

When there's a second incoming call, the Call button flashes on your speaker system, and you hear an alert.

 **Short press**

1. answer second call (first call is placed on hold),
2. end second call (first call resumes),
3. resume first call on hold (when second caller hangs up)

 or  **Long press (either button)**—reject second incoming call*

* If your phone supports this feature

Additional tips

Pairing

- **To initiate pairing (discoverable) mode manually** when your speaker system is already powered on, press and hold both **Call** and **Play/Pause** buttons at the same time.
- **To clear paired devices list in your speaker system**, press and hold both **Reverse** and **Forward** buttons at the same time until speaker system resets.

Power saving using battery power

When using batteries during Bluetooth connection, if your speaker system is inactive (i.e. detects no audio) for over 5 minutes, it will go into power saving mode and dim the music buttons.

If you have any additional questions, please call your hotline number (0870-9010-555) or visit us at www.hellomoto.com.

motorola.com

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. The Bluetooth trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Motorola, Inc. is under license. © 2007 Motorola, Inc. All rights reserved.