




ANDREW COLLINGE



MODEL NO. AC8TC

INSTRUCTIONS AND WARRANTY

TWIRL AND CURL™
SPIRAL CURLING IRON

IMPORTANT SAFEGUARDS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

KEEP AWAY FROM WATER.

DANGER: As with most electrical appliances, electrical parts are electrically live even when the switch is off.

To reduce the risk of death by electrical shock:

1. Always "unplug it" immediately after using.
2. Do not use while bathing.
3. Do not place or store appliance where it can fall or can be pulled into tub or sink.
4. Do not place in or drop into water or other liquid.
5. If an appliance falls into water, "unplug it" immediately. Do not reach into the water.

Warning: To reduce the risk of burns, electrocution, fire or injury to persons:

1. An appliance should never be left unattended when plugged in.
2. Close supervision is necessary when this appliance is used by, on, or near children or invalids.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Call Consumer Service for examination and repair (see Service and Repair in the Warranty Section).
5. Keep the cord away from hot or heated surfaces. Do not wrap the cord around the appliance.
6. Never use while sleeping or while drowsy.
7. Never drop or insert any object into any opening.
8. Do not use out doors or operate where aerosol (spray) products are being used. Do not operate where oxygen is being administered.
9. This appliance is hot when in use. Do not let eyes and bare skin touch heated surfaces.
10. Do not place the heated appliance directly on any surface while it is hot or plugged in. Use the Stand provided.
11. Do not use an extension cord with appliance.
12. This Curling Iron and Clamp are hot when in use. Do not let eyes and bare skin touch heated surfaces.


13. Do not place the heated Curling Iron directly on any surface while it is hot or plugged in. Use the stand provided.
14. While emitting steam, this Curling Iron may cause burns if it is used too close to the skin, scalp, or eyes, or if it is used incorrectly.
15. To reduce the risk of contact with hot water emitted from steam vents, test Curling Iron before each use by holding it away from body and operating the steam button.
16. Do not operate this appliance with a voltage converter.
17. Before plugging in, read the information about dual voltage contained in the instruction section of this manual.

SAVE THESE INSTRUCTIONS

THIS PRODUCT IS FOR HOUSEHOLD USE ONLY
THIS PRODUCT SHOULD NOT BE USED BY CHILDREN
THE IRON IS NOT A TOY



KEEP AWAY FROM CHILDREN



CAUTION: This product can burn eyes

**Getting To Know
Your TWIRL AND CURL™
Spiral Curling Iron**

**Diagram B
Reservoir
With Plug
(P/N 50432)**






Diagram A



Polarized Plug

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

INSTRUCTIONS FOR USE

DUAL VOLTAGE

This appliance utilizes a positive temperature coefficient (PTC) heating element and operates over a range of voltages.

Confirm the voltage available at each location before using the appliance.

For connection to a 240-volt supply or above, use an attachment plug adaptor (not included) of the proper configuration for the power supply receptacle.

USING THE RESERVOIR

Fill the Reservoir with water before using the Iron

Caution: The Reservoir Plug area is very hot immediately after use. Let it cool down before filling.

To Fill:

1. Turn the Reservoir counterclockwise while pushing it into the Iron, separating it from the rest of the unit. Refer to Diagram C.
2. Remove the Reservoir Plug from the Reservoir by turning and pulling out. Refer to Diagram B.
3. Dampen the felt on the inside of the cap with tap water for 5 - 6 seconds. Be sure to dampen the felt of the cap thoroughly before use. Steam will not flow out well if the felt is dry.

Removal of Reservoir




Diagram C

4. Fill the Reservoir with tap water. Do not use any water other than tap or distilled water, otherwise malfunctioning may result. Wipe off any spilled water before attaching the Reservoir.
5. Insert the Reservoir Plug back into the Reservoir. Align the Plug Tabs between the Reservoir Slots. Push down, twist and secure into place. Refer to Diagram B.
6. Replace the Reservoir inside the top of the Iron. Align the Reservoir Tabs with the slots inside the Iron. Push down and turn clockwise until it stops. Refer to the reverse of Diagram C.

HEATING THE IRON

1. Insert the plug into an AC electrical outlet.
2. Slide the Power Switch to ON indicated by the "1".
3. When the Heat-Ready Dot changes from red to black, the Iron is ready to use. It will take approximately three minutes for the Heat-Ready Dot to change.

- To prepare the Iron for steam, Press the Reservoir down 3-4 times to allow steam to flow through the Iron. The steam may not always be visible under normal conditions of use. If you hear a hissing sound, steam is being released.

Caution: Do not leave the Iron near plastic, easily melted or flammable materials while the Barrel is hot.

USING THE IRON

Use only on dry hair.

For better curl control, it is recommended to add a styling mousse or styling spray to towel dried hair. Thoroughly dry the hair and proceed with curling.

- Comb through hair and loosen any tangles.
- Gather a section of hair 1 inch wide. Make sure that the section is not too thick or hair will not curl properly.
- Press the Lever to raise the Hair Clamp.
- Insert the end of the hair under the Hair Clamp on the side where the arrows are facing. (Diagram D)
- Lower the Hair Clamp to secure the hair against the Barrel.
- Rotate the handle counter-clockwise to wind the hair along the Barrel between the guides. It is easier if you support the Reservoir loosely with the other hand.

- Press the Reservoir to make steam. Thicker hair might need two or three presses.




Diagram D


- Hold the curl in place for about 30 seconds (longer for thicker or naturally curly hair).
- Unwind carefully, raise the Hair Clamp to release the hair, and let the curl cool.

CURLING TECHNIQUE


Before Curling:

Using sections is helpful when curling hair.


- Begin by sectioning off a "U" shape at the top crown of the head and clip.



- Next, section off each side by taking a part from the crown section to the back of the ear and clip. This divides the front side from the back of the head.




- Take the back section and divide that horizontally from ear to ear and clip both sections.
- Within each section take 1-inch vertical sections. Unclip one section at a time.
- Start curling the hair at the back nape of the neck and work your way up the back of the head.



Caution:

Do not rest Iron on skin.

- Once the back is finished, continue on to the sides.
- The crown of the head will be the last to be curled. Divide the crown into 3 vertical sections. It is easiest to take one long 1-inch section from part to part, then divide that into a 1-inch wide section.



STORAGE

After use, slide the Power Switch to OFF indicated by the “0”, unplug from outlet and allow the Heat-Ready Dot to change to red. Once the Iron is completely cooled down, store in a cool dry place. Do not wrap cord around Iron.

CARE AND MAINTENANCE

Once build-up appears on the Iron, the unit will have to be cleaned. Make sure the Iron is off, unplugged and completely cooled down before cleaning.

Remove the Reservoir, take out the Reservoir Plug, and remove any remaining water.

Wipe the Handle, Barrel, and Hair Clamp with a soft damp cloth.

If the Barrel becomes coated with hair product residue, the holes for the steam will become blocked. To prevent this, use a medium to soft brush (an old toothbrush works best) to remove any build-up and clear out the steam holes. After loosening the residue, wipe down with a soft damp cloth.

Allow to dry completely before use.

Do not use harsh abrasives, cleaning agents or solvents.

Do not place Iron in any liquids.

REPLACEMENT PARTS

Replacement parts are available, and may be purchased through our Consumer Relations Department by calling 1-800-934-7455, Mon-Fri. 9am-5pm Central Time, with Visa, Mastercard, Discover, or American Express. Please be ready to give the part number(s) when you call.

Or log into our website to order at: www.eSalton.com

ANDREW COLLINGE Twirl and Curl™ Spiral Curling Iron (AC8TC)

REPLACEMENT PARTS

<u>PART #</u>	<u>DESCRIPTION</u>
50432	Reservoir with Plug

NOTES

LIMITED TWO YEAR WARRANTY

Warranty: This Andrew Collinge product is warranted by Salton, Inc. to be free from defects in materials or workmanship for a period of (2) years from the original purchase date. This product warranty covers only the original consumer purchaser of the product.

Warranty Coverage: This warranty is void if the product has been damaged by accident in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel, normal wear and tear, improper assembly, installation or maintenance abuse or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA, and does not extend to any units which have been used in violation of written instructions furnished with the product or to units which have been altered or modified or to damage to products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

Implied Warranties: ANY IMPLIED WARRANTIES WHICH THE PURCHASER MAY HAVE ARE LIMITED IN DURATION TO TWO (2) YEARS FROM THE DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

Warranty Performance: During the above two-year warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at our option) when the product is returned to the Repair Center, or the purchase price refunded. The repaired or replacement product will be in warranty for the balance of the two-year warranty period and an additional one-month period. No charge will be made for such repair or replacement.

Service and Repair: Should the appliance malfunction, you should first call toll-free 1 (800) 934-7455 between the hours of 9:00 am and 5:00 pm Central Standard Time and ask for CONSUMER SERVICE stating that you are a consumer with a problem. Please refer to model number AC8TC when you call.

In-Warranty Service (USA): For an appliance covered under the warranty period, no charge is made for service or postage. Call for return authorization 1 (800) 934-7455.

Out-of-Warranty Service: A flat rate charge by model is made for out-of-warranty service. Include \$8.00 (U.S.) for return shipping and handling. We will notify you by mail of the amount of the charge for service and require you to pay in advance for the repair or replacement.

For Products Purchased in the USA, but Used in Canada: You may return the product insured, packaged with sufficient protection, and postage and insurance prepaid to the USA address listed below. Please note that all customs duty / brokerage fees, if any, must be paid by you and we will require you to pay the cost of customs duty / brokerage fees to us in advance of our performing any service.

Risk During Shipment: We cannot assume responsibility for loss or damage during incoming shipment. For your protection, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following items with your appliance: any accessories related to your problem, your full return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

To return the appliance, ship to:

ATTN: Repair Center
Salton, Inc.
708 South Missouri Street
Macon, MO 63552

To contact us, please write to, call, or email:

Salton, Inc.
P.O. Box 1637
Columbia, MO 65205-7366
1 (800) 934-7455
E-mail: Salton@Saltonusa.com

Limitation of Remedies: No representative or person is authorized to assume for Salton, Inc. any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract. Repair, replacement or refund shall be the sole remedy of the purchaser under this warranty, and **in no event shall Salton be liable for any incidental or consequential damages, losses or expenses.** Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Legal Rights: This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For more information on Salton products: visit our website: www.eSalton.com

©2003 Salton, Inc. All rights reserved.
Made in China

P/N 61093A
Printed in China