




CRP - 913

INSTRUCTION MANUAL
BRUKSANVISNING
BETJENINGSVEJLEDNING
BEDIENUNGSANLEITUNG
MANUAL DE INSTRUCCIONES
INSTRUCCIONES DE USO
INSTRUZIONI PER L'USO
KÄ Y T T Ö H J E T
M O D E D ' E M P L O I
GEBRUIKSAANWIJZING

www.denver-electronics.com

1. ON/OFF/AUTO 13. TUNING CONTROL
2. LED DISPLAY 14. BATTERY BACK-UP
3. AUTO INDICATOR 15. FM ANTENNA WIRE
4. SNOOZE/SLEEP OFF 16. AC POWER CORD
5. ALARM (vacker) 17. POINTERS
6. TIME SET 18. PROJECTION ON/OFF
7. SLEEP SET 19. PROJECTION
8. HOUR/MINUTE INDICATOR 20. TIME SET/TIME FOR PROJECTION
9. MINUTE SET 21. HOUR FOR PROJECTION
10. MINUTE SET 22. MINUTE BUTTON FOR PROJECTION
11. VOLUME CONTROL / BUZZ 23. FOCUS ADJUSTMENT
12. WAVE BAND



AC POWER OPERATION
Before connecting to the power supply ensure that the supply corresponds to the information on the rating label on the bottom of the apparatus.