

Quick Start Guide

VIAMOTO™

Rel. 3.0 for i860



Press to Toggle between Turn-by-Turn screen and Map (while in guidance mode)



featuring **NAVTEQ**
Digital Mapping



MOTOROLA

intelligence everywhere™

For more information, visit www.viamoto.com

Setting up Device

To effectively use *VIAMOTO*™ in your vehicle, you should:

- Change phone settings for best in-vehicle use before you first run *VIAMOTO*™
- Place your phone as close to the windshield as possible
- Power your phone from the vehicle



USEFUL ACCESSORIES

Vehicle Power Charger -
NNTN5165
Available at www.nextel.com
or Nextel retail store



Phone Holder – 848957 or 841957
Available at www.proclipusa.com or
1- 800-296-3212

Launching *VIAMOTO*™

- Press and hold power button.
- Press the *Menu* button and locate the *Java Apps* icon.
- Highlight *JAVA* icon and press the *OK* button.
- Highlight *GO* icon and press the *OK* button.
- Review User Consent and press button under *ACCEPT*, if acceptable.

User Consent

Laws in some areas prohibit the use of a cellular phone when driving a motor vehicle. It is the responsibility of each cellular phone user to be aware of and abide by any and all local laws and ordinances, which may restrict the use of cellular phones. The user must take the utmost care in using a cellular phone safely under all circumstances. Traffic laws and current traffic conditions must always be observed and take precedence over the instructions issued by the navigation system. The user should be aware of situations where current traffic conditions and the instructions from the navigation system may be in conflict. The use of the navigation system does not relieve the user of his/her responsibilities. The user is ultimately responsible for the vehicle under his/her control and should be aware of the surroundings at all times. For traffic safety reasons, it is recommended that routes should be set-up in a stationary vehicle before starting a trip. Privacy: Operation of the navigation system requires that the user's position be sent to a central server for use in preparing the route information. This information will only be used to provide the navigation service and will not be shared with any third parties. A user who wishes to keep their current location private should not use the navigation system. Motorola is not responsible for any financial loss, or other incidental or consequential damage arising out of the use of, or inability to use, this product. This includes damage to property and, to the extent permitted by law, damages for personal injury and death. If after reading these statements you decide not to accept these terms, you should not use the *VIAMOTO*™ service.

Choosing a Destination

Select Existing Address Book Entry:

- On *VIAMOTO* screen, highlight *Use Address Book* and press button under *SELECT*.
- On Address Book screen, highlight an address and press button under *SELECT*.
- Press button under *GO* to begin automatic voice guidance.
To add addresses to your address book online, go to www.viamoto.com.

Enter Address Using Keypad:

- On *VIAMOTO* screen, highlight *Use Address Book* and press button under *SELECT*.
- On Address Book screen, highlight *New Address* and press button under *SELECT*.
- If you know the zip code, press button under *OK* and type the zip code. Press button under *OK* and verify state and city. If you do not know the zip code, select *City, State* and use keypad to type the state and city.
- Press button under *OK*.
- Use keypad to type street address. Press button under *OK*.
- Add name to save the address to your address book.
- Press button under *SELECT*.
- Press button under *GO* to begin automatic voice guidance.

To enter letters press the key multiple times to display each letter.

Search Directory for Nearby Dining, Lodging, etc.:

- On *VIAMOTO* screen, highlight *Search Directory* and press button under *SELECT*.
- Highlight a category or select *SEARCH ALL* and press button under *FIND*.
- Type a partial business name or leave blank to show all results.
- Press button under *FIND*.
*To find a listing near another location, press button under *SKIP* and select an alternate starting location for your search.*
- Highlight the destination and press button under *SELECT* to display directions.
- Press button under *GO* to begin voice route guidance.
To customize list of directory categories, go to www.viamoto.com.

*VIAMOTO will advise you when you have left the route. Press button under *REROUTE* to get a new route.*

GPS needs open sky to receive signals. Buildings, trees, and garages block reception. When possible, plan your route under open sky.

For user guides on installing and using *VIAMOTO*™, go to www.viamoto.com/downloads.