



ΕN

CUSTOMER SERVICE CONTACTS

5870

Fax +358 9 87587301

Suunto USA Phone 1 (800) 543-9124

Canada Phone 1 (800) 776-7770

European Call Center Phone +358 2 284 11 60

Suunto Website <u>www.suunto.com</u>

TABLE OF CONTENTS

1. GETTING STARTED WITH SUUNTO G6

1.1. Getting familiar with Suunto G6



Using modes and menus



TIP

Press and long press

long press

Key lock


Time



1.2. First steps with Suunto G6

Time

Time



1.3. Wearing Suunto G6

2. IMPROVING YOUR SWING (PRACTICE MODE)

Swing information





TIP

2.1. Starting practice

Practice

TIP

Good Bad

Bad

Erase



TIP

2.2. Ending a practice session

Quit

Practice summary

Session details

Variation

Average Deviation for tempo, rhythm, back swing and length:

individual swings



TIP

Stats


Memory

3. USING SUUNTO G6 DURING A GAME (GAME MODE)



3.1. Playing the game Starting the game

Game





Erasing statistics

Erase

Quitting the game or a hole

Quit game

Viewing swing information during a game



Memory

Swing log Memory

ALL OPENINGS MANUAL



TIP

3.2. Playing different game types Playing Scratch

Playing Stroke



- Hole in 1
- Albatr
- Eagle
- Birdie
- Par
- Bogey
- D bogey
- T bogey

Playing Stableford



Stats TIP

4. TESTING SWING CONSISTENCY (TEST MODE)

consistency index

4.1. Starting the test

Test

Improving your swing



TIP

Quit Restart

4.2. Analyzing test results

Consistency index

- Variation
- · Best test

Viewing test statistics

Stats Memory

5. CUSTOMIZING SUUNTO G6

5.1. Default settings



NOTE

5.2. Changing general preferences

Time

Alarm Time

Date General



Time

Units

5.3. Creating a course

Course Create Memory



TIP

5.4. Player details

Players

Memory



TIP

6. USING STOPWATCH AND SETTING ALARMS

6.1. Using the stopwatch

Time





6.2. Setting an alarm

Time Alarm On

7. SUUNTO GOLF MANAGER



NOTE:

Connecting Suunto G6 to the Suunto Golf Manager

Connect/Refresh
NOTE:



Suunto Golf Manager Features

8. SUUNTOSPORTS.COM

Getting started with suuntosports.com

Register



NOTE:

MySuunto

Communities

Sort-specific pages

9. CARE AND MAINTENANCE

Care of the Suunto G6

9.1. Water Resistance



NOTE:

9.2. Replacing the battery



NOTE:



NOTE:

NOTE:

under the metal flap

Q

NOTE:



NOTE:

WARNING:





10. DEFINITIONS AND CALCULATION RULES

Backswing length Consistency index

Course handicap (Course HCP)

Course Rating (C.R.)

Fairway hit (FIR)

Green in Regulation (GIR)

Handicap index

Index

Match play score

Rhythm

Stableford score





Slope rating Speed Strokeplay score

Tempo

Up and down

11. TROUBLESHOOTING

BATTERY LOW / DISABLED, BATTERY LOW

HOLE XX MEMORY FULL

INVALID UP&DOWN MEMORY FULL

Memory

NO COURSES IN MEMORY

NOTHING TO ERASE SWING MEMORY FULL

SWING SESSIONS FULL

Memory

12. TECHNICAL SPECIFICATIONS


13. TERMS AND CONDITIONS

Copyright

Trademarks

CE compliance

ISO 9001 compliance



14. LIMITS OF LIABILITY

SUUNTO

Wristop Computers

TWO YEAR WARRANTY

This product is warranted to be free of defects in material and/or workmanship to the original owner for the above noted period (does not include battery life). Keep a copy of the original purchase receipt and make the place of purchase. The warranty sure to get this warranty card stamped at originates from the date of purchase.

All warranties are limited and are subject to the restrictions given in the instruction manual. This warranty does not cover the to the product resulting from neglect of care, alteration, improper battery improper usage, improper maintenance, replacement or unauthorized repair. damage

Model of	Serial
Wristop computer:	number:
Date of purchase	
Place of purchase/Store name	
Store CityStore	Store Country
Store stamp with date of purchase	Se
Name ————————————————————————————————————	
Address	
CityCountry	У
TelephoneE-mail.	
Signature	

www.suunto.com