


For Models: KFRS365TSS00

(Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GRILL PARTS


For Models: KFRS365TSS00
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	21	W10128636	Bracket, Warming Rack	47	W10128767	Igniter, Main Gas
	W10110725	Use & Care Guide				48	W10137057	Manifold
	W10110730	Conversion Instr. (LP to Natural)	22	W10128637	Cover, Access Panel	49	W10137063	Baffle, Front
2	W10128611	Rack, Warming	23	W10128638	Clip, Wire	50		Electrode
3	W10136417	Grate, Large	24	W10136420	Hood Assy		W10128770	Main Burner
4	W10128616	Grate, Small	25	W10128640	Hole Plug		W10136434	Main Burner
5	W10128618	Plate, Sear	26	W10137047	Panel, Side Left	51	W10128771	Side Panel, Right
6	W10128619	Cover, Rear	27	W10128644	Bracket, Grease Tray (Right)	54	W10128775	Burner, Main
7	W10128620	Panel, Rear				55	W10128776	Bracket, Main Brnr
8	W10128621	Electrode, Rear Burner	28	W10128655	Roller, Drip Tray	56	W10128777	Thermometer
9	W10128622	Thermocouple, Rear, Burner	29	W10128656	Drip Tray Assy (Includes Rollers)	57	W10128779	Bezel, Thermometer
10	W10128623	Flex Tube, Rear Burner	30	W11286570	Bracket, Grease Tray (Left)	58	W10128780	Insulator, Thermometer(Small)
11	W10128624	Burner, Rear	31	W10137048	Shelf, Side (Lf)	59	W10128782	Insulator, Thermometer(Large)
12	W10128625	Bracket, Rear Thermocouple	32	W10137052	Bracket, Handle	60	W10128783	Handle, Hood
13	W10128626	Cover, Rear Thermocouple	33	W10128660	Handle, Shelf	61	W10128785	Endcap, Handle (Left)
14	W10137046	Orifice, Rear Burner	34	W10137053	Bar, Tool	62	W10128786	Spacer, Handle
15	W10128628	Light, Grill	35	W10128663	Harness, Wire Light	63	W10128787	Endcap, Handle (Right)
16	W10136418	Light, Grill (Set)	36	W10137054	Cover, Igniter	64	W10128788	Hinge, Lid
17	W10128631	Socket, Light	37	W10137055	Igniter	65	W10128789	Hood
18	W10128632	Panel, Access	38	W10128751	Nameplate	66	W10137049	Panel, Control
19	W10128634	Bracket, Panel Left	39	W10128753	Knob, Main Burner	67	W10137051	Tray, Condiment
20	W10128635	Bracket, Panel Right	40	W10128756	Knob, Rear Burner	68	W10137067	Bracket, Sear Brnr
			41	W10128759	Bezel, Knob	69	W10137071	Burner, Sear
			42	W10128761	Switch, Light	70	W10137068	Screen, Sear Brnr
			43	W10137056	Panel, Control	71	W10137069	Rod, Connecting
			44	W10128763	Harness, Wire Control	72	W10137070	Panel, Sear Brnr
			45	W10128764	Valve, Main Brnr	73	W10137072	Ignitor, Sear Brnr
			46	W10128766	Valve, Rear Brnr			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BASE PARTS

For Models: KFRS365TSS00
(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	W10128666	Ring, Rubber
2	W10128667	Box, Transformer
3	W10128668	Cover, Transformr Box
4	W10128669	Transformer
5	W10128670	Clamp, Wire
6	W10136421	Panel, Rear
7	W10128672	Caster
8	W10136424	Panel, Bottom
9	W10128674	Bracket, Tank Tray (Right)
10	W10128675	Bracket, Tank Tray (Left)
11	W10128676	Slide, Tank Tray
12	W10128677	Bolt, Tank


Illus. No.	Part No.	DESCRIPTION
13	W10128678	Tray, Tank
14	W10128679	Lock, Tank Tray
15	W10128680	Handle, Tank Tray
16	W10128681	Bracket, Towel Rack
17	W10128686	Rack, Towel
18	W10136429	Tray, Condiment
19	W10136430	Door, Left
20	W10128696	Hole Plug
21	W10128697	Magnet, Door
22	W10136431	Door, Right
23	W10128703	Bag, Lighting Rod
24	W10128704	Rod, Lighting
25	W10128705	Caster, W/Brake
26	W10136432	Panel, Side Assy

Illus. No.	Part No.	DESCRIPTION
27	W10128711	Cover, Battery Box
28	W10128715	Box, Battery
29	W10128719	Case, Battery Box
30	W10128746	Regulator
31	W10128747	Fixture, Manifold
32	W10128748	Connector (Brass)
33	W10128749	Base, Manifold Fixture
34	W10128750	Commutator, Manifold
35	W10128661	Handle, Door
36	W10128659	Bracket, Handle
37	W10136427	Rack, Storage


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SIDE BURNER PARTS

For Models: KFRS365TSS00
(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	W10137073	Grate, Side Burner
2	W10137074	Wire, Side Burner
3	W10137075	Shelf, Side Burner
4	W10137084	Tube, Side Burner
5	W10137076	Burner, Side
6	W10137052	Bracket, Handle
7	W10138660	Handle, Shelf
8	W10137077	Panel, Control
9	W10128764	Valve, Burner
10	W10128753	Knob, Burner
11	W10137078	Manifold, Side Brn
11	W10137078	Manifold, Sd Brnr
12	W10137080	Hose, Side Burner
13	W10137089	Chain, Lid
14	W10137088	Stator, Chain
15	W10137087	Lid, Side Burner
16	W10137053	Bar, Tool
17	W10137079	Hook



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KFRS365TSS00
(Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

Miscellaneous

4396540	Altitude 2K-5K LP
4396541	Altitude 5K-8K LP
4396542	Altitude 8K-10K LP
4396544	Altitude 2K-5K NG
4396545	Altitude 5K-8K NG
4396546	Altitude 8K-10K NG
W10118099	Conv.Kit (NG-LP)
W10118098	Conv.Kit(LP-NG)
	Smoker Box
KFKU361TSS	36" Rotiss. Kit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST