







Dual Band soft-key 6788 Telephone Quick Reference Card

Answer a Call	Open the phone or Press the  key.	Save Numbers in Phonebook	<ol style="list-style-type: none"> 1. Enter the number. 2. Press the Save soft key. 3. Select an icon for label. 4. Press the Selected soft key. 5. Enter the name. 6. Press the OK soft key. 7. If necessary, change the memory. 8. Press the  key to return to Standmode.
Adjust the Volume	Press the  or  key on the left side of the phone.	Search for a Number in Phonebook	<ol style="list-style-type: none"> 1. Press the  key. 2. Select the Search option. 3. Enter the first few letters of the name. 4. To scroll through the names, press the Up or Down key. 5. Press the View soft key. 6. To scroll through the numbers, press the Up or Down key. 7. Press the  key to dial.
Choose the Alert Type	<ol style="list-style-type: none"> 1. Select the Alert Type menu option (Menu 3.3). 2. Select an option: <ul style="list-style-type: none"> • Light Only • Melody • Vibration • Vibrate+Melody 3. Press the Select soft key. 		
Switching the Microphone Off or On during a Call	<ol style="list-style-type: none"> 1. Press the Options soft key. 2. Highlight Mute or Unmute. 3. Press the Select soft key. 		

Press and hold the  key.	<ol style="list-style-type: none"> 1. Key in the number. 2. Press the  key.
Switch On/Off	Press the  key.
Make a Call	Press the  key.
End a Call	Press the  key.
View Missed Calls Immediately After Missing Them	<ol style="list-style-type: none"> 1. Open the phone and press the View soft key. 2. Scroll with the Up and Down keys through the missed calls. 3. To return the call, press the  key.

Access the Menu Functions	<ol style="list-style-type: none"> 1. Press the Menu soft key. 2. Scroll with the Up and Down keys through the list of the menus until you reach the required menu. 3. Press the Select soft key. 4. Scroll with the Up and Down keys through the list of the options until the required one is selected. 5. Press the Select soft key.
Each of the two soft keys  and  perform the function indicated by the text above it, on the bottom line of the display.	