

# TR-5500HRS TREADMILL


GK36-00006-XXXX  
SN: HTE266037-HTE273953

## Display Console

AK36-00049-0001(R) Eng/Eng - R&R only  
AK36-00049-0002(R) Ger/Met - R&R only  
AK36-00049-0004(R) Frn/Met - R&R only  
AK36-00049-0005(R) Spn/Met - R&R only  
AK36-00049-0006(R) Itl/Met - R&R only  
AK36-00049-0007(R) Jap/Met - R&R only  
AK36-00049-0009(R) Dut/Met - R&R only


## Overlay Bezel

AK36-00050-0001 Eng/Eng  
AK36-00050-0002 Ger/Met - NLA  
AK36-00050-0004 Frn/Met - NLA  
AK36-00050-0005 Spn/Met - NLA  
AK36-00050-0006 Itl/Met - NLA  
AK36-00050-0007 Jap/Met - NLA  
AK36-00050-0009 Dut/Met - NLA



TR-5500HRS  
TREADMILL

GK36-00006-XXXX  
SN: HTE 266037-HTE 273953




TR-5500HRS  
TREADMILL

GK36-00006-XXXX  
SN: HTE 266037-HTE 273953

Lift Actuator  
120v/60Hz  
OK36-01012-0004  
220v  
OK36-01012-0003  
Lift Pin Kit  
GK45-00002-0009

Heatsink  
SK36-00061-0000(R)  
120v/60Hz  
AK36-00061-0001  
220v

Not Shown:  
Home Switch  
0017-00032-0178  
Home Switch Cable  
AK36-00025-0000



On/Off Switch  
AK40-00052-0000

Line Cord  
AK36-00013-0000  
Foreign  
AK36-00013-0001  
220v/60Hz  
AK36-00042-0000

Front Panel  
OK36-01013-0001