











Samsung SGH-E310 GPRS Telephone Quick Reference Card


- Access the Menu Functions
- 1 Press the Centre key to enter Menu mode.
 - 2 Scroll using the Navigation keys through the list of the menus until you reach the menu you want.
 - 3 Press the **Select** soft key.
 - 4 Scroll using the Up and Down keys through the list of the options until the one you want is selected.
 - 5 Press the **Select** soft key.

Each of the two soft keys ( and ) performs the function indicated by the text above it, on the bottom line of the display.

Switch On/Off	Press and hold the  key.
Make a Call	<ol style="list-style-type: none"> 1 Enter the number. 2 Press the  key.
End a Call	Briefly press the  key.
View Missed Calls Immediately After Missing Them	<ol style="list-style-type: none"> 1 Open the phone and press the View soft key. 2 Scroll using the Up and Down keys through the missed calls. 3 To return the call, press the  key.
Answer a Call	Open the phone or Press the  key.
Adjust the Volume	Press the  or  key on the left side of the phone.



Choose the Alert Type	<ol style="list-style-type: none"> ① Select the Alert type menu (Menu 9.3.3). ② Select an option: <ul style="list-style-type: none"> • Light only • Melody • Vibration • Vibration+melody ③ Press the Select soft key.
Store Numbers in Contacts	<ol style="list-style-type: none"> ① Enter the number and press the Save soft key. ② Select an icon. ③ Press the Select soft key. ④ Select a memory. ⑤ Press the Select soft key. ⑥ Enter the name. ⑦ Press the OK soft key. ⑧ If necessary, change the location number. ⑨ Press the OK soft key. ⑩ Press the  key to return to Idle mode.

Search for a Number in Contacts	<ol style="list-style-type: none"> ① Select the Contacts list menu (Menu 8.1). ② Enter the first few letters of the name. ③ To scroll through the names, press the Up or Down key. ④ Press the View soft key. ⑤ To scroll through the numbers, press the Up or Down key. ⑥ Press the  key to dial.
Take a Photo	<ul style="list-style-type: none"> • With the phone open <ol style="list-style-type: none"> ① Press and hold the Camera key. ② Press the Camera key. ③ Press the Save soft key. <ul style="list-style-type: none"> • With the phone closed <ol style="list-style-type: none"> ① Press and hold the Camera key. ② Press the Camera key.