



PARTS GUIDE



Using the Parts Guide below, check to make sure all parts are included in the box.
If parts are missing or damaged call 1-888-830-1326.
PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE.

Before installing your fan, record the following information for your records and warranty assistance.

Fan Parts (Not Drawn to Scale)





Model Name _____
 Catalog No. _____
 Serial No. _____
 Date Purchased _____
 Where Purchased _____

Missing / Broken Parts:
Call 1-888-830-1326

- Fan does not work:**
1. Reference the Trouble Shooting guide in your Instruction Manual.
 2. Call your Local Service Center.
 3. Call Technical Support at 901-248-2222.

For additional information on:
 Hunter Products • Trouble Shooting
 Dealer Location • Service Center Locator
 Call 1-800-448-6837
www.hunterfan.com

Hardware (Drawn to Scale)



HUNTER Hunter Fan Company
 2500 Frisco Avenue
 Memphis, TN 38114
www.hunterfan.com

Parts List

Item #	Item Name	Qty	Model #	28010	28016
			Asm. Dwg. #	93139-01	93139-02
			Finish	Antique Brass	White
Item #	Item Name	Qty	Part #	Part #	Part #
1	Canopy Assembly	1	93414-00-800	93414-00-801	
2	* Hanger Bracket Assembly	1	74090-02-000	74090-02-000	
3	* Canopy	1	92697-01-121	92697-01-132	
7	Hanger Pipe Assembly	1	63722-02-000	63722-06-000	
10	Motor/Housing Assembly	1	93139-00-850	93139-00-851	
11	Hanger Adaptor	1	83783-01-119	83783-01-132	
12	* Screw, Set	2	03009-01-000	03009-01-000	
16	Housing, Top	1	92815-04-121	92815-04-132	
19	Cover, Bottom	1	92318-01-121	92318-01-132	
20	Motor Assembly	1	84169-07-000	84169-07-000	
23	* Switch Housing Mounting Plate	1	64156-01-000	64156-01-000	
24	* Screw, 6-32, 100 Degrees Countersink	4	63725-02-232	63725-02-133	
25	* Nut, Acorn	4	03493-01-232	03493-01-133	
26	* Screw, Machine	3	74508-36-232	74508-36-133	
29	* Switch Housing Cover	1	73450-01-121	73450-01-132	
30	* Switch Housing, Upper	1	83227-04-121	83227-04-132	
34	* Capacitor, Start	1	74132-01-000	74132-01-000	
35	* Capacitor, Run	1	74133-01-000	74133-01-000	
36	* Switch, Fan Speed Pull Chain	1	63784-01-000	63784-02-000	
37	* Switch, Reverse Assembly	1	63782-01-000	63782-02-000	
38	* Break Away Connector	1	73384-01-000	73384-01-000	
40	* Housing Cover Screw	2	74506-05-232	74506-05-133	
47	Screw, Blade Iron Armature	11	63755-01-000	63755-01-000	
129	* Washer, Switch Housing Mounting Plate	1	64155-01-000	64155-01-000	
44	Blade Iron Set	1	73461-28-000	73461-22-000	
46	Blade Set	1	73922-04-000	73922-03-000	
49	Light Kit Assembly	1	93022-30-000	93022-31-000	
60	* Hardware Kit	1	93061-00-860	93061-00-861	
61	Washer, Installers Choice	1	73788-01-000	73788-01-000	
62	Screw, Canopy	3	74510-04-232	74510-04-132	
63	Screw, LP Washer	3	74508-06-232	74508-06-232	
64	Screw, Wood	2	06512-01-000	06512-01-000	
65	Screw, Wood	2	03144-03-000	03144-03-000	
66	Grommet, Blade	16	05989-01-000	05989-02-000	
67	Screw, Blade Assembly	16	63730-01-000	63730-01-000	
68	Washer, Flat	4	06301-01-000	06301-01-000	
70	Wire Nut	4	05172-01-000	05172-01-000	
71	Mounting Isolator	2	74135-01-000	74135-01-000	
74	Light Kit Adapter	1	63688-01-121	63688-01-132	
75	* Balancing Kit	1	07570-01-000	07570-01-000	
83	Remote Control Assembly	1	64138-01-000	64138-01-000	
89	* Remote Control Sack Parts	1	64125-01-000	64125-01-000	
91	* Parts Guide	1	98000-01-033	98000-01-033	
101	* Owners Manual (English)	1	41353-01-000	41353-01-000	
102	* Owners Manual (Spanish)	1	41353-02-000	41353-02-000	
120	* Site Prep Guide (English)	1	41278-01-000	41278-01-000	
121	* Site Prep Guide (Spanish)	1	41278-02-000	41278-02-000	
150	Globe/Shade	1	74288-01-000	74288-01-000	
155	* Silencer Band	4	07538-01-000	07538-01-000	

* Items Not Shown

GUÍA DE PIEZAS

98000-01-033

10/25/2000




Use la Gua de Piezas de abajo para verificar que todas las piezas estn incluidas en la caja.

Si alguna pieza falta o est daada, llame al telefono 1-888-830-1326.

POR FAVOR NO DEVUELVA ESTE PRODUCTO A LA TIENDA DONDE LO COMPR.

Antes de instalar su ventilador, anote la informacin siguiente para sus archivos y asistencia con la garanta.

Piezas del ventilador (no dibujadas a escala)



Nombre del modelo _____

No. de catlogo _____

No. de serie _____

Fecha de compra _____


Lugar donde se compr _____

Si alguna pieza falta o est rota:
Llame al telefono 1-888-830-1326


Si el ventilador no funciona:
1. Consulte la gua de localizacin de fallas en su manual de instrucciones.
2. Llame a su centro local de servicio.
3. Llame al telefono 901-248-2222 para obtener asistencia tcnica.

Para informaciones adicionales acerca de:
Productos Hunter • Localizacin de fallas
Localizacin de distribuidores
Localizacin de centros de servicio
Llame al telefono 1-800-448-6837
www.hunterfan.com

Herrajes (dibujados a escala)



PARA USO POR LOS CENTROS AUTORIZADOS DE SERVICIO DE HUNTER SOLAMENTE



Lista de piezas

No. del ítem	Nombre del ítem	Cantidad	No. del modelo	28010	28016
			No. del dibujo de ensamblaje	93139-01	93139-02
			Acabado	Bronce antiguo	Blanco
No. del ítem	Nombre del ítem	Cantidad	No. de la pieza	No. de la pieza	No. de la pieza
1	Conjunto de la campana	1	93414-00-800	93414-00-801	
2	* Conjunto del brazo de suspensin	1	74090-02-000	74090-02-000	
3	* Campana	1	92697-01-121	92697-01-132	
7	Conjunto del tubo de suspensin	1	63722-02-000	63722-06-000	
10	Conjunto del motor y caja	1	93139-00-850	93139-00-851	
11	Adaptador de suspensin	1	83783-01-119	83783-01-132	
12	* Tornillo prisionero	2	03009-01-000	03009-01-000	
16	Parte superior de la caja	1	92815-04-121	92815-04-132	
19	Parte inferior de la cubierta	1	92318-01-121	92318-01-132	
20	Conjunto del motor	1	84169-07-000	84169-07-000	
23	* Placa de montaje de la caja del interruptor	1	64156-01-000	64156-01-000	
24	* Tornillo 6-32 con avellanado de 100	4	63725-02-232	63725-02-133	
25	* Tuerca de bellota	4	03493-01-232	03493-01-133	
26	* Tornillo de máquina	3	74508-36-232	74508-36-133	
29	* Cubierta de la caja del interruptor	1	73450-01-121	73450-01-132	
30	* Parte superior de la caja del interruptor	1	83227-04-121	83227-04-132	
34	* Condensador de arranque	1	74132-01-000	74132-01-000	
35	* Condensador de operacin	1	74133-01-000	74133-01-000	
36	* Interruptor de cadena del ventilador	1	63784-01-000	63784-02-000	
37	* Conjunto del interruptor de inversin de rotacin	1	63782-01-000	63782-02-000	
38	* Conector de separacin rápida	1	73384-01-000	73384-01-000	
40	* Tornillo de la cubierta de la caja	2	74506-05-232	74506-05-133	
47	Tornillo para los herrajes de las paletas	11	63755-01-000	63755-01-000	
129	* Arandela de montaje de la caja del interruptor	1	64155-01-000	64155-01-000	
44	Juego de herrajes para la paletas	1	73461-28-000	73461-22-000	
46	Juego de paletas	1	73922-04-000	73922-03-000	
49	Conjunto de luces	1	93022-30-000	93022-31-000	
60	* Juego de herrajes	1	93061-00-860	93061-00-861	
61	Arandela de opcin del instalador	1	73788-01-000	73788-01-000	
62	Tornillo de la campana	3	74510-04-232	74510-04-132	
63	Tornillos con arandela LP	3	74508-06-232	74508-06-232	
64	Tornillo para madera	2	06512-01-000	06512-01-000	
65	Tornillo para madera	2	03144-03-000	03144-03-000	
66	Ojal de la paleta	16	05989-01-000	05989-02-000	
67	Tornillo de tope	16	63730-01-000	63730-01-000	
68	Arandela plana	4	06301-01-000	06301-01-000	
70	Tuerca para alambre	4	05172-01-000	05172-01-000	
71	Aislador de montaje	2	74135-01-000	74135-01-000	
74	Adaptador del conjunto de luces	1	63688-01-121	63688-01-132	
75	* Juego equilibrador	1	07570-01-000	07570-01-000	
83	Conjunto del control remoto	1	64138-01-000	64138-01-000	
89	* Bolsa de piezas del control remoto	1	64125-01-000	64125-01-000	
91	* Guía de piezas	1	98000-01-033	98000-01-033	
101	* Manual del propietario (Ingleses)	1	41353-01-000	41353-01-000	
102	* Manual del propietario (Español)	1	41353-02-000	41353-02-000	
120	* Guía de preparacin del sitio (Ingleses)	1	41278-01-000	41278-01-000	
121	* Guía de preparacin del sitio (Español)	1	41278-02-000	41278-02-000	
150	Globo / Pantalla	1	74288-01-000	74288-01-000	
155	* Banda silenciadora	4	07538-01-000	07538-01-000	

* ítems no mostrados