
Tanaka.

Parts Catalog

String Trimmer

Model TBC-2800

03-01-95




POWERHEAD ASSEMBLY

ITEM	STK.	PART		UNITS)ED
NO.	CODE	NUMBER	DES		SY.
1	Α.	224044		Spring, Muffler	1
2	Α	300628		Kit, Muffler	- 1
3	Α	224040		. Screen, Spark Arrester	1
4	В	322032		Cover, Spark Arrester	1
5	В	111072		Screw, 8-18 x .31 PN HD TORX	1
6	Α	224228		. Gasket, Muffler	1
7	Α	224922		. Gasket, Exhaust Port	1
8	Α	111055		Screw, 10-14 x .625 Plastite	2
9	₿	322478		Label, Choke(Horizontal)	1
10	Α	224236		Cover, Air Cleaner-Large(8ik)	1
11	Α	224239		Filter, Air	1
12	Α	111058		Nut, 10-24 Flange / Hex	2
13	Α	224238		Box, Air (Blk)	1
14	Α	224242-01		Primer, Remote	1
15	Α	225163		Hose, Fuel Return	1
16		FIGURE 3		CARBURETOR W/CHOKE	- i l
17	Α	218933		Gasket, Carburetor	- 1 1
18	Α	224041		Manifold, Carburetor	1
19	Α	111053		Screw, 10-24 x .88	2
20	В	111057		Screw, 10-24 SPL	2
21	Α	322031		Gasket, Manifold	1
22	В	300871		Kit, Fuel Tank / Cap (Blk)	1
23	Α	300869		. Filter, Fuel	1
24	Α	225162		. Hose, Fuel	1
25	Α	225163		. Hose, Fuel Return	1
26	Α	300700		. Kit, Fuel Cap/Decal	1
27	В	211242		Decal, (OPEN SLOWLY)	1
28	С	322250		Decal, Fuel Cap	1
29	Α	322105		Isolator, Fuel Tank	4
30	Α	300827		Kit, Flywheel	1
31	Α	301019		. Kit, Pawls	1
32	Α	111090		Screw, Starter Pawl 12-24 L.H.	2
33	Α	322320		Pawl, Starter	
34	Α	93469		Washer, Starter Pawi	2 2 2
35	Α	223339		Spring, Starter Pawl	2
36	В	322847		. Nut, Hex	1
37	Α	111085	①	. Nut	1
38	C	301114		Kit, Clutch Spacer	1
39	Α	322844		. Washer, Shaft	1
40	В	322847		. Nut, Hex	1

ITEM	ITEM STK. PART UNITS PER					
NO.	CODE	NUMBER		IŞY.		
41	Α	102164	Key, Flywheel	1		
42	Α	111053	Screw, 10-24 x .88 THD Form	2		
43	В	300321	Terminal Tab	1		
44	Α	219848-01	fgnition Assembly	1		
45	Α	223884	. Kit, Spark Plug Wire	1		
46	Α	102556	Connector, Spark	1		
47	Α	95266	Boot, Spark Plug	1		
48	Α	215533-01	① Grommet, H/T Lead	1		
49	Α	110995	Grommet, S/Plug Wire	1		
50	Α	111054	Screw, 10-24 x .625	3		
51	В	224042	Shroud, Engine Machined	Ť		
52	В	300766	Crankcase / Shaft Assembly CD	1		
		** **	. Crankshaft Assembly	1		
			. Crankcase, Machined	1		
			Bearing 6202	1		
			Bearing 6202RS	1		
		** **	Seal	1		
			Spacer	1		
			O Ring	1		
53	Α	224009	Connecting Rod Assembly	1		
54	Α	91117	Bearing	2		
- 55	Α	300661	Kit, Piston, 28cc Aluminum	1		
56	В	300482	. Piston Pin, C'shaft (10mm dia)	1		
57	A	215876	. Ring, Retaining	t		
58	A	224224	. Ring, Piston 35mm	1		
59	Α	111065	Screw, 10-24 x .688 Tri And	.4		
60	Α	322030	Shield, Muffler	1		
61	Α	300452	Kit, Cylinder 28cc Chrome	1		
62	Α	224022	. Gasket, Cylinder	1		
63	В	224235	Cover, Cylinder/Muffler (8lk)	1		
64	В	322480	Label, Start Instructions (SLI/SW)			
65	С	322210	Washer, Plastic	1		
66	B	111067	Screw, 10-24 x .63 SL TORX TP			
67	В	111068	Screw, 10-14 x 1.38 Taptite	1		
68	Α	93469	Washer	1		
69	A	62345	Spark Plug / DJ8J	i		
70	Ä	224023	Gasket, Crankcase	1		
71	В	224024	Plug, Crankcase	1		
72	Ā	111065	Screw, 10-24 x .688 Tri Rnd	5		
73	.,	FIGURE 2	STARTER HOUSING ASSEMBLY	-		
	С		Label, Air Box			


STARTER HOUSING ASSEMBLY



NO.	STK. CODE	PART NUMBER	DESCRIPTION UNITS	PER ASY.
1	Α	301133	Wire Assembly, Switch	1
2	В	300064	Cover Assembly, Switch	1
3	В	111069	. Screw, 8-16 x .375 Plastite	1
4	В	105497	. Washer, Flat (.180 ID max)	1
5	В	224246	Contact, Switch	1
6	В	224245	. Button, Stop Switch	1
7	B	322081	Label, ON/OFF Switch	1
8	В	224234	Trigger Housing Assembly 22mm	1
9	Α	111061	Screw, 6-19 x .62 FL HD Plast	2
10	С	323696	Housing, Clutch	1
11	Α	300361	Trigger, Throttle	1
12	Α	300372	Throttle Cable Assembly	1
13	Α	111074	. Nut, Speed .188 ID	1
14	Α	322234	Sleeve, Protecting	1
15	В	322140	Grip	1
16	Α	224919	Screw, 10-14 x 1.0 PN HD	4

_					
	ITEM NO.	STK. CODE	PART NUMBER	DESCRIPTION	PER ASY.
	17	A	111070	Screw, 12-11 x .5 PN HD TORX	1
	18	₿	302106	Drum Assembly, Clutch	1
,	19	Α	300459	Kit, Clutch	1
ļ	20	Α	111054	Screw, 10-24 x .625	4
	21	С	301927	Starter Assembly	1
	22	С	302122	. Housing, Starter/Rope Guide	1
	23	Α	301134	. Wire Assembly	1
	24	Α	300475	. Package, Spring Assembly	1
	25	Α	300872	. Drum/Rope Assembly	1
	26	Α	222869	Rope, Starter (46")	1
	27	В	218941	. Washer, Nylon	1
	28	Α	216792	. Handle, Starter	1
	29	Α	224927	. Plate, Baffle	1
	30	Α	215533-01	. Grommet, H/T Lead	1
	31	Α	223357	. Screw, 8-16 Plastite	3
	32	В	300415	Rope, Bulk	1

CARBURETOR ASSEMBLY



NO. CODE NUMBER		PART Number	DESCRIPTION ASY.			
	Α	224033-02	Carburetor w/Choke, Walbro WT-231.	A		
1		⊕	Ring, Screen Retainer	1		
2			Ring, Shaft Retainer	1		
3			Lever, Throttle	1		
4			Cover, Metering Lever	1		
5	В	300072	Cover, Fuel Pump	1		
6			Shaft Assembly, Throttle	1		
7			Valve, Throttle	1		
8		3	Shaft Assembly, Choke	1		
9		3	Valve, Choke	1		
10		(D)	Valve, Inlet Needle	1		
11			Seat Assembly, Check Valve	1		
12		①	Plug, Cup 5mm	1		
13		①	Plug, Welch 5/16	1		
14		3	Ball, Choke Friction	1		
15		①②	Gasket, Metering Diaphragm	1		
16		0 @	Gasket, Fuel Pump	1		
17		T 2	Diaphragm, Fuel Pump	1		
18		①②	Diaphragm Assembly, Metering	1		
19		I I	Screw, Valve	3		


-					
	ITEM NO.	STK. CODE	PART NUMBER	DESCRIPTION	ITS PER ASY.
	20		①	Screw, Metering Lever Pin	1
l	21			Screw, Pump Cover	1
	22			Screw, Idle Adjust Kit	1
	23		①	Screw, Metering Cover	4
l	24		3	Spring, Choke Friction	1 .
	25		①	Spring, Idle Needle	1
	26		①	Spring, High Speed Needle	1
	27		①	Spring, Throttle Return	1
	28		①	Spring, Metering Lever	1
	29		①	Needle, High Speed	1
	30		①	Needle, Idle	1
	31		Φ	Screen, Check Valve	1
	32		①	Screen, Fuel Inlet	1
	33		①	Pin, Metering Lever	1
	34		0	Lever, Metering	1
	0	Α	300457	Kit, Carburetor Repair	
	2	Ą	224460	Kit, Gasket/Diaphragm	
	3	A	322363	Kit, Choke Lever	

NOTE: Items are shown for identification and disassembly sequence purposes only. Components are not available separately unless a part number is listed before the part description.

CARBURETOR METERING LEVER ADJUSTMENT AND SETTINGS

CARBURETOR INLET POP OFF - 16-29 PSI INLET - FLUSH WITH METERING CHAMBER FLOOR

SHAFT/HANDLE /CUTTER ASSEMBLY



ITEM NO.	STK. CODE	PART NUMBER	DESCRIPTION	TS PER ASY.	-
1	Α	217444	Handle, Delta	1	
2	Α	217442	Clamp, Handle	1	
3	Α	120041	Screw, M5 x .8 x 22 Hex	2	
4	Α	217159	Nut, Hex M5	2	
5	Α	300651	Kit, Stringhead -Sml-	1	
6	Α	322025	. Housing/Eyelet Asy, w/Collar	1	
7	Α	224998	Collar	1	
8	Α	322626	. Spring	1	
9	Α	300688	. Kit, Line on Spool(M-Sm)	i	
10	Α	300736	. Kit, Knob Asy. (Right)	1	

ITEM NO.	STK. CODE	PART NUMBER	DESCRIPTION UNIT	TS PER ASY.
11	Α	300429	Housing Assembly, Outer	1
12	В	218295	. Decal, Warning	1
13	С	223407	. Decal, Eye/Ear Cover	1
14	С	211214	. Decal, Warning(15m)	1
15	С	301023	Drive Assembly w/Clip	1
16	₿	322099	Label, Debris Shield Warning	1
17	Α	224062	Shield Assembly, Grass 17"	1
18	Α	300626	. Kit, Knife	1
19	Α	224497-01	Cutter	1
20	Α	216682	Nut, Lock 10-24 Hex	2
21	Α	217935	Screw, TR 10-24 x .50 Torx	2
22	Α	216595	Screw, M6 x 1.0 Hex	1
23	₿	111102	Nut, Wing, M6 x 1.0	1
24	Ţ	322344	Wrench, Stringhead	. 1

SPECIFICATIONS

FLYWHEEL to IGNITION GAP 0.010 to 0.015 inches (0.254 to 0.381 mm)

SERVICE TOOLS

PART NUMBER DESCRIPTION

215432 •

217720

222785

111124

PRESSURE TEST TOOL

TORX DRIVE SET

T-25 TORX DRIVE 3.5"

T-27 TORX DRIVE 3.5"

T	TORQUE SPECIFICATIONS			
DESCRIPTION	P/N	FIG/ITEM	TORQUE VALUE (In.Ibs.)	LOCTITE
ARBURETOR	111058	1/12	25-30	NO
NSULATOR TO CYLINDER	11053	1/19	45-50	242
LYWHEEL NUT	322847	1/35	140-145	242
GNITION ASSEMBLY	11053	1/41	45-50	242
SHROUD TO CRANKCASE	11054	1/49	55-60	242
CRANKASE TO CYLINDER	11065	1/58	55-60	242
SPARK PLUG	62345	1/68	110-120	NO
CRANCASE TO PLASTIC PLUG	11065	1/71	35-40	242
CLUTCH HOUSING	224919	2/16	30-35	NO
STARTER HOUSING	111054	2/20	30-35	NO