


MANUAL DE INSTRUCCIONES

MICRÓFONO INALÁMBRICO

MH-850C



ATENCIÓN:

- Realice siempre las conexiones antes de enchufar el cable de alimentación a la red eléctrica.
- Evite guardar los equipos en lugares expuestos a la luz solar directa, altas temperaturas y humedad.
- No manipule el cable de alimentación con las manos mojadas.
- Mantenga los equipos alejados del fuego u otras fuentes de calor.

CARACTERÍSTICAS

Modelo	MH-850C
Frecuencia de portadora	600 ~ 960 MHz, UHF
Tipo de micrófono	De mano
Diagrama polar	Cardioide
Selección de canales	16 frecuencias
Respuesta en frecuencia	50 ~ 16.000 Hz
Desviación de frecuencia	±48 kHz
Sistema de modulación	PLL
Alimentación	Pila: 2 x AA (1,5 V CC)
Temperatura operación	-10 a +50°C
Indicadores	Funcionamiento y estado de la batería
Controles	Puesta en marcha y selección de canal
Acabado	Plástico gris oscuro
Accesorios	Destornillador

FUNCIONAMIENTO

1. Desenrosque y extraiga la cápsula del micrófono para colocar las pilas en su compartimento.
2. Retire la tapa inferior y use el destornillador suministrado para seleccionar el canal deseado, éste debe ser el mismo en el micrófono y el receptor. Cuando se utilicen 2 o más micrófonos y receptores en la misma área, deberán ser configurados con canales diferentes. Si en un canal se producen interferencias, cambie a otro canal sin interferencias.
3. Accione el interruptor de encendido, el Led se iluminará en verde. Cuando las pilas estén agotadas el Led cambiará a rojo.



LISTA DE FRECUENCIAS*

Canal	Frecuencia	Canal	Frecuencia
1	863.125 MHz	9	864.125 MHz
2	863.250 MHz	10	864.250 MHz
3	863.375 MHz	11	864.375 MHz
4	863.500 MHz	12	864.500 MHz
5	863.625 MHz	13	864.625 MHz
6	863.750 MHz	14	864.750 MHz
7	863.875 MHz	15	864.875 MHz
8	864.000 MHz	16	865.000 MHz

Las frecuencias aplicables indicadas en la tabla pueden ser oficialmente usadas en los países donde la Decisión ERC/DEC(01)18 esté implementada: AT, BE, BG, CY, CZ, DK, EE, FI, FR, DE, GR, HU, IE, IT, LV, LT, LU, MT, NL, PL, PT, SK, SI, ES, SE, GB (Limitado). Los países no enumerados pueden permitir el uso de esas frecuencias conforme a su legislación local.


* Nota: Por favor, contacte con su autoridad nacional correspondiente para obtener información de las frecuencias legales en su área y el uso legal del equipo.

CE 0197

INSTRUCTION MANUAL

WIRELESS MICROPHONE

MH-850C



WARNING:

- Always make all connections before plugging the unit into an AC power outlet.
- Do not leave the device in a place neither with high temperature or high humid.
- Always do not handle the power cord with wet hands.
- Keep the devices away from fire and heat sources.

SPECIFICATIONS

Model	MH-850C
RF Frequency range	600 ~ 960 MHz, UHF
Type	Handheld
Polar pattern	Cardioid
Channels selection	16 frequencies
Frequency response	50 ~ 16.000 Hz
Frequency deviation	±48 kHz
Modulation type	PLL
Power supply	Batteries: 2 x AA (1,5 V DC)
Temperature range	-10 a +50°C
LED indicates	Power On/Off and Low bat.
Controls	Power On/Off and channel Up/Down
Finish	Dark grey plastic
Accessories	Screwdriver

OPERATION

1. Unscrew and extract the microphone capsule to insert the batteries on its compartment.
2. Use the supplied screwdriver to select a desired channel, this must be the same for the microphone and the receiver. When 2 or more microphones and receivers are being used in the same location, they must be set up to use different channels. If existing channel is being interfered, please change to non-interference channel.
3. Turn on the power switch, the Led will light green. The Led will change to red in case of low battery.



FREQUENCY LIST*

Channel	Frequency	Channel	Frequency
1	863.125 MHz	9	864.125 MHz
2	863.250 MHz	10	864.250 MHz
3	863.375 MHz	11	864.375 MHz
4	863.500 MHz	12	864.500 MHz
5	863.625 MHz	13	864.625 MHz
6	863.750 MHz	14	864.750 MHz
7	863.875 MHz	15	864.875 MHz
8	864.000 MHz	16	865.000 MHz

The applicable frequencies listed in the table can be officially used in the countries where the Decision ERC/DEC(01)18 is implemented: AT, BE, BG, CY, CZ, DK, EE, FI, FR, DE, GR, HU, IE, IT, LV, LT, LU, MT, NL, PL, PT, SK, SI, ES, SE, GB (Limited). Countries not listed may allow using those frequencies subject to their local regulations.

* Note: Please contact your national frequency authority to get information on the available legal frequencies for your area and legal use of the equipment.

CE 0197