

USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠️ WARNING and ⚠️ CAUTION Notices

⚠️ WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
⚠️ CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. □ * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

⚠️	The ⚠️ symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
⊘	The ⊘ symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
⚡	The ⚡ symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

----- ALWAYS OBSERVE THE FOLLOWING -----

- Antes de usar esta unidad asegúrese de leer las siguientes instrucciones y el Manual de instrucciones.
- No abra ni realice ninguna modificación interna a la unidad. (La única excepción sería en el caso de que este manual le diera instrucciones precisas para colocar opciones de ampliación instalables por el usuario)
- No intente reparar la unidad ni sustituir ningún componente de su interior (excepto si este manual le da indicaciones precisas al respecto). Consulte cualquier mantenimiento a su distribuidor, al Servicio técnico Roland más cercano o a un distribuidor Roland autorizado, de los que aparecen en la página "información".

WARNING

- Nunca use o guarde la unidad en lugares que estén:
 - Sujetos a temperatura extremas (p.ej., la luz directa del sol en un vehículo cerrado, cerca de un conducto de calefacción, encima de aparatos que generen calor); o que estén:
 - Inundados (p.ej., lavavos, fregaderos, en suelos mojados); o que estén:
 - Húmedos; o que estén:
 - Expuestos a la lluvia; o que sean:
 - Polvorientos; o que estén:
- Sujetos a altos niveles de vibración.
- En hogares con niños pequeños, un adulto debería supervisar la manipulación de la unidad hasta que el niño es capaz de seguir todas las normas esenciales para el correcto funcionamiento de ésta
- Proteja la unidad de impactos fuertes.
(¡No deje caer la unidad!)