USING WITH SONY ERICSSON T39m

a. ACTIVATING THE BLUETOOTH

You must activate the Bluetooth feature of your cell phone to establish a Bluetooth connection between your mobile phone and other Bluetooth devices.

- 1. Press *Menu Key*. Scroll to *Extras* and press **YES**. Select *Operation mode*, **YES**. On, **YES**.
- 2. Continue pressing **NO** to exit.

QUICK ACCESS:

Press Menu followed by the sequence of numbers below.

	Extras	Blue tooth	Operation mode
T39m	5	6	4

b. PAIRING TO THE CELLULAR PHONE (not possible while charging the Handsfree Kit)

- 1. Bring the cellular phone at about 20 cm from the Handsfree Kit.
- 2. Turn off the Handsfree Kit and wait for about 4 seconds.
- 3. While pressing the *Answer Button*, turn ON the Handsfree Kit by sliding the *Power Switch* to the right. Keep the Answer Button pressed for approximately 10 seconds until you hear a distinctive tone and the Bluetooth indicator LED changes from blinking blue to alternately blinking red and blue. The Handsfree Kit is now in pairing mode.
- 4. Press the Answer Button once again for a short time, to access headset pairing mode.
- 5. Press *Menu Key.* Scroll to *Extras*, **YES**. Select *Bluetooth*, **YES**. Select *Paired devices*, **YES**. Add device, **YES**. Choose *Phone initiates*, **YES**. Choose *Headset*, **YES**. The phone will then search the device to be added. After the device is found, press **YES**.

QUICK ACCESS (for steps 5 and 6):

Press *Menu* then follow the sequence of numbers below:

	Extras	Blue tooth	Paired devices	Add device	Phone initiates	Headset
T39m	5	6	2	Yes	1	2

- 6. Enter "0000" as the passkey. If the pairing is successful, the alternating red/blue lights will stop. Press **YES** to confirm the name of the device. If pairing is unsuccessful, the steps above may be repeated.
- 7. Continue pressing **NO** to exit from Menu.

The Handsfree Kit is paired and ready to use.

c. ANSWERING/RECEIVING A CALL

When the phone is receiving a call, a ring tone will be heard on the Handsfree Kit.

- 1. Press once on the Answer Button to answer the call.
- 2. If you wish to answer the call on the cellular phone, press **YES** and the call will automatically be transferred to the phone. Pressing the Answer Button again will transfer the call to the Handsfree Kit.
- 3. To terminate the call, press Hang-Up Button.

d. MAKING A CALL with the Handsfree Kit on

Normal dialing

- Enter the contact number and press YES. Audio can be heard on the Handsfree Kit. Simultaneously, a question "Retrieve call in phone?" will be displayed. Ignoring or pressing "No" will retain the audio to the Handsfree Kit. Pressing "Yes" will transfer the audio to the cell phone.
- 2. Press the Hang-Up Button to terminate the call.

Voice dialing

Refer to step g and h for the procedure when activating and recording for voice dialing.

- 1. Press the Answer Button once to activate the voice dialing.
- 2. A beep will then be heard on the Handsfree Kit prompting the user to say the name of the person to call.
- 3. Say the name. The name will be played back to you. The phone will then place the call automatically. In case the cell phone does not recognize the name spoken, the steps above may be repeated.
- 4. Press the Hang-Up Button to terminate the call.

e. <u>AUDIO TRANSFER</u>

Audio Transfer can be done by pressing the Answer Button or accessing the cell phone's Menu during ongoing calls.

f. **SETTING THE VOLUME**

Setting the volume can be done using the Volume Control.

- 1. Turn it clockwise to increase the volume.
- 2. Decrease the volume by turning it counter-clockwise.

Note: If the volume set is too high, it can cause feedback (whistling sound), echo or background noise during calls on some cell phones.

g. ACTIVATING THE VOICE DIALING

Use your phone when recording for the voice dialing. Before voice dialing, you must first turn on the name dialing function and record your voice. To turn voice dialing on:

- 1. Press Menu Key. Scroll to Settings, YES. Voice control, YES.
- 2. Voice settings, YES. Voice dialing, YES. Select On, YES.
- 3. Continue pressing **NO** to exit

QUICK ACCESS:

Press *Menu* followed by the sequence of numbers below.

- 1000 111011011011011011			the dequence of manifesters				
		Settings	Voice control	Voice settings	Voice dialing	On	
	T39m	4	9	1	1	1	

h. RECORDING FOR VOICE DIALING

- 1. Press Menu Key. Scroll to Settings, YES. Voice control, YES. Voice Commands, YES. Select Contacts, YES. Add voice, YES.
- 2. Find a contact name and follow the instructions in the display. An icon will appear next to a contact name which has a voice command.
- 3. Continue pressing **NO** to exit.

QUICK ACCESS:

Press *Menu* followed by the sequence of numbers below.

	Settings	Voice control	Voice commands	Contacts	
T39m	4	9	2	4	

Note: Noisy environment may affect voice recognition. Record your voice in a quiet environment.