

ISO 9001 Quality System Certified

G-1700, 60 HZ., 1 PHASE COMPRESSOR, 7622153
REPLACEMENT INSTRUCTIONS

1. Remove the old compressor. Unsweat all tubes from the old compressor. Do not cut them off.
2. Place the new compressor into the ice machine, as shown.
3. This replacement compressor may be different than the original compressor and/or have slightly different tubing configurations. The suction line, discharge line, and/or suction service line at the compressor may need to be rerouted, when making this change-out.
4. Replace the compressor components (start relay, start capacitor, and run capacitor) with the new ones provided. NOTE: The new start relay must be mounted in the position shown.
5. Replace the filter drier with the new drier, as called out in the parts manual.
6. Evacuate the ice machine following the steps on the service bulletin.
7. Charge the ice machine with the nameplate charge.

8003453
Revised 10/26/95

MANITOWOC EQUIPMENT WORKS