



**K00198 FLOAT VALVE KIT UK**  
**(QM-45, Q-0130, Q-0210, Q-0270, Q-1400)**  
**Installation Instructions**

1. Turn off water supply to ice machine.
2. Remove front panel (Q-1400 only).
3. Loosen compression nut and remove clear tubing connected to the float valve.
4. Loosen valve body and slide valve out of mounting bracket.
5. Install new float valve and reconnect water supply to valve. Ensure that connections are tight (**do not over-tighten**).
6. Reinstall front panel (Q-1400 only).
7. Apply agency approval label to the machine near the serial plate.
8. Turn on water supply to ice machine.