



RF0300/0650/1200 Flake Ice Machines Ice Chute Replacement Kit Instructions

STEP 1



STEP 5




STEP 2




STEP 6



STEP 3




STEP 7



STEP 4




STEP 8




STEP 9

Rotate the basin support plate 180° and re-attach to reservoir assembly




STEP 13




STEP 10

Re-attach reservoir assembly to cross bar



STEP 11

Join upper and lower assemblies



STEP 12

