



Copying at the WorkCentre® 7328/7335/7345



Simple Copying:



- 1. Load the document into the Document Handler.
- 2. Touch the **Services** button on the Control Panel.
- 3. Touch the **Copy** icon on the Touch Screen.
- 4. Select the appropriate **Settings** on the Touch Screen.
- 5. Enter the **Quantity** using the Number Keypad.
- 6. Press the **Start** button on the Control Panel.

Copying Options:

Output Color

The *Auto Detect* option allows the machine to determine the color content of your document. The *Color* option enables the machine to use all four toner colors. The *Black & White* option enables the machine to use only black toner.

Reduce/Enlarge

Select the 100% option to produce copies that match the size of your original document. Select *More...* to view a list of commonly used Reduce/Enlarge settings.

Paper Supply

The *Paper Supply* options allow you to specify any one of five standard paper trays to use as a source for your copy job. You can also choose the *Auto Paper Select* option to allow the machine to automatically choose the best Paper Tray for your copy job.

2 Sided Copying

Depending on your original documents and your required output, you can select $1\rightarrow1$ Sided, $1\rightarrow2$ Sided, $2\rightarrow2$ Sided, or $2\rightarrow1$ Sided.

Copy Output

The *Copy Output* options differ depending on your machine's Finisher configuration. The most robust Finisher configuration allows you to choose from *Collated*, 1 *Staple*, 2 *Staples*, *Folded*, and *Hole Punched*.

Image Quality

The Image Quality tab options allow you to access the Original Type, Image Options, Image Enhancement, Color Effects, Color Balance, and Color Shift settings.

Layout Adjustment

The Layout Adjustment tab options allow you to access the Book Copying, Original Size, Edge Erase, Image Shift, Image Rotation, Invert Image, and Original Orientation settings.

Output Format

The Output Format tab options allow you to access the Booklet Creation, Covers, Transparency Options, Page Layout, Poster, Annotations, Watermark, and ID Card Copying settings.

Job Assembly

The Job Assembly tab options allow you to access the Build Job, Sample Job, Combine Original Sets, Delete Outside/Delete Inside, Save Current Settings, and Retrieve Saved Settings options.