



# MINI CHEF™ WASHING MACHINE ASSEMBLY INSTRUCTIONS

**Adult Assembly Required.**  
**Save these instructions for future use.**  
**This product is a toy only.**

**THIS ITEM IS PART OF THE  
FOLLOWING MODEL NUMBERS:**

**#09980 - FIVE PIECE KITCHEN PLAY SET**

**#09981 - TARGET THREE PIECE KITCHEN PLAY SET**



## **BEFORE YOU BEGIN ASSEMBLY:**

Check all parts and hardware listed. If anything is missing, please DO NOT call the store or return the product to them. Contact us for assistance. Most problems are resolved without you needing to leave home. When emailing or calling us, please have this instruction manual and your product model number ready.

For fastest service, go to

**<http://www.badgerbasket.com/parts>**

Visit us online at **[www.badgerbasket.com](http://www.badgerbasket.com)**

Toll-Free Customer Service: 1-800-236-1310 (Monday to Thursday 7:30 AM-4:30 PM CST)

**Web:** <http://www.badgerbasket.com/parts> • **E-mail:** [parts1@badgerbasket.com](mailto:parts1@badgerbasket.com)

**PLANT AND GENERAL OFFICE:** PO Box 227, Edgar, WI 54426-0227 • Phone: 715-352-2311 • Fax: 715-352-3163

**CORPORATE OFFICE:** 111 Lions Dr., Suite 220, Barrington, IL 60010

TOOL REQUIRED (not included)

