




WASHER/DRYER CONTROL PANEL PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)

WASHER/DRYER
LAUNDRY SYSTEM



Illus. No.	Part No.	DESCRIPTION
1	W10112506	Literature Parts Installation Instructions
	8578179	Use & Care Guide
	3954161	Energy Guide
	8542754	Sheet, Cycle Feature
	8576808	Wiring Diagram
2	8577368	Harness, Console Wiring (Automatic) (Includes Illus. 2A, 2B & 2C)
2A	3350130	Plug, Terminal (2-Way) (Connects With Main Dryer Harness)
2B	696073	Receptacle, Connector (Connects With Lower Automatic Harness)
2C	3948614	Disconnect Block (Connects With Automatic Timer)

Illus. No.	Part No.	DESCRIPTION
5	3952499	Timer, Control (60 Hz.) (Automatic Washer)
6	8528154	Bracket, Control
7	692993	White End Cap, Console (L.H. & R.H.)
	3978584	Biscuit
8	348689	Screw, End Cap Mounting (4)
9	694091	Screw, Mounting (2)
10	3362987	Switch, Water Level
11	688805	Spring Clip, Knob
12	8054142	Switch, Water Temperature
14	693151	Spring, Console Lock (2)
15	3400860	Screw, Console Lock (2)
16	3406720	Timer, Control (60 Hz.) (Dryer) (Timer Motor Not Serviceable)
18	3977456	Switch, Push-To-Start
19	693152	Bumper, Console (5)


Illus. No.	Part No.	DESCRIPTION
21	694037	Clip, Console
22	8533971	Screw, (8-18 x 5/16)
23	3977194	White Panel, Control
	3977195	Biscuit
24	3957752	White Knob, Timer (Dryer)
	3957753	Biscuit
25	3957800	White Knob, Push-To-Start
	3957801	Biscuit
27	3957796	White Knob, Control (2)
	3957797	Biscuit
28	3957841	White Dial, Timer (Washer)
	3957842	Biscuit
29	3957821	White Knob, Timer (Washer)
	3957822	Biscuit
31	692983	Lock, Console (2)
32	694419	Buzzer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER FRONT PANEL AND DOOR PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3406108	Door Switch
2	697773	Screw, 6-20 x 7/8
4	692619	White
	3978587	Biscuit
5	3390734	Seal, Door
6	695656	Door, Rear
7	348205	White
	3978598	Biscuit

Illus. No.	Part No.	DESCRIPTION
9	8066123	Bearing & Seal
10	685203	Clip, Felt Pad (2)
11	696144	Strike, Panel
12	3390663	Screw, Door Switch Mounting (2)
13	343641	Screw, 10-16 x 1/2 (2) (Front Panel To Side Panel)


Illus. No.	Part No.	DESCRIPTION
14	3389441	Catch, Door
15	686711	White
	3978592	Biscuit
19	694091	Screw, Door Mount To Hinge & Panel (10)
20	348023	Hinge & Pin, Door (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER CABINET AND MOTOR PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER CABINET AND MOTOR PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	660658	Clamp, Motor Mounting (2)	18	686770	Support, Protector	30	693145	Latch, Lid
2	8538265	Motor, Main Drive (60 Hz.)	20	8066064	Belt, Drive	31		Closure, Control Area
5	696541	Bracket, Motor	21	8066051	Pulley, Motor (60 Hz.)		692781	White
6	3390405	Panel, Rear	22	691366	Idler & Pulley Assembly	32	3978599	Biscuit
7	343641	Screw, 10-16 x 1/2	23	692771	Nut, Idler Bracket To Base	32	354975	Screw & Washer (3) (Lid Latch Mounting)
8	3394228	Cover, Terminal Block	24	3399632	Base, Dryer	33	693304	Screw & Washer (2) (Transition Panel To Closure)
9	90296	Clip	25	692400	Nut, Push-In	34	697776	Screw, Ground (10-32 x 5/8)
10		Panel, Side (L.H.)	26	692926	Cove, Transition Panel (Black)	35	3390631	Screw, 10-16 x 3/8
	3402293	White	27		Panel, Transition	36	8572717	Capacitor, Motor Start (Automatic Washer)
14	3399602	Elbow, Upper		692933	White	37	357030	Clamp, Capacitor
15	3394083	Clip, Front Panel (2)		3978591	Biscuit			
16	98234	Clip, Ground	28	692641	Top, Dryer			
17	3399603	Elbow, Lower	29		Panel, Side (R.H.)			
				3402287	White			
				3978590	Biscuit			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER BULKHEAD PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER BULKHEAD PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	343641	Screw, 10-16 x 1/2	19	3404154	Thermostat, Heater Box (200°F)	36A	717252	Receptacle, Terminal (2-Way) (Connects With Door Switch Harness)
2	3395396	Clip, Air Duct To Bulkhead	20	3406652	Resistor Assembly	36B	3395683	Receptacle, Multi-Terminal (Connects With Motor)(Dryer)
3	8566186	Air Duct & Bracket	21	3399507	Shaft, Drum Roller (R.H.)	37	693141	Clip, Wiring Harness (3)
4	90767	Screw, 8-18 x 3/8	22	695943	Drum, Dryer	38	94614	Terminal
5	3398128	Thermostat, Internal Bias	23	3394508	Ring, Bearing	39	279457	Wire Kit (For Heater Element Wiring Harness Repair)
6	3393008	Screw, Terminal Block To Bracket (2)	24	685207	Baffle, Drum (3)	40	8066086	Drum,Hole Plug
7	3397659	Block, Terminal	25	W10109200	Screw, Baffle Mounting (6) (11-16 x 3/4)	41	279393	Screw Kit (For Terminal Block)
8	3388703	Washer	26	345648	Seal, Drum Rear	42	279318	Terminal, Tinned & Brass (3) (Includes Illus. 41)
9	489463	Screw, 8-18 x 5/8	27	695931	Bulkhead	43	697776	Screw, Ground (2) (10-32 x 5/8)
10	3398161	Clip, Heater Box To Bulkhead	28	8531964	Lint Screen	44	348378	Screen, Back-Up
11	3401380	Heater Box	29	8531967	Cover, Lint Screen Outlet	48	359702	Cap, Screw
12	3403586	Element, Heater	30	690997	Tri-Ring (4)	49	255563	Clip, Strain Relief
13	339956	Seal, Air Duct To Bulkhead	31	3399506	Shaft, Drum Roller (L.H.)			
14	696426	Wheel, Blower	32	3397590	Roller, Support (2)			
15	8578221	Thermal Limiter 195°F (91C)	33	348197	Washer, Support (4)			
16	8066094	Seal, Fan Scroll	34	3359452	Nut, 3/8-16 (2)			
17	696418	Fan Scroll	35	3390631	Screw, 10-16 x 3/8			
18	3390647	Screw, 8-18 x 1/2	36	3406941	Harness, Main Dryer Wiring (Includes Nos.36A, 36B)			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRYER SUPPORT AND WASHER PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	694304	Cover, Channel
2	692647	Support, Dryer (L.H.)
3	343641	Screw, 10-16 x 1/2
4	3400000	Screw, 10-24 x 3/8 (8) (Washer Cabinet To Dryer Supports)
5	692646	Support, Dryer (R.H.)
6	3957867	Harness, Lower (Automatic) (Includes Illus. 6A, 6B & 6C)
6A	696074	Plug, Terminal (12-Way) (Connects With Automatic Console Harness)
6B	62889	Plug, Terminal (3-Way) (Connects With Automatic Lid Switch Harness)
6C	62505	Block, Disconnect (Connects With Automatic Washer Motor)
7	3347812	Clip, Wiring Harness (4)
8	3352501	Clip
9	90016	Clip, Pressure Switch Hose (2)
10	693141	Clip, Harness And Hose
11	3351614	Screw, 10-24 x 3/8
12	8066080	Hose, Pressure Switch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER TOP AND LID PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3398848	Lid White
	3398849	Biscuit
2	384475	Bumper, Lid (2)
3	91770	Hinge, Lid (2)
4	3351355	Screw, Lid Hinge Mounting (4)
5	343641	Screw, 10-16 x 1/2
6	692985	Clip, Spring (2) (Top To Cabinet)

Illus. No.	Part No.	DESCRIPTION
7	384693	Top White
	3978593	Biscuit
8	21258	Bearing, Lid Hinge (2)
9	3356311	Screw & Washer, Lid Switch Shield (2)


Illus. No.	Part No.	DESCRIPTION
10	358684	Strike, Lid Switch
11	3400030	Screw, Ground (10-24 x 1/2)
12	8533959	Nut, Ground Screw (10-24)
13	3355806	Switch, Lid
14	90016	Clip, Harness Routing

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER CABINET PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WASHER CABINET PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	356746	Clip, Condenser
2	343641	Screw, 10-16 x 1/2
3	9740848	Screw, Mixing Valve Mounting (8-18 x 1/2)
4	370451	Clamp, Hose
5	3952163	Valve, Water Mixing
7	692699	Hose, Water Inlet (Siphon Break To Mixing Valve)
8		Cabinet
	696013	White
	3978594	Biscuit
10	696710	Hose, Drain
11	692400	Nut, Push-In (2)
12	660975	Plug, Top To Cabinet
13	8557915	Connector, Hose
15	356471	Cap, Siphon Break
16	356363	Siphon Break
17	272861	Clamp, Hose
18	696394	Hose, Water Inlet (Siphon Break To Tub Ring)
21	660628	Clamp, Hose
22	3394083	Clip, Front Panel (2)
23	358652	Link, Leveling
24	359364	Clip, Leveling Mechanism (2)
25	98234	Clip, Ground
26	345670	Lock, Top (2)
27		Panel, Front
	692628	White
	3978596	Biscuit
28	367594	Foot, Front (2)
29	358594	Foot, Rear (2)
30	3400000	Screw, 10-24 x 3/8 (Washer Cabinet To Dryer Supports)
32	3390046	Protector, Edge

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	387948	Brake And Drive Tube (Complete) (Refer To Page 16 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951312	Clutch (Complete)
6	3951308	Band And Lining (Includes Illus. 7 & 8)
7	3946846	Spring, Clutch
8	62646	Cap, Clutch Spring (2)
9	3360630	Gearcase (Complete)(Refer To Page 15 For Further Breakdown)

Illus. No.	Part No.	DESCRIPTION
10	3357334	Screw, (3) (Gearcase To Tub Support)
11	62611	Plate, Motor Mount To Gearcase
13	3364003	Coupling, Motor & Isolating
14	661600	Motor, Main Drive
16	3946532	Plate, Motor
18	3363394	Pump, Complete
19	8546127	Retainer, Pump
20	62850	Switch, Main Drive Motor
21	62691	Grommet, Motor (4)
22	3349637	Retainer, Motor (2)
23	3350013	Foam
24	3387485	Screw, 10-16 x 5/8
25	3355454	Clip (Anti-Rattle)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	285203	Centerpost Bearing Kit (Incls. Illus. 10, 11, & 12)
3	64137	Shield, Tub
4	388492	Spring, Counterweight
5	3406201	Suspension Assembly (3)
6	8577373	Base
10	8577376	Seal, Centerpost
11	8546455	Bearing, Centerpost (2)
12	357409	Seal, Centerpost
13	63134	Ring, Sound Deadening
14	343641	Screw, 10-16 x 1/2
15	63636	Bracket, Counterweight Spring
17	63637	Shield, Tub
18	3351021	Nut, 1/2 - 13 (3)
19	63740	Tub Support and Drum
21	3351614	Screw, 10-24 x 3/8
22	90767	Screw, 8-18 x 3/8
23	386011	Screw & Washer (Base To Cabinet)
24	696044	Block, Restraint

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TUB AND BASKET PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	358237	Screw & Washer (5/16-24 x 1)
3	63840	Filter, Agitator
4	3349098	Agitator
5	64175	Tub Ring & Gasket (Includes Illus. 7, 14 & 15)
6	21366	Nut, Spanner
7	3359587	Gasket, Tub Ring
8	3351985	Basket
9	8066082	Tub
10	389140	Block, Basket Drive
11	3949550	Washer
12	3363366	Clamp, Hose
13	8066201	Hose, Tub To Pump
14	352155	Clip, Retaining
15	356398	Tube, Drain Off
16	357640	Screw & Washer (Tub Mounting)
17	383727	Gasket, Centerpost

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WATER SYSTEM PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)



WS-900D


Illus. No.	Part No.	DESCRIPTION
1	285321	Sleeve Kit, Plastic Drain Hose (Contains 2 Sleeves)
2	65349	Clamp, Hose (2)
3	16272	Connector, Straight
4	285320	Siphon Break Kit (Not Included)
5	661575	Hose, Corrugated Plastic Drain (5 1/2 Ft.)
	W10108350	Hose, Corrugated Plastic Drain (6 1/2 Ft.) (For FSOU & Twin-Twin)
	661577	Hose, Corrugated Plastic Drain (10 Ft.) (Not Included)
6	8577378	U-Bend
7	3357331	Clamp, Hose
8	356739	Connector, Hose
9	3354858	Hose, Inlet (2)
10	285442	Connector Kit, Plastic Drain Hose

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10-24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate


GC-215-C

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE AND DRIVE TUBE PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	387948	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	356427	Seal, Drive Tube
4	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
5	64035	Ring, Retaining
6	64232	Shoe, Brake (2)
7	62703	"T" Bearing, Spin Tube
8	3353956	Cap, Brake Spring (2)
9	63748	Spring, Brake
10	3355360	Sleeve, Brake Spring
11	661516	Cam, Brake Release
12	63022	Sleeve, Cam
13	64194	Driver, Brake Cam
14	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED

285208 Lubricant
(Use Only In Brake Shoe Assembly On Roller & Pin)


BD-313C

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PRODUCT ACCESSORY PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
1	279823	Side Exhaust Extension Kit (Complete)
2	488729	Screw, 8-18 x 1/2
3	3395536	Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MISCELLANEOUS PARTS

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3359934	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose (4)
3	370445	Clamp, Hose
4	367594	Foot, Front (2)
5	358594	Foot, Rear (2)
6	3347869	Tie, Cable
7	3357331	Clamp, Hose (Upper Drain)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: LTE5243DQ7, LTE5243DT7

(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
-------------------	-----------------	--------------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
4392899 Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350938 Primer, Gray
350930 White
4392901 Biscuit

PAINT, BULK (1 qt.)

799344 White (Uncut)
4392900 Biscuit (Uncut)

ACCESSORY PARTS

685463 Kit, Grounding
Plug, Dryer
Side Panel
692790 White
3977784 Biscuit

OIL

350572 Oil, Gearcase
(16 Oz.)

LUBRICANT

285208 Lubricant (Use
Only in Brake
Shoe Assembly
On Roller and
Pin)

SEALER

285195 Sealer, Gasket
(.20 Fl. Oz.)
(6 ml)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST