

AMCOR Rainfall Dual Showers

Shower Options

See other side for easy step by step instructions.

Use One or Two Shower Heads!



Shower Heads have 5 Functions!

1. Spray



2. Jet



3. Massage



4. Spray & Jet



5. Spray & Massage



NOTES: You can use a wrench to tighten connections at any step. • When tightening, put a rag around the shower connections to protect them.



QUESTIONS? Contact us at 1-800-245-8646 or www.amcorgroupusa.com
Amcor, Inc. 685-A Gotham Parkway · Carlstadt, NJ 07072

AMCOR Rainfall Dual Showers

Installation Instructions

To ensure satisfying performance, please read and follow these easy step by step instructions.

Parts:



Assembly:




1. All you need is a wrench
OR pliers.




2. Remove your existing
shower head.




3. Clean the shower arm. Lightly
wrap white tape (included)
around threads of shower arm.



4. Attach Part A to shower arm
with shower head facing down.



5. Attach Part B to Part A.



6. Attach Part C to Part B.



7. Adjust all parts as desired.



NOTES: You can use a wrench to tighten connections at any step. • When tightening, put a rag around the shower connections to protect them.

QUESTIONS? Contact us at 1-800-245-8646 or www.amcorgroupusa.com
Amcors, Inc. 685-A Gotham Parkway · Carlstadt, NJ 07072