


ATD-10702



ORDERING PART#	ITEM#	PART DESCRIPTION
PRT10702-01	1	FRONT COVER ASSY
PRT10702-02	2	RUBBER WASHER
PRT10702-03	3	WASHER A
PRT10702-04	4	FRONT IMPACT ASSY
PRT10702-05	5	REAR IMPACT ASSY
PRT10702-06	6	GEAR RING HOUSING
PRT10702-07	7	GEAR RING
PRT10702-08	8	PLANETARY GEARS
PRT10702-09	9	PINION
PRT10702-10	10	MOTOR ASSY
PRT10702-11	11	FORWARD/REVERSE ROD
PRT10702-12	12	SWITCH
PRT10702-13	13	BATTERY CONNECTOR ASSY

ORDERING PART#	ITEM#	PART DESCRIPTION
PRT10702-14	14	MAIN HOUSING L&R
PRT10702-15	15	SOFT GRIP
PRT10702-16	16	HANDSTRAP
PRT10702-17	17	HOUSING SCREW
PRT10702-18	18	FRONT COVER SCREW
ATD10703	19	BATTERY FOR 10702
N/A	20	LEFT NAMEPLATE
N/A	21	RIGHT NAMEPLATE
PRT10702-22	22	SCREW
PRT10702-23	23	SIDE HANDLE
PRT10702-24	24	CHARGER
PRT10702-25	25	WASHER B
PRT10702-26	26	O-RING