

# The Ultimate Water Broom™/MC

4515-890

## 2 IN 1 Wash and sweep at the same time Lavez et balayez en même temps

READ THE COMPLETE INSTRUCTION SHEET BEFORE FIRST USE.

- Connects to any standard garden hose
- Works with standard thread or Quick Connect hose fittings
- Pressure control lever
- Ideal for decks, docks, patios, pools, entryways, walkways, driveways, garage floors and siding
- Use wet or dry
- Telescopic, aluminum handle extends to 5' / 1.5 m
- 13" / 33 cm broom head

### ASSEMBLY

1. Attach the water flow adjustment nozzle to the top of the handle. Screw on until snug. DO NOT over tighten.
2. Screw the telescopic handle into the broom head. DO NOT over tighten.
3. Select either standard hose thread connection or quick connect. If using quick connect attach the quick connect adapter into the water flow adjustment nozzle. then attach a hose with a quick connector to the quick connect adapter. If using the standard hose thread connection simply screw the hose into the water flow adjustment nozzle.
4. Adjust the telescopic handle to the desired length.
5. Set the water flow lever to low then turn on the water supply.
6. Adjust the water flow to the desired pressure and begin scrubbing. Suitable for outdoor use only.

**WARNING: Use appropriate pressure while scrubbing to avoid scratching. Not for use on sensitive surfaces. Stiff bristles can harm tile, synthetic, painted and sensitive surfaces. Always test in an inconspicuous area before first use.**

### BIEN LIRE LE MANUEL D'INSTRUCTIONS EN ENTIER AVANT D'UTILISER POUR LA PREMIÈRE FOIS.

- Se branche à tout tuyau d'arrosage standard
- Convient aux raccords de tuyau à filetage standard ou aux raccords rapides
- Manette de commande de la pression
- Idéal pour les terrasses, quais, patios, piscines, entrées de maison, allées, entrées d'auto, planchers de garage et parements
- S'utilise à sec ou mouillé
- Manche télescopique en aluminium pouvant s'allonger jusqu'à 5 pi/1,5 m
- Tête de balai de 13 po/33 cm

### ASSEMBLAGE

1. Raccordez le dispositif de régulation du débit d'eau au haut du manche. Vissez jusqu'à ce que les deux pièces soient solidement connectées. ÉVITEZ de trop serrer.
2. Vissez le manche télescopique dans la tête du balai. ÉVITEZ de trop serrer.
3. Choisissez un raccord de tuyau standard ou un raccord rapide. Dans le cas d'un raccord rapide, insérez l'adaptateur de raccordement rapide dans le dispositif de régulation du débit d'eau, puis branchez un tuyau à raccord rapide à l'adaptateur. Si vous utilisez le raccord de tuyau standard, vissez tout simplement le tuyau dans le dispositif de régulation du débit d'eau.
4. Réglez le manche télescopique à la longueur désirée.
5. Réglez la manette de débit d'eau au niveau faible, puis ouvrez l'arrivée d'eau.
6. Ajustez le débit d'eau à la pression désirée et commencez à frotter. Pour usage extérieur seulement.


**MISE EN GARDE : Utiliser une pression appropriée pour frotter sans rayer. Ne convient pas aux surfaces sensibles. Les poils raides du balai risqueraient d'abîmer les surfaces en céramique, synthétiques, peintes et fragiles. Toujours faire un premier essai sur une partie discrète.**

- Hose quick connection adapter
- Adaptateur de raccordement rapide



- Pressure control lever
- Manette de commande de la pression

- Telescopic, aluminum handle extends to 5' / 1.5 m
- Manche télescopique en aluminium pouvant s'allonger jusqu'à 5 pi / 1,5 m



- 13" / 33 cm broom head
- Tête de balai de 13 po / 33 cm



MADE IN CHINA / FABRIQUÉ EN CHINE  
**HOME HARDWARE STORES LIMITED**  
ST. JACOBS, ONTARIO N0B 2N0  
www.homehardware.ca  
**4515-890**  
© 08/2013 Home Hardware Stores Limited

### The Ultimate Water Broom™/MC

The Ultimate Water Broom is exclusive to Home Hardware and guaranteed against defects in material and workmanship, not against wear or misuse.

The Ultimate Water Broom est vendu en exclusivité chez Home Hardware et est garanti contre tout vice de matière et de fabrication, mais pas contre l'usure ou le mauvais usage.



F