

M-450

SONY

Pressman® Microcassette Recorder

- LED BATTERY LEVEL INDICATOR
- 30 HOUR BATTERY LIFE
- ▶ CLEAR VOICE™ RECORDING SYSTEM
- ▶ INCLUDES 1 CASSETTE AND 2 BATTERIES
- BUILT-IN MICROPHONE
- ONE TOUCH RECORDING
- CUE AND REVIEW WITH SLIDE CONTROL
- SONY-MATIC® AUTOMATIC RECORDING LEVEL CONTROL
- AUTOMATIC SHUT OFF AT END OF TAPE
- 2-SPEED RECORD/PLAYBACK
- BATTERY LED
- DC-IN JACK
- L/R MONAURAL EARPHONE JACK
- HINGED BATTERY LID

▲ STEP-UP FEATURE ▶ NEW FEATURE



PRESSMAN

features

- **LED BATTERY LEVEL INDICATOR** provides visible indication of battery power remaining
- **30 HOUR BATTERY LIFE** is made possible by advanced technology which extends battery power beyond previous limits
- ▶ **CLEAR VOICE™ RECORDING SYSTEM** improves and enhances voice quality during record and playback
- ▶ **INCLUDES 1 CASSETTE AND 2 BATTERIES** so this Pressman® recorder is ready to go to work for you, right out of the box
- **BUILT IN MICROPHONE** for extra convenience, eliminates the need for an external microphone
- **ONE TOUCH RECORDING** for simplified, quick Play/Record operation
- **CUE AND REVIEW WITH SLIDE CONTROL** provides sound during Fast Forward and Rewind modes to help find specific passages
- **SONY-MATIC® AUTOMATIC RECORDING LEVEL CONTROL** uses advanced circuitry to ensure correct recording level
- **AUTOMATIC SHUT OFF AT END OF TAPE** pops up buttons to conserve battery power, reduces mechanical wear, and alerts you that the end of the tape has been reached
- **2-SPEED RECORD/PLAYBACK** gives you the option of recording on a standard microcassette at either normal speed of 2.4cm/sec or half the normal speed at 1.2cm/sec for extended recording or dictation sessions
- **BATTERY LED** provides visible indication of battery power remaining
- **BUILT-IN SPEAKER** has excellent quality to monitor tape playback
- **DC-IN JACK** for 2-way operation using replaceable batteries or with optional AC adaptor
- **L/R MONAURAL EARPHONE JACK** provide sound in both ears when using with an optional stereo headset
- **HINGED BATTERY LID** helps prevent accidental loss when changing batteries

specifications

TAPE SYSTEM: 2-Track 1-Channel monaural

FREQUENCY RESPONSE: 250-4000Hz

INPUTS: DC-In, 3V

OUTPUTS: Earphone/Headphones

SPEAKER: 1" (28mm)

POWER REQUIREMENTS: DC 3V with "AA" x 2 batteries (supplied)
AC 120V, 60Hz with optional AC adaptor

COLOR: Black

DIMENSIONS (WHD): 4 5/8" x 2 1/2" x 1" (119.2 x 62.2 x 25.4mm)

WEIGHT: 3 7/8 oz (109g)

SUPPLIED ACCESSORIES: Microcassette, "AA" Batteries x 2

OPTIONAL ACCESSORIES: AC-E30HG AC Adaptor, MC-60 Microcassettes

©2002 Sony Electronics Inc.

Reproduction in whole or in part without written permission is prohibited. All rights reserved.

Sony, Clear Voice, Pressman and Sony-Matic are trademarks of Sony.

Features and specifications are subject to change without notice. Non-metric weights and measures are approximate.