


Spare Parts List

2006-03



PB-500 R


IMPORTANT! - To assure product SAFETY and RELIABILITY, repairs, maintenance or adjustments should be performed by DOLMAR Service Centers, or other qualified service organisations. Always use DOLMAR replacement parts.

DOLMAR



A member of the *Makita* Group

995 700 258 (GB)




PB-500 R

DOLMAR



Page	Pos.	PB-500 R	Part No.	Notes	Description	Specifications
1	1	1	377 150 020		VOLUTE CASE 1	
1	2	1	377 100 400		VOLUTE CASE 2 CPL.	
1	3	10	377 005 987		TAPPING SCREW	M5X25
1	4	2	377 360 525		P. H. SCREW	M5X25
1	5	2	381 170 500		NUT	M5
1	6	1	377 100 600		ELBOW CPL.	
1	7	1	377 263 085		O-RING	
1	8	2	377 100 500		BRACKET CPL.	
1	9	2	368 150 030		SPACER	
1	10	4	377 005 991		TAPPING SCREW	M5X10
1	11	2	377 370 500		FLANGE NUT	M5
1	12	2	377 150 040		DAMPER	
1	13	2	377 170 600		NUT	M6
1	14	2	388 370 600		FLANGE NUT	M6
1	15	1	377 150 021		IMPELLER	
1	16	3	377 130 625		BOLT & WASHER ASS'Y	
1	17	1	377 200 800		FRAME CPL.	
1	18	2	377 250 060		SIDE FRAME	
1	19	1	377 250 070		KNOB	
1	20	9	374 005 943		P. H. SCREW	M5X25
1	22	11	377 370 500		FLANGE NUT	M5
1	23	1	374 201 000		CUSHION	
1	24	4	377 250 020		LOCK RIVET	
1	25	2	374 005 943		P. H. SCREW	M5X25
1	26	1	377 605 900		FUEL TANK CAP CPL.	
1	28	1	377 300 300		TUBE	
1	29	1	382 650 390		FILTER	
1	30	1	377 300 500		FUEL TANK	
1	31	1	377 850 220		SPIRAL TUBE	L = 170
1	32	1	377 850 110		CLAMP	M6XL=73
1	33	1	374 800 500		ENGINE COVER CPL.	INC. 34-39, 40
1	34	1	381 501 511		SCREW	
1	35	1	382 500 301		REEL	
1	36	1	382 500 302		SPIRAL SPRING	
1	37	1	382 500 303		WASHER	
1	38	1	382 500 114		STARTER ROPE	
1	39	1	382 500 211		STARTER KNOB	
1	40	1	377 501 100		PULLEY UNIT	INC. 41-43
1	41	1	374 501 101		RATCHET	
1	42	1	374 501 102		RETURN SPRING	
1	43	1	374 500 304		E-RING	
1	44	1	383 006 992		WASHER	M6
1	45	1	381 130 616		BOLT ASS'Y	
1	46	8	377 360 620		SCREW	M6X20
1	400	2	377 902 100		BAND SET	
1	401	1	377 901 900		HOSE CLAMP	
1	402	1	377 902 000		HOSE CLAMP	
1	403	1	377 950 690		FLEXIBLE PIPE	
1	404	1	377 901 701		PIPE 1	
1	405	1	377 901 702		PIPE 2	
1	406	1	377 950 670		END PIPE	
1	407	1	377 900 100		TOOL KIT	





PB-500 R

DOLMAR



Page	Pos.	PB-500 R	Part No.	Notes	Description	Specifications
2	47	1	374 100 700		CRANKCASE ASS'Y	INC. 48-52
2	48	1	374 017 993		OIL SEAL	
2	49	1	374 015 997		OIL SEAL	
2	50	1	374 017 983		BALL BEARING	6203C3
2	51	1	374 015 006		BALL BEARING	
2	52	1	377 150 120		CRANKCASE GASKET	
2	53	1	377 150 180		CYLINDER	
2	54	1	377 150 051		CYLINDER GASKET	
2	55	4	377 906 999		H.S.H. BOLT	M6X18
2	56	4	377 905 994		H.S.H. BOLT	M5X30
2	57	1	377 202 400		CRANKSHAFT CPL.	
2	58	1	377 250 071		PISTON	
2	59	1	377 250 110		PISTON PIN	
2	60	2	377 250 090		PISTON RING	
2	61	1	377 012 995		NEEDLE ROLLER BEARING	
2	62	2	377 511 999		CLIP	
2	63	1	381 320 310		WOODRUFF KEY	
2	64	1	377 304 500		EXHAUST MUFFLER	
2	65	1	377 304 600		INSULATOR CPL.	
2	66	1	377 350 170		MUFFLER GASKET	
2	67	2	377 350 200		BOLT	M6X13
2	68	2	377 009 999		WASHER	M6
2	69	1	377 150 616		BOLT	M6X16
2	70	1	377 303 600		LEAD VALVE ASS'Y	
2	71	1	377 350 280		BRACKET GASKET	
2	72	1	377 350 060		INSULATOR GASKET	
2	73	4	377 905 963		S.H. BOLT	M5X20
2	74	1	377 702 101		FLYWHEEL	
2	75	1	377 702 402		COIL	
2	76	1	374 500 994		PLUG CAP	
2	77	1	377 400 993		PLUG CAP SPRING	
2	78	1	374 014 966		SPARK PLUG	
2	79	1	377 130 816		BOLT & WASHER ASS'Y	
2	80	1	377 110 800		WASHER	
2	81	2	377 905 979		H.S.H. BOLT	M5X22
2	82	4	377 130 625		BOLT & WASHER ASS'Y	
2	83	1	377 800 301		WIRE CPL.	
2	122	1	377 304 800		CLEANER PLATE ASS'Y	
2	123	1	377 350 700		AIR CLEANER CASE	
2	124	2	377 350 710		AIR CLEANER ELEMENT	
2	125	2	377 350 720		AIR CLEANER GASKET	
2	126	1	367 360 514		SCREW ASS'Y	M5X14
2	127	1	377 650 430		CARBURETOR GASKET	
2	128	2	377 360 555		SCREW	
2	129	1	377 650 460		CABLE BRACKET	
2	130	1	381 600 801		CABLE ADJUST SCREW	
2	131	1	377 270 600		NUT	M6
2	132	1	377 350 790		CARBURETOR GASKET	
2	133	1	377 350 780		PLATE	



PB-500 R						
Page	Pos.	PB-500 R	Part No.	Notes	Description	Specifications
3	84	1	377 604 301		CARBURETOR	INC. 85 - 121
3	85	1	377 604 343		STRAINER	
3	86	1	377 604 346		RETAINER	
3	87	1	377 604 302		THROTTLE SHAFT ASS'Y	
3	88	1	377 604 352		THROTTLE LEVER	
3	89	1	377 604 303		THROTTLE RETURN SPRING	
3	90	1	377 604 304		THROTTLE VALVE	
3	91	1	377 604 326		DIAPHRAGM ASS'Y	
3	92	1	377 604 311		PUMP DIAPHRAGM	
3	93	1	377 604 331		METERING CHAMBER GASKET	
3	94	1	377 604 312		PUMP GASKET	
3	95	1	377 604 321		INLET NEEDLE VALVE	
3	96	1	377 604 322		METERING LEVER SPRING	
3	97	1	377 604 323		METERING LEVER	
3	98	1	377 604 324		PIN	
3	99	1	377 604 335		MAIN MIXTURE SCREW	
3	100	1	377 604 336		IDLE MIXTURE SCREW	
3	101	1	957 377 500		CHOKE SHAFT ASS'Y	
3	102	1	377 604 362		CHOKE VALVE	
3	103	1	377 604 354		POST	
3	104	1	377 604 332		PRIMER BASE ASS'Y	
3	105	1	377 604 351		SYRINGE	
3	106	1	377 604 325		SCREW	
3	107	2	377 604 305		SCREW	
3	108	2	377 604 334		SCREW	
3	109	1	377 604 316		SCREW	
3	110	1	377 604 353		SCREW	
3	111	2	377 604 306		E-RING	
3	112	1	377 604 333		RETAINER SCREW	
3	113	1	377 604 385		COLLAR	
3	114	1	377 604 376		TAMPER RESIST LIMITER (R)	
3	115	1	377 604 381		TAMPER RESIST LIMITER (W)	
3	116	1	377 604 364		CHOKE RETURN SPRING	
3	117	1	374 604 356		CHOKE CONTROL LEVER	
3	118	1	377 604 366		CHOKE LEVER	
3	119	1	377 604 361		CHOKE SHAFT COLLAR	
3	120	1	377 604 371		CHOKE LEVER SCREW	
3	121	1	377 604 382		PUMP COVER KIT	
3	134	1	377 500 100		CONTROL LEVER ASS'Y	INC. 135-150
3	135	1	377 550 050		CASE COVER	
3	136	1	377 500 300		SWITCH CPL.	
3	137	1	377 550 060		THROTTLE LEVER 1	
3	138	1	377 550 070		THROTTLE LEVER 2	
3	139	1	377 500 400		PLATE CPL.	
3	140	1	377 550 090		TORSION SPRING	
3	141	1	377 013 990		CONTROL CABLE	
3	142	1	377 550 100		CABLE TUBE	
3	143	1	377 550 170		S.H. BOLT	M6X30
3	144	1	377 004 997		TAPPING SCREW	
3	145	2	388 110 600		WASHER	
3	146	1	377 220 600		WAVE WASHER	
3	147	1	377 270 600		NUT	M6
3	148	4	377 004 994		TAPPING SCREW	M4X16
3	149	1	377 360 525		P. H. SCREW	M5X25
3	150	2	377 310 520		P. H. SCREW	M5X20

1	Volute case, frame, starter, tank, accessories
2	Engine, ignition, exhaust muffler, air cleaner
3	Control lever, carburetor

	Key to symbols
⇒ 1999999 2000000 ⇒ 2003.04 ⇒ TI 2003/07 Acc. = { m Corr.	Production to serial number New part from serial number New part from Year / Month See Technical Information Year / No. Accessories (not included in the delivery inventory) No standard execution, may be used Contains item number Sold by the meter Error correction
	Specifications subject to change without notice