

American DJ® User Instructions

MINE™

HALOGEN LAMP WARNING!

This fixture is fitted with halogen lamps which are highly susceptible to damage if improperly handled. Never touch lamp with bare fingers as the oil from your hands will shorten lamp life. Also, never move fixture until lamp has had ample time to cool. Remember, lamps are not covered under warranty conditions.

Caution! Always disconnect from main power before replacing lamps or servicing unit. Remember to always replace with same lamps and fuses.

Model: **MINE™**

SPECIFICATIONS:

Lamp: 2 x ZB-64514 120V 300W,

Dimensions: 16" x 12" x 11"

Weight: 11 lbs.

Supply Voltage: 120V

Fuse: 7A

Working Position: Any Safe position

Duty Cycle: 10 min., on, 10 min. off

Colors: Multiple Colored Lens

Optional: ZB-ADJ300 120V 300W 150 hr.

Long Life lamp also available.



Thank you for purchasing this American DJ® product. For your convenience this lighting effect has been lamped and is ready to be used, there is no assembly required. Please read the following instructions before installing or using your new unit.

Product Description:

Dual rotating disks on attached base

Operating Instructions:

Unit is ready to be hung or set on flat surface. Be sure not to obstruct cooling vents and keep in a well ventilated area. Fog best results, fog or special effects smoke must be used in order to see the beams of light.

Caution! Never open unit when in use. Always disconnect main power before serving or replacing lamp. Remember always replace same lamp and fuses.

Lamp replacement: Remove thumb screws on side of each disk and disconnect socket from rear of lamp. Remove and replace lamps..

For service, contact your American DJ® dealer.