

# VIDEONOW™

## COLOR

### Car Adaptor


#### IMPORTANT SAFETY INSTRUCTIONS

1. SAVE THESE INSTRUCTIONS - This manual contains important safety and operating instructions for Car Adaptor Product 73988.
2. Before using car adaptor, read all instructions and cautionary markings on car adaptor, battery and product using battery.
3. Do not expose the car adaptor to rain, moisture, or snow.
4. Use of an attachment not recommended or sold by the car adaptor manufacturer may result in a risk of fire, electric shock, or injury to persons.
5. To reduce risk of damage to the adaptor and cord, pull by adaptor connector rather than cord when disconnecting adaptor.
6. Make sure cord is located so that it will not be stepped on, tripped over, or otherwise subjected to damage or stress.
7. Do not operate car adaptor with damaged cord - replace it immediately.
8. Do not operate car adaptor if it has received a sharp blow, been dropped, or otherwise damaged in any way, take it to a qualified service person.
9. Do not disassemble adaptor, take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of electric shock or fire.
10. To reduce risk of electric shock, unplug adaptor before attempting any maintenance or cleaning. Turning off controls will not reduce this risk.

Adult Supervision Required

Thank you for purchasing the **VIDEONOW** COLOR Car Adaptor. Be sure to read and follow all instructions carefully before using this product.

NOTE: The **VIDEONOW** COLOR Car Adaptor does not charge the batteries in your player. It simply powers your player, so that you do not waste your batteries.



© 2004 Hasbro. All Rights Reserved.  
 ® denotes Reg. U.S. Pat. & TM Office.  
 73988 P/N 6352360200

**TIGER**  
 ELECTRONICS

Where Technology Comes to Play!™



Questions? Call 1-800-327-8264