

PARTS LIST

for

KitchenAid®

MIDLINE 2-SLICE TOASTER

MODELS:

KMTT200OB0 (Onyx Black)
KMTT200BW0 (Blue Willow)
KMTT200ER0 (Empire Red)
KMTT200GC0 (Gloss Cinnamon)
KMTT200SS0 (Stainless Steel)




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



UNIT PARTS

For Variations of Models: KMTT200__0



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8212358	Use & Care Guide
	8212307	Repair Parts List
2	◆	Unit, Toaster
3	8212355	Knob, Lifter
4	8212356	Knob, Control
5	8212354	Foot, Rubber
6	8212352	Handle, Tray
7	8212353	Tray, Crumb

◆ **Note:**
 Parts not sold separately.
 Must be purchased as a
 complete unit.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST