


# Life Fitness

ARCTIC SILVER SUMMIT 95LEZ-0XXX-01



Customer Support Services  
**PARTS MANUAL** revised 26 Feb 2008


	Page
Miscellaneous .....	3
Console Support and Dead shaft Covers .....	4
User Arms and Hardware .....	5
Monocolumn, Handrail and Vertical Uprights.....	6
Console and Related Components .....	7
Entertainment TV Console.....	8
Connector Bracket.....	9
Entertainment Mounting Bracket .....	10
Shrouds, Boot and Rear Step Assembly .....	11
Rocker Arms and Control Link Assy”s .....	12
Rocker Arm/Control Link Covers .....	13
Pedal Track Covers and Hardware.....	14
Pedals, Truck and Rollers Assembly .....	15
Resistor Assembly and Crossover Pulley .....	16
Flexonic Belts and Tensioner Bracket .....	17
Clutch Shaft and Sprockets .....	18
Clutch Pulley and Shaft Assembly.....	19
Timing Belts and Springs.....	20
Power Control Board, Battery and Alternator.....	21
Wheels and Leg levelers .....	22
Lower Track Cover and Hardware.....	23
Cables .....	24


OPERATION MANUAL – (ENG)	M051-00K68-A001
OPERATION MANUAL – (F/S/P)	M051-00K68-A002
OPERATION MANUAL – (G/D/I)	M051-00K68-A003
OPERATION MANUAL – (JAP)	M051-00K68-A004
TOUCH UP PAINT: SPRAY CAN	0017-00008-0204
.5 OZ BOTTLE W/APPLICATOR	0017-00008-0205
.33 OZ PEN	0017-00008-0206
SERVICE MANUAL	M051-00K68-A030
PCB/ACCESS PANEL ASSY. ASSEMBLY CONSISTS OF:	AK68-00107-0000
1) 120" COAX CABLE	AK32-00020-0002
2) 120" POWER EXTENSION CABLE	AK32-00078-0001
3) ACCESS PANEL BRACKET	0K68-01031-0000
4) F TYPE CONNECTOR	0017-00021-2846
5) PLASTIC GROMMET (QTY. 2)	0017-00042-0821
HARDWARE BAG	AK68-00198-0000

**Note: This model is a combination of the attachable LCD TV ( LCDXEZ-XXXX-01) and a base unit ( 95LWEZ-XXXX-01). This model comes with both Telemetry and Life Pulse sensors for reading Heart Rate.**

**ARCTIC SILVER SUMMIT 95LEZ**  
**Console Support & Dead shaft Covers**

**95LEZ-0XXX-01**  
**S/N LWE100000 and up**





Right User Arm with grip

AK68-00143-0001

Left User Arm with grip

AK68-00143-0002

Grip


0K62-01138-0000

(3) User Arm Mtg. Screws

0017-00101-1791

**ARCTIC SILVER SUMMIT 95LEZ**  
**Monocolumn, Handrail and Vertical Uprights**

**95LEZ-0XXX-01**  
**S/N LWE100000 and up**




# ARCTIC SILVER SUMMIT 95LEZ

## Console and Related Components

95LEZ-0XXX-01


S/N LWE100000 and up



CONSOLE ASSY		OVERLAY/BEZEL/SWITCH ASSY	
AK68-00187-0001	ENG/LED	AK68-00188-0001	ENG/LED
AK68-00187-0002	ENG+MET	AK68-00188-0001	ENG/LED
AK68-00187-0003	GER/MET	AK68-00188-0003	GER/MET
AK68-00187-0004	SPN/MET	AK68-00188-0004	SPN/MET
AK68-00187-0006	JAP/LED	AK68-00188-0006	JAP/LED
AK68-00187-0007	FRN/MET	AK68-00188-0007	FRN/MET
AK68-00187-0008	ITL/MET	AK68-00188-0008	ITL/MET
AK68-00187-0009	DUT/MET	AK68-00188-0009	DUT/MET
AK68-00187-0010	POR/MET	AK68-00188-0010	POR/MET
AK68-00187-0014	ENG/TUR	AK68-00188-0001	ENG/LED

**ARCTIC SILVER SUMMIT 95LEZ**  
**Entertainment TV Console**


**95LEZ-0XXX-01**  
**S/N LWE10000 and up**






**ARCTIC SILVER SUMMIT 95LEZ**  
**Connector Bracket**

**95LEZ-0XXX-01**  
**S/N LWE100000 and up**



**ARCTIC SILVER SUMMIT 95LEZ**  
**Entertainment Mounting Bracket**

**95LEZ-0XXX-01**  
**S/N LWE100000 and up**





**ARCTIC SILVER SUMMIT 95LEZ**  
**Shrouds, Boot and Rear Step Assembly**


**95LEZ-0XXX-01**  
**S/N LWE100000 and up**

Monocolumn Boot  
0K68-01061-0000

Right Shroud Assembly  
AK68-00176-0000  
Left Shroud Assembly  
AK68-00176-0001  
Shroud Mtg. Screws  
( 6 per shroud)  
0017-00101-1796





Rear Step (plastic only)  
0K68-01020-0000  
Rear Step Assembly  
AK68-00136-0000  
(3) Rear Step  
Mounting Screws  
0017-00101-1903




**ARCTIC SILVER SUMMIT 95LEZ**  
**Rocker Arm/Control Link Covers**

**95LEZ-0XXX-01**  
**S/N LWE100000 and up**



Right Clevis Cover Assy.  
AK68-00154-0001




Left Clevis Cover Assy.  
AK68-00154-0002

# ARCTIC SILVER SUMMIT 95LEZ

## Pedal Track Covers and Hardware


95LEZ-0XXX-01

S/N LWE100000 and up




**ARCTIC SILVER SUMMIT 95LEZ**  
**Pedals, Truck and Rollers Assembly**

**95LEZ-0XXX-01**  
**S/N LWE100000 and up**



**ARCTIC SILVER SUMMIT 95LEZ**  
**Resistor Assembly and Crossover Pulley**


**95LEZ-0XXX-01**  
**S/N LWE100000 and up**






**ARCTIC SILVER SUMMIT 95LEZ**  
**Flexonic Belts and Tensioner Bracket**

**95LEZ-0XXX-01**  
**S/N LWE100000 and up**




**ARCTIC SILVER SUMMIT 95LEZ**  
**Clutch Shaft and Sprockets**

**95LEZ-0XXX-01**  
**S/N LWE10000 and up**




**ARCTIC SILVER SUMMIT 95LEZ**  
**Clutch Pulley and Shaft Assembly**

**95LEZ-0XXX-01**  
**S/N LWE100000 and up**



Note: The following parts are used on each end of both Timing Belts:

- Belt Terminator  
0K35-01105-0000
- Bracket  
0K35-01142-0000
- (2) Screws  
0017-00101-1904
- (2) Washers  
0017-00104-0469



Upper Timing Belt  
AK68-00210-0000

- Upper Spring  
0K68-01051-0000
- Lower Spring  
0K68-01081-0000
- Spring Mounting  
Screws ( 1 per spring)  
0017-00101-1902
- Washer ( 1 per spring)  
0017-00104-0465


- Crossover Pulley  
AK68-00104-0000
- Pulley Mtg. Screw  
0017-00101-1911
- Nut  
0017-00103-0332
- Lower Timing Belt  
AK68-00211-0000

# ARCTIC SILVER SUMMIT 95LEZ

## Lower PCB, Battery and Alternator


95LEZ-0XXX-01


S/N LWE100000 and up



**ARCTIC SILVER SUMMIT 95LEZ**  
**Access Panel, Wheels and Leg Levelers**

**95LEZ-0XXX-01**  
**S/N LWE100000 and up**





**Lower Track Cover Assembly**

AK68-00220-0000

Mounting Screw (3)

0017-00101-1906

Washer, Nylon (3)

0017-00104-0485

Flat Washer (3)

0017-00104-0479

# ARCTIC SILVER SUMMIT 95LEZ

## Cables

95LEZ-0XXX-01  
S/N LWE10000 and up

