



IMPORTANT — To assure product SAFETY and RELIABILITY, repairs, maintenance or adjustments should be performed by MAKITA Service Centers or other qualified service organizations. Always use MAKITA replacement parts.

Fig.	Part No.	Qty. Used	Description	Fig.	Part No.	Qty. Used	Description
1	183032-3	1	HOUSING Set (Incl. Fig. 20)	16	191971-3	1	CARBON BRUSH Set
3	266130-9	8	T. SCREW BIND PT 3x16	17	643929-3	2	HOLDER CAP
4	344391-2	2	BIT HOLDER	18	266134-1	3	T. SCREW ST 4x8
5	654168-0	1	SPRING TERMINAL (+)	19	265999-8	4	T. SCREW FLANGE 4x25
6	654169-8	1	SPRING TERMINAL (-)	20	183032-3	1	HOUSING Set (Incl. Fig. 1)
7	687085-9	1	HOLDER	22	122575-0	1	GRIP Ass'y
8	651968-9	1	SWITCH				
9	416079-5	1	F/R CHANGE LEVER	<u>ACCESSORIES</u>			
10	125091-1	1	SPEED CHANGE LEVER (Incl. 2 ea. 231433-0 Compression Spring 4)	400	763140-2	1	KEYLESS DRILL CHUCK 13
11	251465-1	1	F. H. SCREW M6x32	401	122576-8	1	STOPPER POLE
13	125088-0	1	GEAR HOUSING Ass'y	402	784614-0	1	PHILLIPS/SLOTTED BIT 2-45
14	629729-5	1	DC MOTOR (Incl. Fig.16, 17 & 226361-2 Spur Gear 20)	403	414938-7	1	BATTERY COVER
15	911006-2	1	P.H. SCREW M3x8	404	192827-3	2	BATTERY 1822
				405	DC1801	1	BATTERY CHARGER
				406	824525-8	1	PLASTIC CARRYING CASE

2 Model 6343DWAE

09-98