

2

Warm water changes color.

Empty water into drain after play.

3

Color change will last longer if you do not expose this toy to intense heat or direct sunlight for prolonged periods of time.

FEATURING: MULTI-COLOR CHANGE!

● Purple ● Red ● Yellow

ICY WATER WARM WATER WARMER WARMER ICY WATER (AGAIN!)

Not for use with some Hot Wheels® vehicles

More Ways TO PLAY

Drain, rinse, clean and dry all items thoroughly before storing.

Hot Wheels

DR. BONES COLOR LAB™

COLOR SHIFTERS
WATER CHANGES THE COLOR!

INSTRUCTIONS

Please keep these instructions for future reference as they contain important information.

CONTENTS

4+ **MATTEL**
R1199-0920

© 2010 Mattel, Inc. All Rights Reserved. Consumer Relations - Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. - 1-800-524-8697. service.mattel.com • Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at 1-800-524-8697. • Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB. Helpline 01628500303 • Mattel Australia Pty., Ltd., Richmond, Victoria. 3121. Consumer Advisory Service - 1300 135 312. • Mattel East Asia Ltd., Room 1106, South Tower, World Finance Centre, Harbour City, Tsingshatsui, HK, China. • Distributor & Dealer: Mattel SEA Ptd Ltd. (993532-P) Lot 13.5, 13th Floor, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410 PJ. Tel: 03-78803817, Fax: 03-78803867.

ASSEMBLY

1

2

3

4

5

6

7

Right Side View

One-time snap assembly.

GET READY TO PLAY

86°F/30°C-104°F/40°C WARM WATER

Do not fill past the top of line or spillage may occur.

To avoid burns do not use water that is too hot, above 120°F/48°C.

For best performance of color change feature, please use icy water under 50°F/10°C.

Icy water

Icy water

Do not fill past the top of line or spillage may occur.

Water toys sometimes get messy. Protect play surfaces before use.

86°F/30°C-104°F/40°C WARM WATER

TO PLAY

Icy water changes color.