


mellerware®

E X E C U T I V E

Jupiter Stove-top Kettle



complies with
INTERNATIONAL
IEC60335
SAFETY SPECIFICATIONS

CE
2 YEAR
GUARANTEE

Model:
44000

PLEASE READ ALL INSTRUCTIONS BEFORE USE

2 year guarantee

Please read these instructions carefully and retain for future reference.

Instruction for use:

1. Remove the lid
2. Pour in the desired amount of tap water, taking care not to exceed the maximum fill mark
3. Replace the lid and make sure the spout cover is in place
4. Place the kettle onto the hob or gas burner until you hear the ready whistle
5. **CAUTION:** the handle and spout maybe hot
6. Remove immediately from the heat surface using an oven glove to hold the handle
7. Carefully remove the spout cover to pour out water, again using the oven glove

Caring for your kettle:

1. Take care when removing the product from its packaging
2. Before the first use; wash each piece in hot, soapy water and rinse thoroughly and then dry with a cloth
3. Always dry the kettle thoroughly after washing
4. Never leave the kettle to soak in water for extended periods of time
5. Never use an abrasive cleaner as it may scratch or damage the surface of the kettle
6. This product is dishwasher safe

Some simple precautions:

1. Do not overfill your kettle
2. Always ensure there is sufficient water in the

3. kettle before placing on a heated surface
3. Do not allow any part of the kettle to extend beyond the surface of the heated surface
4. Always ensure that the flame on your hob and gas burner is properly controlled and does not flare up the sides of the kettle and over-heat the handle. This can cause burns to an unprotected hand and will waste gas.
5. Keep children away from the heated surface
6. Before cleaning, always ensure that the kettle has cooled completely
7. Never use the kettle when it is empty as this may damage the kettle
8. Never leave a boiling kettle unattended

creative housewares

27 Nourse Avenue Epping 2 Cape Town
P.O. Box 975 Eppindust 7475 South Africa
Tel: +27 21 534 8114 Fax: +27 21 534 8086
Service Centre Share Call: 086 111 5006
web: www.creativehousewares.co.za