

# OWNER'S MANUAL

Model No. SG8SS

# Salton®

**AUTOMATIC SALT/PEPPER MILL**



**salton®**

## **IMPORTANT SAFEGUARDS**

When using this appliance, basic safety precautions should always be followed including the following:

### **READ ALL INSTRUCTIONS BEFORE USING**

- 1 Do not immerse the unit in water or any liquid.
- 2 Do not mix old and new batteries.
- 3 Avoid contacting moving parts.
- 4 The use of attachments not recommended or sold by the manufacturer may cause injury.
- 5 Remove the batteries and store in a dry, cool place when not in use.
- 6 Don't run the motor for more than 1 minute, or it may overheat. After 1 minute, switch off for at least 3 minutes, to let the motor cool.
- 7 Don't use the appliance for any purposes other than those described in these instructions.
- 8 Don't run the appliance empty, it may overheat.
- 9 Don't use the appliance if it's damaged or malfunctions.

## **SAVE THESE INSTRUCTIONS**

**THIS PRODUCT IS FOR HOUSEHOLD USE ONLY.**

**THIS IS NOT A TOY**

## **CARE AND MAINTENANCE**

Wipe the outside of the mills with a clean dry cloth. Don't let them get wet or damp, and don't use detergent.

### **BATTERY CARE**

- 1 Check that the batteries are fitted correctly - there's a guide inside the battery compartment.
- 2 Don't leave dead batteries in the appliance, they may leak over the product and surroundings.
- 3 Unless you're using the batteries regularly, it's best to remove them altogether.
- 4 When you need new batteries, change them all. Don't use new and used batteries together.
- 5 Don't use different kinds of batteries together.
- 6 Don't put old batteries in a fire or incinerator.
- 7 Don't try to recharge batteries unless they're specifically designed to be recharged.

# OPERATING INSTRUCTIONS

- 1 To open, hold the unit vertically, gripping the cover in one hand, and the grinder in the other.
- 2 Turn the cover to move the pointer ▼ from  to .
- 3 Gently lift the cover off.

## INSTALL BATTERIES FOR OPERATION

- 1 Fit 4 AA Alkaline batteries into the motor unit.
- 2 The polarities (+ and -) are marked on the battery compartment.

## FILL THE GRINDER


- 1 Lift the motor unit off the grinder.
- 2 Fill the grinder with peppercorns, sea salt, dried herbs or spices.
- 3 Don't overfill, or it won't fit together.
- 4 Align the pointers ▼ ▼ on the bottom of the motor unit with the padlocks   on the top of the grinder, and lower the motor unit on to the grinder.
- 5 The spindle should slide easily into the centre of the motor unit.
- 6 Lower the cover on to the motor unit.
- 7 Align the pointer ▼ on the cover with the open padlock , push the cover down, then turn it to align the pointer ▼ with the closed padlock .

## ADJUST THE GRINDER


- 1 Turn the whole mill upside down, and turn the knob right (-) until it won't go any further.
- 2 Now turn it left (+) a little.
- 3 Turn the mill right way up, and press and release the switch.
- 4 Check the grind size, and adjust till it's the way you want it.
- 5 Don't turn it more than 6 complete turns towards +, or you may unscrew the knob from the spindle.
- 6 Set the base down and sit the mill on the base.

## GETTING TO KNOW YOUR SALTON AUTOMATIC SALT/PEPPER MILL

Your product may vary slightly from illustration.



Cover P/N 71203  
Motor Unit P/N 71204  
Grinder P/N 71205  
Base P/N 71206



# LIMITED ONE YEAR WARRANTY

**Warranty Coverage:** This product is warranted to be free from defects in materials or workmanship for a period of one (1) year from the original purchase date. This product warranty is extended only to the original consumer purchaser of the product and is not transferable. For a period of one (1) year from the date of original purchase of the product, our Repair Center will, at its option, either (1) repair the product or (2) replace the product with a reconditioned comparable model. These remedies are the purchaser's exclusive remedies under this warranty.

**Warranty Service:** To obtain warranty service, you must call our warranty service number at 1-800-233-9054 for return instructions on how to deliver the product, in either the original packaging or packaging affording an equal degree of protection to the Repair Center specified below. You must enclose a copy of your sales receipt or other proof of purchase to demonstrate eligibility for warranty coverage.

**To return the appliance, ship to:**

ATTN: Repair Center  
708 South Missouri Street  
Macon, MO 63552 USA

**To contact us, please write to, call, or email:**

Consumer Relations Department  
PO Box 7366  
Columbia MO 65205-7366 USA  
1-800-233-9054  
E-mail:  
consumer\_relations@toastmaster.com

**What Is Not Covered:** This warranty does not cover damage resulting from misuse, accident, commercial use, improper service or any other damage caused by anything other than defects in material or workmanship during ordinary consumer use. This warranty is invalid if the serial number has been altered or removed from the product. This warranty is valid only in the United States and Canada.

**LIMITATION ON DAMAGES:** THERE SHALL BE NO LIABILITY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OR CONDITION ON THIS PRODUCT.

**DURATION OF IMPLIED WARRANTIES:** EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ALL IMPLIED WARRANTIES AND CONDITIONS, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES AND CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE OR USE ON THIS PRODUCT ARE LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may have other rights under the laws of your jurisdiction.

For more information on our products, visit our website: [www.maxim-toastmaster.com](http://www.maxim-toastmaster.com).

Made in China  
Printed in China

04/06