

You can read the recommendations in the user guide, the technical guide or the installation guide for CUISINART DTC-850. You'll find the answers to all your questions on the CUISINART DTC-850 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual CUISINART DTC-850 User guide CUISINART DTC-850 Operating instructions CUISINART DTC-850 Instructions for use CUISINART DTC-850 Instruction manual CUISINART DTC-850





Manual abstract:

Carefully lift the coffee maker from the remaining inserts. Remove the plastic bag from the coffee maker. We suggest you save all packing materials in the event that future shipping of the machine is needed. Keep all plastic bags away from children. heat are sealed in. Now, you can program your coffee maker to start brewing when you want. Simply set the desired brew time, fill the reservoir with water, put in your filter, add ground coffee and press the "ON" button. In minutes, you'll have a wonderfully fresh pot of coffee. We know the Cuisinart® Automatic Brew and Serve will bring you years of pleasure. Nothing is more satisfying than a rich cup of your favorite brew.

DESCRIPTION OF PARTS Your thermal carafe coffee maker brews fresh, filtered coffee in minutes. The thermal carafe contains a vacuum-sealed glass inner liner which delivers heat retention superior to other containers used with drip coffee makers and helps keep full coffee flavor. Reservoir Cover Thermal Carafe Swing-Out Filter Basket Brew-Through Lid Water Level Indicator Pause & Serve Programmable Control Panel Carafe Platform Cord Storage TABLE OF CONTENTS Important Safeguards Unpacking Instructions Introduction Using the Programming Feature Coffee Preparation About the Thermal Carafe Cleaning and Maintenance Features and Benefits Warranty p.1 p.2 p.

2 p.2 p.3 p.4 p.4 p.

5 p.6 PREPARATION FOR USE Before first use, clean the thermal carafe coffee maker by completing a brew cycle as described below without using coffee or coffee filter. INTRODUCTION The Cuisinart® Automatic Brew and Serve Coffee Maker is a coffee lover's dream. It delivers the freshest coffee in the world. The secret? The patented lid. Coffee brews and pours through without ever having to open or turn the lid. Flavor and USING THE PROGRAMMING FEATURE To Set The Clock To set the time, press and hold the hour or minute button for two seconds. "Time set" starts flashingn the upper left hand corner of the LCD screen. WARNING RISK OF FIRE OR ELECTRIC SHOCK DO NOT OPEN WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT REMOVE THE BASE PANEL! NO USER SERVICEABLE PARTS INSIDE REPAIR SHOULD BE DONE ONLY BY AUTHORIZED SERVICE PERSONNEL ONLY 2 Press the hour button to advance the clock to the desired time. The hour numeral moves in one hour increments.

When passing 12 am, the "PM" indicator will illuminate in the lower left hand corner of the LCD screen. Press the "minute" button to advance the minutes to the desired time. Minutes move in one second increments. When complete, press the hour button again, or wait for 15 seconds and your time change will be accepted. To Program the Brew Time To program the brew time, press and hold the program button for two seconds. The "prog" symbol starts flashing in the lower right corner of the LCD screen. Press the hour button to advance the clock to the desired time. The hour numeral moves in one hour increments. When passing 12 am, the "PM" indicator will illuminate in the lower left hand corner of the LCD screen. Press the "minute" button to advance the minutes to the desired time.

Minutes move in one second increments. When complete, press the "prog" button, or wait for 15 seconds and your set time will be accepted. To Activate the Auto Brew Cycle To activate the auto brew mode, depress the "auto on" button. The "auto" symbol will illuminate in the upper right hand corner of the LCD screen. The unit will now begin the brewing cycle at the programmed time.

When the programmed time initiates the cycle, the red "ON" indicator light will show that the brewing cycle has started. NOTE: The unit will continue to attempt to brew at the programmed time, each day, until the Auto On button is turned off. The red "ON" indicator light will illuminate each time the attempt to brew is made. If there is no water in the reservoir, the unit will automatically shut off one minute later. cover; pour water into reservoir opening. Markings on water level indicator show amount of water needed to make desired number of cups of coffee. TO AVOID OVERFLOW, DO NOT FILL ABOVE

8-CUP MARK. Close reservoir cover. 3. Before thermal carafe is returned to platform, prewarm carafe by running warm water through carafe.

