



myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for CUISINART DTC-950. You'll find the answers to all your questions on the CUISINART DTC-950 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual CUISINART DTC-950
User guide CUISINART DTC-950
Operating instructions CUISINART DTC-950
Instructions for use CUISINART DTC-950
Instruction manual CUISINART DTC-950

Cuisinart®

**INSTRUCTION AND
RECIPE BOOKLET**



Programmable Stainless Thermal Carafe Coffeemaker

DTC-950

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.



[Your user manual](#)
[CUISINART DTC-950](#)

Manual abstract:

Reservoir Cover Stainless Steel Thermal Carafe Swing-Out Filter Basket Brew-Through Lid Water Level Indicator Pause & Serve Programmable Control Panel Carafe Platform TABLE OF CONTENTS Important Safeguards Unpacking Instructions Introduction Using the Programming Feature Coffee Preparation About the Thermal Carafe Cleaning and Maintenance Features and Benefits Warranty p.1 p.2 p.2 p.2 p.3 p.4 p.4 p.5 p.6 PREPARATION FOR USE Before first use, clean the thermal carafe coffeemaker by completing a brew cycle as described below, without using coffee or coffee filter.

USING THE PROGRAMMING FEATURE To Set The Clock To set the time, press and hold the hour or minute button for two seconds. "Time set" starts flashing in the upper left hand corner of the LCD screen. Press the hour button to advance the clock to the desired time. The hour numeral moves in one hour increments. When numeral passes 12 am, the "PM" indicator will illuminate in the lower left hand corner of the LCD screen.

Press the "minute" button to advance the minutes to the desired time. Minutes move in one second increments. When complete, press the hour button again, or wait for 15 seconds and your time change will be accepted. **INTRODUCTION** The Cuisinart® Thermal Carafe Coffeemaker is a coffee lover's dream. It delivers the freshest coffee in the world.

The secret? The patented lid. Coffee brews and pours through without ever having to open or turn the lid. Flavor and heat are sealed in. Now, you can program your coffeemaker to start brewing when you want. Simply set the desired brew time, fill the reservoir with water, put in your filter, add ground coffee and press the "ON" button. In minutes, you'll have a wonderfully fresh pot of coffee. We know the Cuisinart® Thermal Carafe Coffeemaker will bring you years of pleasure. Nothing is more satisfying than a rich cup of your favorite brew. **2 To Program the Brew Time** To program the brew time, press and hold the program button for two seconds. The "prog" symbol starts flashing in the lower right corner of the LCD screen.

Press the hour button to advance the clock to the desired time. The hour numeral moves in one hour increments. When numeral passes 12 am, the "PM" indicator will illuminate in the lower left hand corner of the LCD screen. Press the "minute" button to advance the minutes to the desired time. Minutes move in one second increments. When complete, press the "prog" button, or wait for 15 seconds and your set time will be accepted. **To Activate the Auto Brew Cycle** To activate the auto brew mode, depress the "auto on" button. The "auto" symbol will illuminate in the upper right hand corner of the LCD screen. The unit will now begin the brewing cycle at the programmed time. When the programmed time initiates the cycle, the red "ON" indicator light will show that the brewing cycle has started.

NOTE: The unit will continue to attempt to brew at the programmed time, each day, until the Auto On button is turned off. The red "ON" indicator light will illuminate each time the attempt to brew is made. If there is no water in the reservoir, the unit will automatically shut off one minute later. Prewarming carafe will help keep coffee warmer, and also prevent glass liner from being damaged. **4.**

Return carafe lid to thermal carafe. To close lid, turn it in direction of "CLOSE" arrow until it fits tightly on carafe, and "POUR" arrow is aligned with spout.

Return empty thermal carafe to platform. Be certain thermal carafe lid is in "CLOSED" position and is securely in place during brew cycle. **5.** Open filter basket by grasping basket handle and swinging outward. Insert a filter into filter basket; make sure filter fits snugly in basket. Use a fresh filter for each carafe of coffee. **6.** After placing 2 level tablespoons per cup of ground coffee into cone filter, return basket to closed position. To ensure safe operation, make sure basket is closed securely. **7.** With thermal carafe and basket securely in place, press "ON" button; LED will light. **CAUTION:** Coffeemaker becomes very hot during brew cycle; handle with extreme care, as hot parts and escaping steam may cause burns. **8.**

The Brew-Through lid allows coffee to drip from coffeemaker through closed lid..



[Your user manual](#)
[CUISINART DTC-950](#)