



## Operation

### ACTIVATING MIST CYCLE

#### ACTIVATING WITH REMOTE CONTROL

1. Before activating Mist Cycle, make sure no people, pets, or food items are in the mist area.
2. Press green Power/Mist Button on back of Mister once to turn unit ON. System Power light on Battery Pack will flash indicating unit is ON.


**NOTE:** *Mister will automatically power OFF after 10 minutes of inactivity.*

3. Press and HOLD for one second Remote Control ON button.
4. Mister begins a 12 second audible countdown before 3-minute Mist Cycle begins.
5. From a location outside the misting area, watch mist movement to ensure mist moves toward desired area.

**NOTE:** *If mist moves toward an undesired area (e.g., bodies of water, neighboring properties, etc.), stop Mist Cycle by pressing OFF button once on Remote Control device. See 'To Stop Mist Cycle' below.*

6. Mist Cycle automatically ends after 3 minutes.
7. Re-enter and enjoy area after mist has dissipated (usually 2-5 minutes).

**CAUTION:** *Store Remote Control device in an area inaccessible to children.*



#### ACTIVATING DIRECTLY FROM MISTER


1. Before activating Mist Cycle, make sure no people, pets, or food items are in the mist area.
2. Press green Power/Mist Button on back of Mister once to turn unit ON. System Power light on Battery Pack will flash indicating unit is ON.

**NOTE:** *Mister will automatically power OFF after 10 minutes of inactivity.*

3. Press and HOLD green Power/Mist Button for 3 seconds until Mister begins to beep.

**NOTE:** *3 second 'Press and HOLD' feature is intended to prevent accidental activation from unauthorized users.*

4. Follow Steps 4 through 8 above.



#### TO STOP MIST CYCLE

**Option 1:** Use Remote Control device to stop unit before or during Mist Cycle by pushing the OFF button once on the Remote Control device.

**Option 2:** Before misting begins push green Power/Mist Button on Mister once to stop Mist Cycle.

**NOTE:** *Use Remote Control device to stop misting whenever possible. Do not stop Mist Cycle from unit while misting. If Mister is stopped, it will reset to original settings. The next time Mister is activated it will begin a new 3-minute Mist Cycle with a 12*