

Operation


POSITIONING THE MISTER

Proper placement of the ALLCLEAR Cordless Mosquito Mister PRO is important for optimal insect control.


1. Determine area to be protected.
2. Roll Mister into desired coverage area and establish direction of prevailing wind.
3. Position Mister according to wind conditions shown here.

EXAMPLE:


Treating a Patio Area. Determine prevailing wind. Depending on wind direction, place Mister on either side of, in the center of, or a few feet beyond center of patio so that prevailing winds will carry mist solution directly over patio and surrounding areas.



Position Mister at edge of desired coverage area with Mister nozzles facing mist area so that prevailing wind will carry mist solution over target area.



Position Mister in the center of desired coverage area so that the wind will carry the mist solution equally throughout desired coverage area.



Position Mister in the center of desired coverage area or a few feet beyond center of coverage area.



IMPORTANT TIPS

- Mister performs best if positioned and activated near desired coverage area.
- For optimal control, users may need to mist an area more than once and/or move the Mister to another part of the treatment area in the following situations:
 - Areas of very heavy mosquito populations
 - Areas planned for large gatherings (more people bring increased mosquito activity)
 - Areas where wind is idle since solution may not be carried as far into treatment area
- Place Mister and direct Mister nozzles away from bodies of water and eating or cooking areas when food is present.
- Leave at least 2 to 3 feet between Mister and barrier such as a fence, house, or wall.