



PARTS LIST

BRUSHCUTTERS

BC2201DL

NOTE:

- 1. Use KOMATSU ZENOAH genuine parts as specified in the parts list for repair and/or replacement.
- 2. KOMATSU ZENOAH does not warrant the machines, which have been damaged by the use of any parts other than those specified by the company.
- When placing parts orders for repair and/or replacement, check if the model name and the serial number are applicable to those specified in the parts list, then use parts number described in the parts list.
- 4. The contents described in the parts list are accurate as of the date and may change due to improvement.
- 5. The parts for the machine shall be supplied ten (10) years after the machine is discontinued. [It is possible that some specific parts may be subject to change of their delivery term and list price within the limit of ten (10) years after the machine is discontinued. It is also possible that some parts may be available even after the limit of ten (10) years.]

APPLICABLE SERIAL NUMBERS:

200101 and up

February 2002




Fig.1 CUTTER GROUP

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	T3146-11300	PIPE COMP 1500x24xT1.5	1		65	K5200-000090	• CORD	1	
2	3520-12213	SHAFT, spline ø7x7teeth	1	1536x7	66	K5100-000270	CABLE COMP	1	
3	T3109-13000	GEARCASE ASSY	1		67	K5100-000201	• • THROTTLE CABLE	1	
4	6489-13110	• GEARCASE	1		68	K5200-000130	•• SLEEVE	1	
5	06000-00626	BEARING	1		69	K2300-000390	• LID	1	
6	06000-06000	• BEARING	1		70	B1176-090530	• SCREW	4	
7	3565-13130	• SEAL	1		71	B1181-04054506	• NUT	4	
8	04065-02612	• RING	1		72	T3109-83100	CABLE COMP.	1	
9	6440-13211	• SHAFT	1		73	T3109-83310	TUBE	1	
10	6440-13220	• GEAR	1 1		74	T3146-93110	MANUAL	1	
11	6423-13241	• HOLDER(A)	1			10140 30110	W/WO/NE		
	6423-13250	• HOLDER(B)							
12			1						
13	3560-13290	• WASHER	1 1	M7::05(L)					
14	3560-13261	• BOLT	1	M7x25(L)					
15	T3002-13310	• PINION	1						
16	06000-00609	• BEARING	1						
17	06001-00609	BEARING	1						
18	T3300-13330	• RING	1						
19	04065-02412	• RING	1						
20	01252-30510	• BOLT	1						
21	3350-21320	• BOLT	1	M5x30					[
22	0224-40610	• BOLT	1				•••••		
23	6130-18000	HANGER ASSY	1				***************************************		
24	6130-18101	• HANGER	1						
25	6130-18200	• CLUMP	1						
26	0263-90520	• SCREW	1						
	0200 00020		·						
29	T2146 12510	PLATE NAME	1						
	T3146-12510								
30	6425-12552	PLATE CAUTION	1 1						
31	T3146-12590	No.PLATE	1 1						
32	6489-24000	GUARD ASSY	1						
33	6489-24110	• GUARD	1						
34	6489-24200	PLATE COMP	1						
35	6489-24210	••PLATE	1						
36	6489-24220	••BLADE	1						
37	0277-10412	••SCREW	1	[]					
38	6489-24120	• PLATE	1						
39	01252-30516	• BOLT	4						
40	01601-20513	• WASHER	4						
41	3560-13284	COVER(BOLT)	1				***************************************		
42	6251-15910	COVER(BLADE)	1						
43	T3300-17100	STRAP ASSY	1						
44	6298-E3390	SAW	1						
45	5883-32160	SCREW	1						
46	T3110-14000	HANDLE ASSY	1						
	T3110-14110	• HANDLE	1 1	·····					
47									
48	0263-90530	• SCREW	4						
49	T3110-18000	GRIP ASSY	1	ļ					
50	K2300-000240	• GRIP (R)	1 1						
51	K2300-000230	• GRIP (L)	1 1						
52	K3200-000370	• CLAMP (A)	1						
53	K3300-000010	• PLATE (A)	1						
54	K3300-000020	• PLATE (B)	1						
55	K5100-000240	• COLLAR	1	[]			***************************************		
56	K5100-000220	• SPRING	1						
57	K2300-000260	• SAFETY LEVER	1						
58	K2300-000250	• THROTTLE LEVER	1	[••••••		[
59	K3200-000380	• CLAMP (B)	1						
60	K5100-000230	• SPRING	1						
61	K5100-000210	• SPRING	1	·····					·····
62	K2300-000270	• PLATE	1						
63	B1122-C2910H	• SCREW	1						
64	K2300-000280	• SWITCH	1						




Fig.2 ENGINE GROUP (SERIAL NUMBER LABEL: Only serial number printed.)

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	5850-12110	CYLINDER	1		65	1850-81530	• SCREW	4	
2	5500-12213	GASKET, base	1		66	5850-82310	SCREW	2	
3	1850-12130	BOLT	2		67	5850-83110	O-RING	1	
4	5500-13163	INSULATOR	1		68	5850-82100	BODY ASSY	1	
5	5500-13121	GASKET, insulator	1		69	5850-82170	ELEMENT	1	
6	5500-13131	GASKET, carburetor	1		70	5850-82180	SCREEN	1	
7	5850-13210	SCREW	2		71	5850-82200	COVER	1	
	0000 10210	OOKLVV			72	5851-31101	HOUSING COMP	1	
9	5850-15110	MUFFLER	1		73	0225-30635	BOLT	1	
9	3630-13110	MOFFLER						1	
	5050 45400	BOLT			74	0280-10605	NUT		
11	5850-15130		2		75	5850-13210	SCREW	4	
12	5500-15210	GASKET, muffler	1		76	5850-32110	COVER, engine	1	
13	5500-15221	PLATE, muffler	1		77	5850-15230	SCREW	1	
14	5850-15230	SCREW	1		78	5850-32170	SCREW	2	
15	5850-21100	CRANKCASE COMP	1		79	5602-73110	SPARKPLUG	1	RCJ-6Y
16	5500-21141	GASKET, case	1		80	5883-73200	CORD COMP	1	
17	06030-06001	BEARING	2	[81	1852-72121	GROMMET	1	
18	2169-21210	OIL SEAL	1		82	5504-85004	TANK ASSY	1	
19	1850-21220	OIL SEAL	1		83	5607-85201	CAP-ASSY	1	
20	04065-02812	SNAP RING	1		84	5601-85300	• • HOLDER ASSY	1	
21	01252-30530	SCREW	4						
22	5600-41111	PISTON			86	5601-85260	•• FILTER	1	
23	1100-41210	RING	2		87	5500-85220	• • PACKING	1	
24	1101-41310	PIN	1		88	4820-85260	•• STOPPER		
25		SNAP RING				5500-85300	• PIPE-C		
	1260-41320		2		89			1	
26	5850-42000	CRANKSHAFT COMP	1		90	5500-85400	• FILTER	1	
27	1000-43240	KEY	1		91	1260-85460	• CLIP	1	
28	5882-51201	SHOE COMP	1		92	5850-85510	SCREW	3	
29	5882-51310	WASHER	1		93	5851-91121	LABEL, recoil	1	
30	1260-71261	SPACER	1		94	5504-91130	LABEL, housing	1	
31	5850-51220	ROTOR	1		95	5850-91000	TOOL SET	1	
32	5850-71200	COIL ASSY	1		96	3239-91310	• SOCKET	1	
33	1260-71261	SPACER	2		97	3582-91330	• BAR	1	
34	5850-72160	SCREW	2		98	3540-91110	• BAR	1	
35	5500-75100	RECOIL ASSY	1		99	2634-31420	LABEL(CE)	1	
36	5500-75110	CASE COMP	1						
37	1850-75120	• REEL	1						
38	1850-75130	SPIRING, spairal	1						
39	1850-75151	• SCREW	1						
	1000-70101	• SCREW							
41	1850-75160	• ROPE	1						
42	1140-75320	• KNOB	1						
43	5500-75170	• WASHER	1						
44	1850-75201	PULLY ASSY	1						
45	1850-75221	• RATCHET	1	[]					
46	1850-75230	• SPIRING	1						
48	5850-15230	SCREW	4				••••••		
49	5850-83220	BRACKET	1						
50	5850-81000	CARBURETOR ASSY	1	WYL-123					
51	5850-81110	• SCREW	1						
	1751-81130	• RING	1						
52									
53	1881-81140	• SWIVEL							
54	1751-81240	• O-RING	1						
55	5516-81250	• JET #38	1						
56	3310-81260	• DIAPHRAGM	1	.					ļ
57	1065-81410	GASKET, pump	1						
58	1065-81420	DIAPHRAGM, pump	1						
59	1850-81450	• BODY, ASSY	1			• • • • • • • • • • • • • • • • • • • •			T
60	3306-81380	•• SCREEN	1	• • • • • • • • • • • • • • • • • • • •					
61	1850-81470	GASKET, diaphragm	1						
62	1850-81490	BODY, purge	1						·
63	1751-81510	• PUMP, priming	1						
64	1850-81520								·
04	1000-01520	 COVER, pump 	1		1				




Fig.3 ENGINE GROUP (SERIAL NUMBER LABEL: Serial number and "Made in USA" printed.)

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	5850-12110	CYLINDER	1		65	1850-81530	• SCREW	4	
2	5500-12213	GASKET, base	1		66	5850-82310	SCREW	2	
3	1850-12130	BOLT	2		67	5850-83110	O-RING	1	
4	5500-13163	INSULATOR	1		68	5850-82100	BODY ASSY	1	
5	5500-13121	GASKET, insulator	1		69	5850-82170	ELEMENT	1	
6	5500-13131	GASKET, carburetor	1		70	5850-82200	COVER	1	
7	5850-13210	SCREW	2		71	5851-31101	HOUSING COMP	1	
					72	0225-30635	BOLT	1	
9	5850-15110	MUFFLER	1		73	0280-10605	NUT	1	
					74	5850-13210	SCREW	4	
11	5850-15130	BOLT	2		75	5850-32110	COVER, engine	1	
12	5500-15210	GASKET, muffler			76	5850-15230	SCREW	1	
13	5500-15221	PLATE, muffler	1		77	5850-32170	SCREW	2	
14	5850-15230	SCREW	1		78	5602-73110	SPARKPLUG	1	RCJ-6Y
15	5850-21100	CRANKCASE COMP	1		79	5883-73200	CORD COMP	1	
16	5500-21141	GASKET, case	1		80	1852-72120	GROMMET	1	
17	06030-06001	BEARING	2		81	5850-85110	TANK	1	
		OIL SEAL							
18	2169-21210		1 1		82	5851-85200	CAP ASSY	1 1	
19	1850-21220	OIL SEAL	1		83	5850-85320	PIPE, return	1 1	
20	04065-02812	SNAP RING	1		84	5850-85330	GROMMET	1	
21	01252-30530	SCREW	4		85	5850-85400	FILTER ASSY	1	
22	5600-41111	PISTON	1		86	5850-85510	SCREW	3	
23	1100-41210	RING	2		87	5851-91121	LABEL, recoil	1	
24	1101-41310	PIN	1		88	5504-91130	LABEL, housing	1	
25	1260-41320	SNAP RING	2		89	5850-91000	TOOL SET	1	
26	5850-42000	CRANKSHAFT COMP	1		90	3239-91310	• SOCKET	1	
27	1000-43240	KEY	1		91	3582-91330	• BAR	1	
28	5882-51201	SHOE COMP	1		92	3540-91110	• BAR	1	
29	5882-51310	WASHER	1		93	2634-31420	LABEL(CE)	1	
30	1260-71261	SPACEER	1						
31	5850-51220	ROTOR	1						
32	5850-71200	COIL ASSY	1						
33	1260-71261	SPACER	2						
34	5850-72160	SCREW	2						
35	5850-75100	RECOIL ASSY	1						
36		CASE COMP	1						
37	5850-75120	• REEL	1						
38	5850-75130	SPIRING, spairal	1						
39	5850-75140	• SCREW	1						
40	1400-86280	• WASHER	1						
41	5850-75150	• ROPE	1						
42	5850-75160	• KNOB	1						
43	3310-75431	• WASHER	1						
44	5850-75200	PULLY ASSY	1						
45	5850-75220	• RATCHET	1						
46	5850-75230	• SPIRING	1						
47	0308-00040	• RING	1						
48	5850-15230	SCREW	4						
49	5850-83220	BRACKET							
50	5850-81000	CARBRETOR ASSY	1	WYL-123					
51	5850-81110	• SCREW	1						
52	1751-81130	• RING	. 1						
53	1881-81140	• SWIVEL	1						
54	1751-81240	• O-RING	1						
55	5516-81250	• JET	1						
56	3310-81260	• DIAPHRAGM	1						
57	1065-81410	GASKET, pump	1						
58	1065-81420	DIAPHRAGM, pump	1		[T
59	1850-81450	• BODY ASSY	1						T
60	3306-81380	• • SCREEN	1						1
61	1850-81470	GASKET, diaphragm	1						
	1850-81490	BODY, purge	1						
62		, , , ,			L	l			
62 63	1751-81510	PUMP, priming	1						



KOMATSU ZENOAH CO.

1-9 Minamidai, Kawagoe, Saitama, 350-1192 Japan