




# myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for KRUPS PROAROMA ELECTRONIC 313. You'll find the answers to all your questions on the KRUPS PROAROMA ELECTRONIC 313 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual KRUPS PROAROMA ELECTRONIC 313**  
**User guide KRUPS PROAROMA ELECTRONIC 313**  
**Operating instructions KRUPS PROAROMA ELECTRONIC 313**  
**Instructions for use KRUPS PROAROMA ELECTRONIC 313**  
**Instruction manual KRUPS PROAROMA ELECTRONIC 313**



[Your user manual](#)  
[KRUPS PROAROMA ELECTRONIC 313](#)

**Manual abstract:**

Before turning your KRUPS coffee maker on, please make sure that: 1. the filter is properly inserted into the swivel filter; 2. the swivel filter is properly closed; 3. the lid for the glass carafe is properly attached to the glass carafe; 4. the glass carafe sits flat on the inside circle of the heating plate. Keep your hands and the cord away from hot parts of the appliance during operation. . . Never clean with scouring powders or hard implements. .

-. .! ., ' l a b KRUPS ~ c d - e k a: b: c: d: e: f: Hinged water chamber lid Release button Swing away filter holder Glass-Carafe Warming-plate Carafe pre-warm g: h: I: j: k: Indicator light 3 flavor selector buttons Off button Magnified water level indicator Hidden cord storage , , ' , . , ' - ' " - , KRUPS CD - , " , ' ' , " , - : " , ; , , - " " , , " : " , " , " ; : ' " , ' , ' , ' , " , ; , KRUPS "ProAroma Electronic" Your new KRUPS "ProAroma Electronic" has the following features: - Exclusive KRUPS deep brew system with special filtering action for maximum flavor. - Touch button electronic brewing cycles lets you select 1-3 cups, 4-10 cups (medium) or 4-10 cups. (strong).

W-;ar, ITicking :ess than 5 cups the electronic control slows down the brewing process, ensuring good coffee every time. - Swing away 2 part filterholder with release button is convenient to use and easy to clean. -Automatic warming plate has non-stick coating for easy cleaning. Raised edges keep carafe firmly in place. -KRUPS specially designed heating and tubing system minimizes calcification and leaves no residual water in the system when brewing is finished. 0 - Hidden Yv:" cord storage allows you to set the cord length r,,,,;u. wiUnot function properly, which may cause hot water or hot coffee to overflow. The "Stop'n Serve" mechanism is opened as long as the glass carafe is inserted into the machine and sits properly on the warming plate and the swivel filter is properly closed. j=iii og tile W8r~rchamber i - Hinged water container lid will protect the water container from dust and dirt. PREPARING COFFEE Before making your first pot of delicious coffee, we recommend operating the coffee maker once or twice with water only, without ground coffee or a paper filter to remove any possible dust.

Be sure that the water 0 - "Stop'n Serve" feature interr[:.pts the brewing cycle to let you pour a cup or two of coffee while brewing. The automatic filter seal will allow you to remove the carafe for 20 seconds without coffee dripping onto the warming plate. - Aroma Savor System lid locks in flavor and aroma by creating a seal on the carafe lid. container is empty. Remove literature, etc. if inserted in the water container. 0 The lid of the glass carafe - Carafe Pre-Warming Cycle pre-warms the carafe so every cup of coffee is hot, from first to last. - Automatic Shut-Off feature turns the coffeemaker off after 2 hours. - Magnified water level indicator is easy to read.

- Automatic warming plate will keep coffee hot al all times. When coffee is kG.)t hot for a prolonged period of time it will begin to lose its aroma. (We recommend not to serve coffee which has been kept warm for more than 1 hour -. must be properly positioned during the brewing process. Position the lid over the carafe and snap the rectangular piece onto the handle. The lid is then locked in place. Make sure that the swivel filter (c) is properly closed during the brewing process. When closing the swivel filter you wiUfeel a. noticeable resistance when the handle of the swivel filter is approximately 1/2 inch away from the nonremovable base.

Push in firmly until you hear the filter "click" into place. 0Caution: If the swivel filter is not- completely closed, 0 Open the hinged lid (see figure. ). Using the glass carafe, pour in the desired quantity of water (see figure.). The water level indicator shows you how much water you are pouring into the container (see figure.). The amount of freshly brewed coffee delivered after the brewing process will always be slightly less than the amount put into the water container..



[Your user manual](#)

[KRUPS PROAROMA ELECTRONIC 313](#)