



User's Guide AIR PURIFIER FRESHENER WITH LIGHT

MODEL XJ-201



• IMPORTANT • SAVE THIS BOOKLET!

Includes: Important Safety Instructions Warranty Operating Instructions

REGISTER YOUR PRODUCT ON THE WEB: WWW.ORECK.COM

IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE



- WARNING To reduce the risk of fire, electric shock, or injury:
- Do not use wet hands to plug or unplug the freshener from power socket to avoid electric shock.
- Do not wet or soak the freshener. Do not insert metallic items into the freshener. Do not dismantle the freshener to avoid electric short and damage to internal parts.
- Static electric noise caused by moisture content in the air during operation of the freshener is harmless.
- Unplug from electric socket when you clean your air freshener. Pull out the dust collector from the top of the freshener and wipe with a soft clean cloth. A mild detergent may be used to clean the exterior.

SAVE THESE INSTRUCTIONS Household Use Only

ALL SERVICING SHOULD BE DONE BY AN AUTHORIZED ORECK SERVICE CENTER.

CUSTOMER SERVICE HOT LINE US: 1-800-989-3535 Canada: 1-888-676-7325

Warranty

Oreck Corporation warrants the Air Purifier Freshener (Model XJ-201) free from defects in material and workmanship under normal, non-commercial use and service. Oreck will remedy any such defects if they appear within one (1) year from date of purchase. This warranty gives you specific legal rights, and you may have other rights, which vary, from state to state. The air you breathe is filled with thousands of particles of air pollution. Some of the pollutants like dust and lint are large enough to be visible to the naked eye, but pollutants such as pollen, smoke, germs, bacteria, etc., are microscopic in size. Your Air Purifier Freshener with light (Model XJ-201) has been designed to trap and remove visible and invisible pollutants and provide your home or office with the luxury of clean air living.



Operating Instructions

- 1. To turn Air Purifier Freshener on, plug into an electrical outlet.
- 2. To turn Air Purifier Freshener off, unplug from electrical outlet.

Cleaning Instructions

For maximum performance, clean the collector cell every four to eight weeks.

- 1. Unplug the unit from electrical outlet.
- 2. Remove collector cell from unit. (fig. 1)
- 3. Using a damp cloth, gently wipe collector cell clean.
- 4. Allow collector cell to dry thoroughly.
- 5. Replace collector cell in unit.

