

# BUNN®

**RWS1, RWS1A, & RWS1B  
WARMERS  
( $\frac{5}{8}$  RW10002448 and up)**

## INTRODUCTION

This portable warmer keeps one BUNN® Safety-Fresh® server of coffee at the perfect temperature.

## ELECTRICAL REQUIREMENTS

Model RWS1 has attached cordset and requires 2-wire grounded service rated 120 volts ac, single phase. Model RWS1 has 100 watts total, plus 200W maximum auxiliary receptacle.

Model RWS1B has attached cordset and requires 2-Wire grounded service rated 100 volts ac, single phase. Model RWS1B has 90 watts total, plus 200W maximum auxiliary receptacle.

Models RWS1A requires 2-wire grounded service rated 220-240 volts ac, single phase. Model RWS1A has 100 watts total. It is equipped with an I.E.C. 320 connector for attachment of a customer-supplied cordset.

## WARRANTY

Bunn-O-Matic Corp. ("Bunn") warrants the equipment manufactured by it to be commercially free from defects in material and workmanship existing at the time of manufacture and appearing within one year from the date of installation. In addition:

- 1.) Bunn warrants electronic circuit and/or control boards to be commercially free from defects in material and workmanship for two years from the date of installation.
- 2.) Bunn warrants the compressor on refrigeration equipment to be commercially free from defects in material and workmanship for two years from the date of installation.
- 3.) Bunn warrants that the grinding burrs on coffee grinding equipment will grind coffee to meet original factory screen sieve analysis for three years from date of installation or for 30,000 pounds of coffee, whichever comes first.

This warranty does not apply to any equipment, component or part that was not manufactured by Bunn or that, in Bunn's judgement, has been affected by misuse, neglect, alteration, improper installation or operation, improper maintenance or repair, damage or casualty.

**THE FOREGOING WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY OTHER WARRANTY, WRITTEN OR ORAL, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF EITHER MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** The agents, dealers or employees of Bunn are not authorized to make modifications to this warranty or to make additional warranties that are binding on Bunn. Accordingly, statements by such individuals, whether oral or written, do not constitute warranties and should not be relied upon.

The Buyer shall give Bunn prompt notice of any claim to be made under this warranty by telephone at (217) 529-6601 or by writing to Post Office Box 3227, Springfield, Illinois, 62708-3227. If requested by Bunn, the Buyer shall ship the defective equipment prepaid to an authorized Bunn service location. If Bunn determines, in its sole discretion, that the equipment does not conform to the warranty, Bunn shall repair the equipment with no charge for parts during the warranty period and no charge for labor by a Bunn Authorized Service Representative during the warranty period. If Bunn determines that repair is not feasible, Bunn shall, at its sole option, replace the equipment or refund the purchase price for the equipment.

## **BUNN-O-MATIC CORPORATION**

POST OFFICE BOX 3227

SPRINGFIELD, ILLINOIS 62708-3227

TELEPHONE: (217) 529-6601 FAX: (217) 529-6644

## WARRANTY, CONT.

**THIS EQUIPMENT, WHETHER DERIVED FROM WARRANTY OR OTHERWISE, SHALL BE LIMITED, AS SPECIFIED HEREIN, TO REPAIR OR, AT BUNN'S SOLE OPTION, REPLACEMENT OR REFUND.**

In no event shall Bunn be liable for any other damage or loss, including, but not limited to, lost profits, lost sales, loss of use of equipment, claims of Buyer's customers, cost of capital, cost of down time, cost of substitute equipment, facilities or services, or any other special, incidental or consequential damages.


## CLEANING

The use of a damp cloth rinsed in any mild, nonabrasive, liquid detergent is recommended for cleaning all surfaces on Bunn-O-Matic equipment.

## REPLACEMENT PARTS


01908.0000 .....	IEC Power Connector (RWS1A)	02753.0000 .....	Switch, On/Off Lighted (RWS1, RWS1B)
20630.0002 .....	Cordset Assy	02754.0000 .....	Switch, On/Off Lighted (RWS1A) Prior to S/N RW10024943
00986.0002 .....	Decal, Electrical Warning	27727.0000 .....	Switch, On/Off Lighted (RWS1A) After S/N RW10024943
24708.0000 .....	Decal, Front-Black Decor	03656.0000 .....	Warmer Dish
24708.0001 .....	Decal, Front-Black Decor (RWS1A) After S/N RW10024943	03652.0000 .....	Warmer Dish Assembly (RWS1)
02822.0000 .....	Decal, 200 Watt Maximum	02817.0000 .....	Warmer Dish Assembly (RWS1A)
12364.0000 .....	Decal, Warmer & Surfaces are Hot	03668.0000 .....	Warmer Dish Assembly (RWS1B)
12249.0006 .....	Guide Rail (Brass)	01227.0000 .....	Warmer Element, 100W @ 120V (RWS1)
12249.0002 .....	Guide Rail (Stainless Steel)	01225.0000 .....	Warmer Element, 90W @ 100V (RWS1B)
03359.0001 .....	Leg, 4.0" Adjustable Black	01951.0000 .....	Warmer Element, 100W @ 220V (RWS1A)
00511.0000 .....	Leg, 4.0" Adj. Satin Nickel	05212.0000 .....	Warmer Retainer Plate
03993.0000 .....	Pad, Anti Skid (Legs) (For 03359.0001)	24436.0000 .....	Wiring Harness, 100V/120V (RWS1, RWS1B)
03996.0000 .....	Pad, Anti-Skid (Legs) (For 00511.0000)	24437.0000 .....	Wiring Harness, (240V) (RWS1A)
03628.0000 .....	Rear Receptacle (RWS1, RWS1B)		
24738.0000 .....	Shield, Heat Deflector		

### SCHEMATIC WIRING DIAGRAM RWS1 & RWS1B



**100 or 120 VOLTS A C  
2 WIRE**

### SCHEMATIC WIRING DIAGRAM RWS1A



**230 VOLTS A C  
2 WIRE**