Electronics/Power Supply

Cable

1	C4557-60022	Cable assembly - An 11 pin (F) connector to two 3 pin (F) connectors and a 7 pin (F) connector - 36.8cm (14.5 inches) long
2	C4557-80075	Carriage assembly flex cable - 40.3cm (15.9 inches) long
3	C5870-60140	Cable assembly - 12 pin (F) connector, 5 pin (F) connector, and 7 pin (F) connector - 43.9cm (17.3 inches) long

Keypad

4	C4557-60009	Keypad assembly

PC Board

5	C4557-60062	Banner PCA and cable assembly
6	C5870-60209	Ink cartridge carriage PCA NO LONGER SUPPLIED
7	C5870-69121	Main logic PCA NO LONGER SUPPLIED
8	C6409-60200	Paper encoder PCA - Controls operation of paper motor

Power Cord

9	8120-8336	Power cord (Quartz Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 100V in Japan)
10	8120-8337	Power cord (Quartz Gray) - Two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 240V in Australia and New Zealand)
11	8120-8341	Power cord (Quartz Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 240V in the UK)
12	8120-8345	Power cord (Quartz Gray) - Two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 240V in South Africa and India)
13	8120-8900	Power cord (Flint Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 120V in the USA, Canada, Brazil, Latin America and Saudi Arabia)
14	8121-0023	Power cord (Flint Gray) - 18 AWG, two conductor, 1.8m (6.0ft) long - Has straight (F) C7 receptacle (For 220V in Europe, Asia Pacific, Germany, Spain, France, Netherlands, Switzerland, Italy, and Portugal)

Power Module

15	C6409-60014	Power Supply Module - 100V-240V, 50/60Hz - Requires separate AC power cord - For worldwide use

External Case Parts

Cover

16	C4557-40053	Main logic PCA cover - Has cut outs for the parallel interface socket and the power module socket
17	C4557-60020	Left side case
18	C6409-60162	Right side case

Door

19	C5870-40045	Top/front access door - Print cartridge access door - Solid door without a window opening
20	C6458-60001	Top/front access door assembly - Print cartridge access door with strawberry colored window - Includes installation instructions
21	C6458-60002	Top/front access door assembly - Print cartridge access door with strawberry colored window - Includes installation instructions
22	C6459-60001	Top/front access door assembly - Print cartridge access door with lime window - With installation instructions
23	C6459-60002	Top/front access door assembly - Print cartridge access door with lime colored window - Without installation instructions
24	C6460-60001	Top/front access door assembly - Print cartridge access door with tangerine colored window - With installation instructions
25	C6460-60002	Top/front access door assembly - Print cartridge access door with tangerine window - Without installation instructions
26	C6461-60001	Top/front access door assembly - Print cartridge access door with grape colored window - With installation instructions
27	C6461-60002	Top/front access door assembly - Print cartridge access door with grape colored window - Without installation instructions
28	C6462-60001	Top/front access door assembly - Print cartridge access door with blueberry colored window - With installation instructions

© 2004 Hewlett-Packard

External Case Parts

Door

29	C6462-60002	Top/front access door assembly - Print cartridge access door with blueberry colored window - Without installation instructions NO LONGER SUPPLIED
30	C6409-40014	I/O and power input cable covering door
31	C4557-60076	Rear cleanout door assembly - Paper jam cleanout door

Foot

32	C4557-40118	Rubber foot

Knob

33	C4557-40090	Rear cleanout door knob

Label

34	C4557-80057	Front panel label - Includes kodak image enhancements

Nameplate/Logo

35	C5894-40001	Nameplate - DeskJet 710C printer NO LONGER SUPPLIED
36	C5894-40002	Nameplate - DeskJet 712C printer NO LONGER SUPPLIED

Plate

37	C4557-40014	Back Plate - Holds Latch Spring, Knob and Latch Components of Rear Cleanout Assembly

Interface Cables

Cable (Interface)

	5063-1256	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 2.0m (6.6ft) long
	5063-1257	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 3.0m (9.8ft) long
	C2950A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 2.0m (6.6ft) long
	5063-1256	*New Part for C2950A*
	C2951A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) connector (type A) to 36 pin Centronics (M) connector (type B) - 3.0m (9.8ft) long
	C2990A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) (type A) to 36 pin (M) Centronics (type B) - 1.8m (6ft) long NO LONGER SUPPLIED
	C2991A	IEEE-1284 Bi-Tronics parallel cable - DB-25 (M) (type A) to 36 pin (M) Centronics (type B) - 3.0m (10ft) long NO LONGER SUPPLIED

Other Accessories

CD-ROM (Support)

	C6450-60020	DeskJet and DeskWriter service manual on CD-ROM - Version 4.1
	C6450-60021	DeskJet and DeskWriter service manual on CD-ROM - Version 4.1

Cartridge

44	51645A	Black print cartridge (High capacity) - Prints approximately 840 pages based on 5% density on a 8 inch by 10 inch print area (for USA)
45	51645AA	Black print cartridge (High capacity) - Prints approximately 840 pages based on 5% density on a 8 inch by 10 inch print area (for Asia/Pacific)
46	51645AC	Black print cartridge (high capacity) - Prints approximately 840 pages based on 5% density on a 8 inch by 10 inch print area (for Canada)
47	51645AE	Black print cartridge (high capacity) - Prints approximately 840 pages based on 5% density on a 8 inch by 10 inch print area (for Europe)
48	51645AL	Black print cartridge (high capacity) - Prints approximately 840 pages based on 5% density on a 8 inch by 10 inch print area (for Latin America)

© 2004 Hewlett-Packard

Other Accessories

Cartridge

49	51645G	Black print cartridge (economy) - Prints approximately 415 pages based on 5% density on a 8 inch by 10 inch print area (for USA)
50	51645GA	Black print cartridge (economy) - Prints approximately 415 pages based on 5% density on a 8 inch by 10 inch print area (for Asia/Pacific)
51	51645GC	Black print cartridge (economy) - Prints approximately 415 pages based on 5% density on a 8 inch by 10 inch print area (for Canada)
52	51645GE	Black print cartridge (economy) - Prints approximately 415 pages based on 5% density on a 8 inch by 10 inch print area (for Europe)
53	51645GL	Black print cartridge (economy) - Prints approximately 415 pages based on 5% density on a 8 inch by 10 inch print area (for Latin America)
54	C1823A	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8 inch by 10 inch print area (for USA)
	C1823D	*New Part for C1823A*
55	C1823AA	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8 inch by 10 inch print area (for Asia/Pacific)
56	C1823AC	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8 inch by 10 inch print area (for Canada)
57	C1823AE	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8 inch by 10 inch print area (for Europe)
58	C1823AL	Tri-color ink print cartridge - Prints approximately 475 pages based on 13.5% total density (4.5% for each colors) on a 8 inch by 10 inch print area (for Latin America)
59	C1823D	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for USA)
60	C1823DA	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Asia/Pacific)
61	C1823DC	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Canada)
62	C1823DE	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Europe)
63	C1823DL	Tri-color ink print cartridge - Prints approximately 360 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Latin America)
64	C1823G	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for USA)
65	C1823GA	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Asia/Pacific)
66	C1823GE	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Europe)
67	C1823GL	Tri-color ink economy print cartridge - Prints approximately 180 pages based on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Latin America)
68	C1823T	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for USA)
69	C1823TA	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Asia/Pacific)
70	C1823TE	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Europe)
71	C1823TL	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch by 10 inch print area (for Latin America)
72	C6613AN	Black print cartridges (High capacity) - (2 pack of 51645A) each prints approximately 840 pages based on 5% density on a 8 inch (20.3cm) by 10 inch (25.4cm) print area (for USA) NO LONGER SUPPLIED
73	C6618AN	Tri-color ink cartridges (2 pack of C1823D) - Each prints approximately 360 pages on 13.5% total density (4.5% for each color) on a 8 inch (20.3cm) by 10 inch (25.4cm) print area (for USA) NO LONGER SUPPLIED

© 2004 Hewlett-Packard

Other Accessories

Door (Product)

76	C6458A	Top/front access door assembly - Print cartridge access door with Strawberry colored window - Replaces the existing door
77	C6459A	Top/front access door assembly - Print cartridge access door with Lime colored window - Replaces the existing door
78	C6460A	Top/front access door assembly - Print cartridge access door with Tangerine colored window - Replaces the existing door
79	C6461A	Top/front access door assembly - Print cartridge access door with grape colored window - Replaces the existing door
80	C6462A	Top/front access door assembly - Print cartridge access door with blueberry colored window - Replaces the existing door

Manual

C5894-60112	DeskJet 710C/712C user's guide (English) NO LONGER SUPPLIED
C5894-60113	DeskJet 710C/712C user's guide (French) NO LONGER SUPPLIED
C5894-60114	DeskJet 710C/712C user's guide (Japanese) NO LONGER SUPPLIED
C5894-60115	DeskJet 710C/712C user's guide (Portuguese) NO LONGER SUPPLIED
C5894-60116	DeskJet 710C/712C user's guide (Spanish) NO LONGER SUPPLIED
C5894-60117	DeskJet 710C/712C user's guide (Arabic) NO LONGER SUPPLIED
C5894-60118	DeskJet 710C/712C user's guide (Czechoslovakian) NO LONGER SUPPLIED
C5894-60119	DeskJet 710C/712C user's guide (Danish) NO LONGER SUPPLIED
C5894-60120	DeskJet 710C/712C user's guide (Dutch) NO LONGER SUPPLIED
C5894-60121	DeskJet 710C/712C user's guide (Finnish) NO LONGER SUPPLIED
C5894-60122	DeskJet 710C/712C user's guide (German) NO LONGER SUPPLIED
C5894-60123	DeskJet 710C/712C user's guide (Greek) NO LONGER SUPPLIED
C5894-60124	DeskJet 710C/712C user's guide (Hebrew) NO LONGER SUPPLIED
C5894-60125	DeskJet 710C/712C user's guide (Hungarian) NO LONGER SUPPLIED
C5894-60126	DeskJet 710C/712C user's guide (Italian) NO LONGER SUPPLIED
C5894-60127	DeskJet 710C/712C user's guide (Korean) NO LONGER SUPPLIED
C5894-60128	DeskJet 710C/712C user's guide (Norwegian) NO LONGER SUPPLIED
C5894-60129	DeskJet 710C/712C user's guide (Polish) NO LONGER SUPPLIED
C5894-60130	DeskJet 710C/712C user's guide (Russian) NO LONGER SUPPLIED
C5894-60131	DeskJet 710C/712C user's guide (Simplified Chinese) NO LONGER SUPPLIED
C5894-60132	DeskJet 710C/712C user's guide (Swedish) NO LONGER SUPPLIED

© 2004 Hewlett-Packard

Other Accessories

Manual

	C5894-60133	DeskJet 710C/712C user's guide (Traditional Chinese) NO LONGER SUPPLIED
	C5894-60134	DeskJet 710C/712C user's guide (Thai) NO LONGER SUPPLIED
	C5894-60135	DeskJet 710C/712C user's guide (Turkish) NO LONGER SUPPLIED

Restraint

	C6409-80031	Right carriage restraint - Used to protect the carriage assembly from damage during shipment

Retainer

	C6409-80030	Left carriage retainer - Protects the carriage assembly from damage during shipment

Return Kit

	5183-5268	Return kit with box and instructions - For returning defective Thermal InkJet (TIJ) 2.5 InkJet cartridges covered under the CREW program - For USA
	5184-2833	Return kit with box and instructions - For returning defective Thermal InkJet (TIJ) 2.5 InkJet cartridges covered under the CREW program - For use outside of the USA

Training Kit

	5183-3032	ASP training kit - Service manual CD-ROM and NTSC training videos for 400, 540, 600, and 700 family DeskJet printers NO LONGER SUPPLIED

Other Internal Parts

Brace

110	C4557-40128	Left bacKBone brace - Provides support for bacKBone
111	C4557-40130	Left wall brace - Provides support for left wall
112	C5870-40020	Right backbone brace - Installed on right side of printer base to provide support for backbone

Ferrite Assembly

113	9170-1655	Ferrite core

Frame

114	C5870-40039	Wing frame - Chassis for in/out tray components

Shield

115	C4557-00038	Paper motor ESD shield
116	C4557-00040	Main logic board EMI shield

Spring

117	C4557-00042	EMI spring - Provides grounding point between upper paper guide hanger and EMI shield NO LONGER SUPPLIED

Paper Tray Parts

Cam

161	C4557-40034	Drawer cam - Short, spring loaded lever attached to the base of the wing frame - Used to draw input tray into position

Channel

162	C5870-00006	Width adjust channel

Door

163	C4557-40026	Output door - Separates output media from input media

Guide

164	C5870-40037	Length adjuster - Media input length adjuster NO LONGER SUPPLIED
165	C6409-40034	Left wall pusher - Pushes against left side of media to maintain correct edge alignment
166	C6411-40004	Width adjust (Gray) - Holds media against right wall of input tray NO LONGER SUPPLIED

© 2004 Hewlett-Packard

Paper Tray Parts

Lever

167	C6411-40006	Banner lever - Used to choose either single sheet paper or continuous feed (Banner) paper NO LONGER SUPPLIED

Pad

168	C4557-80027	Length adjust pad (Poron) - Mounted under the fine length adjuster

Panel

169	C4557-40098	Paper tray left inner panel (Left cheek cap)
170	C4557-40099	Paper tray right inner panel (Right cheek cap) NO LONGER SUPPLIED
171	C4557-40116	Paper tray left outer panel (Left cheek)
172	C5870-40019	Paper tray right outer panel (Right cheek)

Spring

173	C4557-00012	Right wing spring - Applies pressure to right wing during paper output NO LONGER SUPPLIED
	C6409-00017	*New Part for C4557-00012*
174	C4557-00029	Left wall spring (Front) - Holds left wall assembly in position
175	C4557-00030	Left wall spring (Rear) - Provides pressure against media
176	C4557-00031	Paper length adjuster spring - Provides tension for paper input length adjuster
	C6455-00011	*New Part for C4557-00031*
177	C4557-00035	Paper pusher spring - Maintains alignment in paper tray
178	C4557-20020	Envelope spring - Holds envelopes in position for picking
179	C6409-00017	Wing torsion spring - Provides pressure on the wing during paper output NO LONGER SUPPLIED

Stop

180	C6411-40005	Fine paper length adjuster (Gray) - Holds paper firmly against the back of the paper input tray

Tray

181	C4557-60049	Paper input tray pressure plate
182	C5870-40028	Paper input tray base - Does not include the pressure plate assembly

Tray Assembly

183	C5870-60081	Paper input tray assembly (partial) - Includes only base of tray and pressure plate assembly
184	C6411-60004	Paper tray left side assembly (Left cheek assembly) - Includes left cheek, banner PCA and cable assembly, banner switch lever NO LONGER SUPPLIED

Wing

185	C4557-40024	Left wing - Holds printed paper after being ejected
186	C4557-40025	Right wing - Holds printed paper after being ejected

Paper and Other Media

Film (Transparency)

C3832A	Premium InkJet transparency film - A4 size (21.0cm x 29.7cm) - 20 sheets per package
C3835A	Premium InkJet transparency film - A4 size (21.0cm x 29.7cm) - 50 sheets per package
C6053A	Premium InkJet rapid-dry tranparencies - A4 size (21.0cm x 29.7cm) - 50 sheets per package NO LONGER SUPPLIED
C3828A	Premium InkJet transparency film - A size (8.5 x 11-inches) - 20 sheets per package
C3834A	Premium InkJet transparency film - A size (8.5 x 11-inches) - 50 sheets per package
C6051A	Premium InkJet rapid-dry tranparencies - A size (8.5 x 11-inches) - 50 sheets per package NO LONGER SUPPLIED

© 2004 Hewlett-Packard

Paper and Other Media

Greeting Card Kit

C6587AN	Printable Expressions all occasions card kit - Includes 20 greeting cards and envelopes, and a CD-ROM with 24 original pieces of art NO LONGER SUPPLIED

Iron-On Transfers

C6065A	Iron-on T-shirt transfers - A4 size (21.0cm x 29.7cm) - 10 sheets per package (Asia)
C6050A	Iron-on T-shirt transfers - A4 size (21.0cm x 29.7cm) - 10 sheets per package
C6049A	Iron-on T-shirt transfers - A size (8.5 x 11-inches) - 10 sheets per package

Paper

C6828A	Greeting card paper pack (White) - A size (8.5 x 11-inches) - Felt textured - Includes 20 sheets and 20 envelopes
C6042A	Greeting card paper pack (White) - A4 size (21.0cm x 29.7cm) - Includes 20 sheets and 20 envelopes
C1812A	Greeting card paper pack (White) - A size (8.5 x 11-inches) - Includes 20 sheets and 20 envelopes

Paper (Banner)

C1821A	Banner paper - A4 size (21.0cm x 29.7cm) - Perforated for easy separation - 100 sheets per pack
C1820A	Banner paper - A size (8.5 x 11-inches) - 24 lb - Perforated for easy separation - 100 sheets per pack

Paper (Glossy)

C3837A	Premium glossy InkJet paper - A4 size (21.0cm x 29.7cm) - 50 sheets per package
C6045A	Glossy greeting cards - A4 size (21.0cm x 29.7cm) - 10 scored glossy cards and envelopes
C6044A	Glossy greeting cards - A size (8.5 x 11-inches) - 10 scored glossy cards and envelopes
C6817A	Professional glossy InkJet brochure and flyer paper - Glossy on both sides - A size (8.5 x 11-inches) - 50 sheets per box

Paper (InkJet Photo)

C6983A	Photo quality InkJet paper - With two sided semi-gloss finish - A size (8.5 x 11-inches) - 25 sheets per package
C7007A	Photo quality InkJet paper - With two sided matte finish - A size (8.5 x 11-inches) - 100 sheets per package

Paper (InkJet)

51634Z	InkJet non-glossy LX paper - A4 size (21.0cm x 29.7cm) - 200 sheets per package
C1825A	Bright white InkJet paper - A4 size (21.0cm x 29.7cm) - 500 sheets per package
C1853A	Premium InkJet heavyweight paper - A4 size (21.0cm x 29.7cm) - Coated on both sides - 100 sheets per package
C5977A	Bright white InkJet paper - A4 size (21.0cm x 29.7cm) - 200 sheets per package
C5977B	Bright white InkJet paper - A4 size (21.0cm x 29.7cm) - 250 sheets per package
51634Y	InkJet non-glossy LX paper - A size (8.5 x 11-inches) - 200 sheets per package
C1824A	Bright white InkJet paper - A size (8.5 x 11-inches) - 500 sheets per package
C5976A	Bright white InkJet paper - A size (8.5 x 11-inches) - 200 sheets per package
C5976B	Bright white InkJet paper - A size (8.5 x 11-inches) - 250 sheets per package

Paper (Matte)

C7018A	Matte greeting cards (White) - Half fold - A size (8.5 x 11-inches)
C6955A	Professional and flyer paper (Matte) - A size (8.5 x 11-inches) - 50 sheets

Paper (Photo)

C6979A	Premium glossy photo paper (fast dry time) - A size (8.5 x 11-inches) - 50 sheets per package
C1847A	Photo paper - A4 size (21.0cm x 29.7cm) - 20 sheets per package
C6040A	Premium glossy photo paper - A4 size (21.0cm x 29.7cm) - 15 sheets per package (Europe, Brazil, and Argentina)
C6043A	Premium glossy photo paper - A4 size (21.0cm x 29.7cm) - 15 sheets per package (Japan)
C6057A	Premium glossy photo paper - A4 size (21.0cm x 29.7cm) - 20 sheets per package NO LONGER SUPPLIED
C1846A	Photo paper - A size (8.5 x 11-inches) - 20 sheets per package
C6039A	Premium glossy photo paper (Fast dry time) - A size (8.5 x 11-inches) - 15 sheets per package

© 2004 Hewlett-Packard

Paper and Other Media

Paper (Photo)

	C6055A	Deluxe glossy photo paper - A size (8.5 x 11-inches) - 20 sheets per pack - For use with DeskJet KIE-logo printers
	C6039A	*New Part for C6055A*

Paper (Textured)

	C7019A	Textured greeting card - White half fold - A size (8.5 inches x 11 inches)

Stickers

	C6822A	Round re-stickable InkJet stickers - HP bright white 6.35cm (2.5in) round stickers with 3M 'Post-it' adhesive - A size (8.5 x 11-inches) - 10 sheets per package with nine stickers per sheet
	C6823A	Square re-stickable InkJet stickers - HP bright white 6.35cm (2.5in) square stickers with 3M 'Post-it' adhesive - A size (8.5 x 11-inches) - 10 sheets per package with nine stickers per sheet

Print Mechanism Parts

Adjuster

187	C6409-40021	Carriage rod adjuster - Used to support and align the carriage rod (2 used) - This item should be replaced only by trained, experienced service personnel NO LONGER SUPPLIED

Backbone

188	C6409-00013	BacKBone - Large metal item where the main logic PCA and the carriage drive motor are mounted - This item should be replaced only by trained, experienced service personnel

Belt

189	C4557-40049	Carriage drive belt - Moves printhead side to side NO LONGER SUPPLIED

Blade

190	C2145-00037	ESD blade - Installed between cartridge and carriage PCA ESD blade - Installed between cartridge and carriage PCA

Bracket

191	C5870-00010	Paper motor mounting bracket

Cam

192	C6409-40040	Pick cam - Controls pressure plate and lever NO LONGER SUPPLIED

Carriage

193	C6409-40031	Ink cartridge carriage
194	C6409-60003	Ink cartridge carriage assembly - This item should be replaced only by trained, experienced service personnel

Encoder

195	C4557-80019	Paper motor encoder disk

Flag

196	C5870-40024	OOPS flag - Media sensor - Mounts on the top right edge of the upper paper guide

Gear

197	C4557-40007	Pick gear
198	C4557-40021	Feed roller idler gear
199	C4557-40095	Encoder gear
200	C4557-40102	Feed roller cluster gear

Guide

201	C4557-40013	Rear paper guide - Guides media through rear of printer
202	C4557-40020	Lower guide - Platform for seperator peg, spring and pad
203	C4557-40121	Paper encoder disk guide
204	C6409-40022	Upper paper guide - Guides media through paper path NO LONGER SUPPLIED

© 2004 Hewlett-Packard

Print Mechanism Parts

Latch

205	C4557-40042	Plastic latch (Y-shaped) - Used in conjuction with the knob to hold the rear paper cleanout door assy in place
206	C4557-60045	Cartridge latch (Black) - Holds black ink cartridge in place NO LONGER SUPPLIED
207	C4557-60046	Cartridge latch (Color) - Holds color ink cartridge in place

Lever

208	C4557-00037	Pressure plate lever - Transfers upward pressure from the separator lifter to the kicker
209	C5870-40022	Paper pusher - Small, spring loaded lever attached to pivot - Pushes against left side of paper to maintain right edge alignment

Lifter

210	C4557-40063	Separator lifter - Used to lift the separator peg

Link

211	C6429-60025	Kicker bar cam link (Spring loaded)

Motor

212	C4557-60003	Carriage motor assembly (Includes pulley)
213	C6409-60004	Paper advance motor

Paper Stacker

214	C4557-40016	Kicker - Restacks paper in stack after top sheet is picked

Pin

215	C4557-40085	Link pin - Small plastic piece
	C6429-60025	*New Part for C4557-40085*
216	C5870-40029	Separator peg

Plate

217	C6409-40028	Belt Attachment Plate - Mounted to back of Ink Cartridge Carriage Assembly - Used to attach the Carriage Drive Belt

Print Mechanism

218	C5870-69080	Print mechanism assembly - Complete mechanism with carriage movement, paper picking and service station operations NO LONGER SUPPLIED

Retainer

219	C4557-00024	Ferrite retainer - Holds head drive flex cable ferrite
220	C4557-20026	Felt retainer - Holds the lubricating felt to the side of the carriage

Rod

221	C6409-20004	Carriage rod - Shaft that the carriage assembly rides on - This item should be replaced only by trained, experienced service personnel

Roller

222	C4557-20002	Pinch roller - Provides downward pressure on media as it passes by upper paper guide
223	C4557-40015	Rear roller (Black) - Between paper and rear paper guide NO LONGER SUPPLIED
224	C4557-60025	Pivot feed roller - Shaft with 4 hard rollers - Does not include other items such as gear or encoder
225	C5870-40030	Postscan roller - Shaft with 2 rollers - Mounts on underside of the lower ADF chassis
226	C5870-60092	Pickup roller assembly - Shaft with large rollers, gear, and 2 bearings - Picks paper from paper input tray - Available for trade sales in Europe and Asia/Pacific - Available for authorized service centers only in USA
227	C6409-60037	Pivot feed roller assembly - Shaft with small rollers and paper encoder - This item should be replaced only by trained, experienced service personnel
228	C6426-60049	Pickup roller - Shaft with large rollers - Does not include other items such as gear or bearings

© 2004 Hewlett-Packard

Print Mechanism Parts

Separator

229	C4557-60011	Separator pad

Shaft

230	C4557-20027	Cartridge latch shaft near top of carriage - Used to hold cartridge latches in place

Shift Plate

231	C6455-60057	Shift plate assembly - Five plastic gears held in a two piece plastic frame - Attaches to feedroller assembly

Slide

232	C5870-40036	Integrated slider for carriage assembly

Snap

233	C4557-40150	Pivot snap - Used to hold pivot to pick feed roller shaft

Spring

234	C2145-00033	ESD spring between ESD blade and carriage PCA
235	C4557-00009	Separator spring - Provides pressure between separator assembly and the center drive roller
236	C4557-00011	Drawer spring - Holds input drawer in place
237	C4557-00017	Belt tension spring - Provides tension for carriage belt
238	C4557-00018	Encoder spring - Provides tension for encoder strip
239	C4557-00033	Link spring - Provides tension to shaft of pick cam gear
240	C4557-20003	Rear roller spring - Flexible axle for rear roller
241	C4557-20007	Pinch spring - Provides tension on upper paper guide
242	C4557-20009	Latch spring - Provides friction for rear access door knob
243	C4557-20024	Shifter spring - Provides tension on the pivot
244	C4557-20028	EOR tension spring - Maintains tension on wear strip
245	C5870-20002	Paper stacker (kicker) spring

Strip

246	C4557-80001	Encoder strip - Clear strip with position marks - Used by the sensor in the carriage assembly to determine position
247	C5870-00004	Wear strip - Long, spring loaded strip mounted in top of backbone - Used to ensure smooth ink cartridge carriage motion

Support

248	C6409-00008	Upper paper guide support - Base for upper paper guide NO LONGER SUPPLIED

Turnaround Assembly

249	C4557-60109	Turnaround assembly - Provides carriage belt tension - Does not include spring

Washer

250	C4557-80002	Felt washer - Used to lubricate the carriage rod

Service Station Parts

Absorber

251	C5870-80007	Spittoon sponge - Absorbs excess ink from cartridges

Bonnet

252	C5870-40016	Service station bonnet - Top cover of the spittoon - Has cutout for pallet/link assembly

Clip

253	C5870-00002	Service station ESD grounding clip

Gear

254	C4557-40079	Transfer gear (Double gear)
255	C5870-40017	Cluster gear (Large gear)

© 2004 Hewlett-Packard

Service Station Parts

Motor

256	C5870-60004	Service station motor assembly - Includes PC board and gear

Pallet

257	C6426-60054	Pallet/link assembly - Installed between spittoon and sled cap assembly - Mounting platform for the wiper and capping systems parts

Shaft

258	C4557-40066	Drive shaft with molded gears on each end - Inside the service station spittoon assembly

Sled

259	C4557-60013	Sled cap assembly - Top cover of the service station assembly - Includes print cartridge caps (gaskets which keep the cartridges from drying out when not printing)

Snap

260	C4557-40069	Cap snap - Installed between pallet/link assembly and sled cap assembly - Used to hold the cap spring

Spittoon

261	C5870-40014	Spittoon base - The bottom of the service station assembly

Spring

262	C4557-00026	Cap spring - Provides pressure to cap parked print cartridges

Vent


263	C4557-40068	Cap vent - For equalizing the print cartridge capping pressure

Wiper

264	C4557-60014	Wiper assembly - Metal base with plastic wipers


© 2004 Hewlett-Packard

Main Assembly Locator




© 2004 Hewlett-Packard

Carriage Assembly




© 2004 Hewlett-Packard

Paper Drive Motor Assembly




© 2004 Hewlett-Packard

Paper Tray Assembly (1 of 2)




© 2004 Hewlett-Packard

Paper Tray Assembly (2 of 2)




© 2004 Hewlett-Packard

Printer Mechanism (1 of 2)




Printer Mechanism (2 of 2)

← 1 of 2




© 2004 Hewlett-Packard

Rear Access Cleanout Assembly




© 2004 Hewlett-Packard

Service Station



© 2004 Hewlett-Packard

Upper Paper Guide Assembly



© 2004 Hewlett-Packard

HP Parts Reference Guide
http://www.hp.com/go/parts

HP PartSurfer
http://partsurfer.hp.com

HP Parts Ordering Information
http://www.hp.com/go/hpparts

HP Parts Questions/Comments
http://partsurfer.hp.com/contactus.htm

© 2004 Hewlett-Packard