

IMPORTANT SAFETY INSTRUCTIONS

As with any electrical device, certain precautions must be taken in order to ensure your safety.

READ ALL INSTRUCTIONS BEFORE USING

DANGER— To reduce the risk of death or serious injury from electric shock:

1. Do not reach for an appliance that has fallen into water. **Unplug immediately.**
2. Do not use while bathing or in a shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
4. Always unplug this appliance from the electrical outlet immediately after using.
5. Unplug this appliance before cleaning or changing head.

WARNING — To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
2. This appliance should never be left unattended when plugged in.
3. This product should not be used by, on, or near children or individuals with certain disabilities.
4. Never operate this appliance if it has a damaged cord or plug, if it is not working properly,

if it has been dropped, damaged or dropped into water. Return the appliance to a service center for examination or repair.

5. Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
6. Never drop or insert any object into any opening. Keep the air openings free of lint, hair and the like.
7. Never operate the appliance with the air opening blocked or while on a soft surface, such as a bed or a couch, where the air openings may be blocked.
8. Do not place appliance on any surface while it is operating.
9. Do not use outdoors or operate where aerosol spray products are being used or where oxygen is being administered.
10. When using this appliance with its cord, be mindful of tangles or kinks in the cord. If the cord does become tangled during use, turn the unit off and straighten cord before operating again.
11. Never use while sleeping.
12. Do not use an extension cord with this appliance.

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

COMPACT EPILATOR

Before using the Class 2 Power supply, read these instructions carefully.

Rated input voltage: 120Vac, 60Hz.

Rated output: 12VDC, 400mA

For almost 25 years, Conair has been responding

with the other. **Only move your epilator against the direction of the growth of your hair. Do not use circular or back-and-forth motions.**

4. Slowly move the hair remover, while pressing down lightly. Careful not to press the appliance down too hard against your skin; it might slow down and be less effective.

Removing hair from sensitive areas:


To remove hair from sensitive areas, we recommend putting the accessory for sensitive areas on the head of your hair remover. It reduces the number of hair remover disks so that you can remove hair more smoothly and with greater precision.

If your hair is long (longer than 1 cm), we recommend cutting it with scissors before using your hair remover, preferably set at speed I.

1. To remove hair from your underarms, move the appliance using an upward motion, then a second time using a downward motion.



2. To remove hair from your bikini line, carefully stretch your skin and move the appliance working from the outside in.



C - Moisturizing:

After hair removal, we recommend using a moisturizing milk to soften your skin. Apply the milk then massage it in using circular motions to help your skin absorb it.

IMPORTANT


- Only use Conair® epilator for hair removal and following the instructions in this manual.
- Do not remove hair from areas with open wounds, cuts, burns, warts, moles, sunburn skin or varicose veins. Do not use if you are suffering from a skin irritation, skin infections like psoriasis or eczema on the legs, or any skin ailment or disease.
- Do not use for removing hair from your face, head, chest, eyebrows, eyelashes or genitals. Only use the epilator to remove hair from your legs, bikini line, arms and underarms.

MAINTENANCE

• To clean the rotating disks, remove the upper part that protects them simply by sliding up.

Caution: pull without pressing on the buttons on the sides of the appliance so as not to remove the whole hair removal head.

- Run the provided cleaning brush between the disks after each use.
- We recommend you regularly disinfect the head and accessories with alcohol. Never immerse the appliance or the removable heads in water.
- If the body of the appliance needs to be cleaned, use a cloth moistened with soft detergent.




to the women's desires for hair removal systems. Your new compact epilator is the result of Conair's advanced research.

- Effective, its hair removal head removes hair with the hair bulb. Your skin remains hair-free for about three weeks.
- Easy to use, it has accessories that have been specially designed to remove hair from sensitive areas (bikini line, underarms).

DESCRIPTION OF THE EPILATOR

1. Hair removal head (18 tweezers)
2. Accessory for sensitive areas
3. Protective cap
4. Cleaning brush
5. Storage pouch
6. Adaptor



TIPS FOR SUCCESSFUL EPILATION

A- Scrubbing:

Scrubbing is a necessary step for successful hair removal. Done regularly, it:


- prevents hair from growing back under the skin,
- removes dead cells and refines the texture of your skin,
- prepares your skin to help it absorb skin care products. (We recommend a loofa sponge – not included).

Scrubbing done once or twice a week maintains a healthy and fresh skin. We recommend scrubbing ideally the day before hair removal. The scrubbing will straighten the hair thereby helping you to remove it. Avoid scrubbing just after hair removal.

B- Hair Removal:

Your Conair® epilator has 18 tweezers that work like many small hair-removing tweezers. For perfect efficiency, we recommend you use it on fairly short hair (0.5 cm). Before removing hair, we recommend taking a warm shower. The warmth will help your pores dilate and thereby ease removal of the hair. **To remove hair successfully, it is essential to look closely at the direction in which the hair grows in the area where hair is to be removed. It is important to move the hair remover in the direction opposite to that of the hair growth; failure to do so could result in the hair being simply cut or being improperly pulled and then it growing back under the skin.**

Removing hair from the legs:



1. Put the hair removal head on the appliance. Turn it on. Select speed I or II (I: fine hair/II: coarse hair).
2. Hold the appliance at an angle of 90 degrees to the surface of where hair is to be removed.
3. Always work with both hands: carefully stretch the skin with one hand while moving the appliance

LIMITED TWO YEAR WARRANTY

Conair will repair or replace, at our option, your appliance free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service centre listed below together with your sales slip and \$7.50 for postage and handling. In the absence of a receipt, the warranty period shall be 24 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24 MONTH DURATION OF THIS WARRANTY.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

This warranty gives you specific legal rights, and you may also have other rights which vary from province to province.

SERVICE CENTRE:

Conair Consumer Products Inc.
100 Conair Parkway,
Woodbridge, ON L4H 0L2.
1-800-472-7606

©2009 Conair Consumer Products Inc.
www.conaircanada.ca
Consumer Call Centre E-mail :
Consumer_Canada@Conair.com
09CN14446

IB-9360

CONAIR® *compact epilator*

*hair removal results last longer than shaving
and produce smooth, silky skin.*

Have a Question?

*Please do not return this product
to the retailer.*

Call Us First!

Our customer service and product experts
are ready to answer ALL your questions.

Please call our TOLL-FREE
customer service number at:

1-800-472-7606

or visit us online at
www.conaircanada.ca



INSTRUCTIONS FOR CARE AND USE
MODEL EP1CSC