



6010 - 99 Street, Edmonton, Alberta T6E 3P2 Phone: (780) 435-2211 Fax: (780) 437-4964
www.specialeventrentals.com info@specialeventrentals.com Toll Free: 1-888-601-2961

Econo Floss Operating Instructions

There is a \$35.00 cleaning charge that will apply to each unit that is not clean upon return.

ELECTRICAL REQUIREMENTS:

Econo Floss machine requires a 15 amp., 110 volt outlet

HOW TO OPERATE:

- 1) Plug machine into outlet and place pan on top around head. DO NOT USE AN EXTENSION CORD!
- 2) Flip main power, motor and heat switch to the 'ON' position.
- 3) With motor running, fill floss head about 90% full with floss sugar.
- 4) Cotton candy will start appearing within about 30 seconds.
- 5) Cotton candy should feel dry like hair. If it is damp, turn the heat down. Also, if the machine begins to smoke, turn the heat down.
- 6) If the floss seems to be flying out of the pan, bend the leather strips on the head up.

TO MAKE A CONE:

- 1) Hold the paper cone between thumb and two fingers, and break into the floss with the cone.
- 2) Let a little floss build up on the cone and then start to rotate the cone.
- 3) Roll the cone along the pan, rotating it towards the inside of the pan.
- 4) To bag the floss, use the cone or gloved hand, put two balls of the floss into the bag.
- 5) Seal the bag keeping as much air in the bag as possible to preserve the look of the floss. Remember: 2 colors in the bag sell better than one!

CLEANING INSTRUCTIONS

Wash floss pan and wipe down the machine. DO NOT CLEAN THE FLOSS HEAD. Leave the left over sugar inside the machine for our experienced employees to remove.

SPECIAL EVENT RENTALS WILL NOT ASSUME ANY LIABILITY FOR INJURY DUE TO CARELESS HANDLING OR OPERATION OF THIS EQUIPMENT.

Should any problems arise or if you have any questions, contact us at (780) 435 - 2211 or after hours on our pager at (780) 951-8082

For Office Use Only

CLEANED/TESTED BY: _____

DATE TESTED: _____

SERIAL # _____

FLOSS PAN: _____YES _____NO

STABILIZER CLIPS: _____YES _____NO

MESH SCREEN: _____YES _____NO

PLASTIC DOME: _____YES _____NO

SPINNER MOTOR: _____YES _____NO

BOX FOR DOME: _____YES _____NO

BOX FOR SPINNER MOTOR: _____YES _____NO