






Open the flex port cover and plug the USB cable into the PowerPlant. Plug the other end of the cable into your device. Press the Power button once to start charging. Hold the Power button for 2 seconds to turn the PowerPlant off













4 Charging Your PowerPlant

Open the flex port cover and plug the micro-USB cable into the micro-USB port. Plug the other end of the micro-USB cable into any USB power source such as a PC, Laptop, USB home or car charger, etc. For fastest charge time, use a USB power source rated at 1 Amp or higher.

While charging, the LEDs will light up in order from one to four. When the PowerPlant is fully charged, all the LEDs will turn off.





Note: Devices will start charging when the PowerPlant is 70% charged.

*Power supply not included



Specifications:

Battery Cell: Li-ion Polymer Battery Capacity: 5,200mAh Output Voltage: 4.75 - 5.25V Output Current: 2.1A Battery Charge Time: 6 - 7 hrs

Battery Charge Time: 6 - 7 hrs Dimensions: 78 x 44 x 33 mm

Weight: 5.4 Oz.



Warning:

Do not disassemble.

Do not immerse in water.

Do not store near a heat source above 120°F. Do not short circuit.

For additional information, please visit our website at www.tylt.com

©2013 TYLT. All rights reserved.

TYLT* and the TYLT* logo are registered trademarks of Foreign Trade Corp.

Other marks are the property of their respective owners.

[C1371]

